



# **Installation Guide**

## **QLogic intelligent Storage Router (iSR)**

6200 Series

Information furnished in this manual is believed to be accurate and reliable. However, QLogic Corporation assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties which may result from its use. QLogic Corporation reserves the right to change product specifications at any time without notice. Applications described in this document for any of these products are for illustrative purposes only. QLogic Corporation makes no representation nor warranty that such applications are suitable for the specified use without further testing or modification. QLogic Corporation assumes no responsibility for any errors that may appear in this document.

Document Revision History	
Revision A, March 20, 2009	
Revision B, May 24, 2009	
Revision C, November 30, 2009	
Revision D, May 14, 2010	
Revision E, October 29, 2010	
Revision F, November 8, 2010	
Revision G, September 28, 2011	
Revision H, May 18, 2012	
Revision J, December 02, 2012	
Changes	Sections Affected
Updated Documentation Conventions	<a href="#">“Documentation Conventions” on page xiii</a>
Updated Technical Support, Training, Contact Information, and Knowledge Base	<a href="#">“Technical Support” on page xix</a> , <a href="#">“Training” on page xx</a>
Added China Compulsory Certification warnings	<a href="#">“China Compulsory Certification (CCC) Warnings” on page xviii</a>
Added Simplified Chinese translation to warnings	<a href="#">“警告” on page 3-5</a> , <a href="#">“警告” on page 3-9</a>
Added French, German, Spanish, and Simplified Chinese to the warning	<a href="#">“Connecting the Router to AC Power” on page 3-7</a>

# Table of Contents

## Preface

Intended Audience . . . . .	xi
What's in This Guide . . . . .	xi
Related Materials . . . . .	xii
Documentation Conventions . . . . .	xiii
Communications Statements . . . . .	xv
Federal Communications Commission (FCC) Class A Statement . . .	xv
Canadian Department of Communications Class A Compliance Statement . . . . .	xv
Avis de conformité aux normes du ministère des Communications du Canada . . . . .	xv
CE Statement . . . . .	xvi
VCCI Class A Statement . . . . .	xvii
BSMI Class A Statement . . . . .	xvii
Laser Safety Information . . . . .	xvii
Electrostatic Discharge Sensitivity (ESDS) Precautions . . . . .	xviii
China Compulsory Certification (CCC) Warnings. . . . .	xviii
Accessible Parts. . . . .	xviii
License Agreements. . . . .	xviii
Technical Support. . . . .	xix
Downloading Updates . . . . .	xix
Training . . . . .	xx
Contact Information . . . . .	xx
Knowledge Database . . . . .	xx

## 1

## Introduction

Router Capabilities and Features. . . . .	1-1
Licensed Features . . . . .	1-2
Data Migration . . . . .	1-2
Remote SAN Island Connectivity . . . . .	1-2
iSR6200 Router Chassis . . . . .	1-3
Power and Cooling Module (PCM). . . . .	1-5
iSR6200 Router Blades . . . . .	1-6

iSR6200 Router Family Models . . . . .	1-7
iSR6260 Router Blade . . . . .	1-7
iSR6250 Router Blade . . . . .	1-8
iSR6240 Router Blade . . . . .	1-9
Router Blade LEDs . . . . .	1-9
Heartbeat LED (Green) . . . . .	1-9
System Fault LED (Amber) . . . . .	1-10
Input Power LED (Green) . . . . .	1-10
Beacon Indicator (Blue) . . . . .	1-10
Maintenance Button . . . . .	1-11
Reset a Router Blade . . . . .	1-11
Reset and Select Boot Image . . . . .	1-12
Reset IP Address . . . . .	1-12
Enable DHCP . . . . .	1-12
Restore Factory Defaults . . . . .	1-12
Fibre Channel Port LEDs . . . . .	1-13
Fibre Channel Transceivers . . . . .	1-14
Gigabit Ethernet Port LEDs . . . . .	1-15
Ethernet Port—Management . . . . .	1-15
Serial Port . . . . .	1-16

## 2

### Planning

Devices . . . . .	2-1
Device Access . . . . .	2-2
Fibre Channel . . . . .	2-2
iSCSI . . . . .	2-2
Fibre Channel Switches Required for VPGroups . . . . .	2-2
Fibre Channel Performance . . . . .	2-2
Distance . . . . .	2-2
Bandwidth . . . . .	2-3
Latency . . . . .	2-3
iSCSI Performance . . . . .	2-3
Distance . . . . .	2-3
Bandwidth . . . . .	2-3
Latency . . . . .	2-4
Performance Tuning . . . . .	2-4
Topology . . . . .	2-7
High Availability . . . . .	2-7
Management . . . . .	2-7
Recovery . . . . .	2-8

	Services .....	2-8
	Security .....	2-9
<b>3</b>	<b>Installation</b>	
	Site Requirements .....	3-1
	Management Workstation .....	3-1
	Power Requirements .....	3-2
	Environmental Conditions .....	3-2
	Installing the iSR6200 Router .....	3-2
	Pre-installation Check List .....	3-3
	Mounting the Router .....	3-5
	Installing the Transceivers .....	3-6
	Connecting the Router to AC Power .....	3-7
	Connecting the Management Workstation to the Router .....	3-10
	Configuring the Management Workstation .....	3-11
	Setting the Workstation IP Address .....	3-11
	Configuring the Workstation Serial Port .....	3-12
	Installing SANsurfer Router Manager .....	3-13
	Downloading the SANsurfer Router Manager Installer .....	3-13
	Windows Installation .....	3-15
	Linux Installation .....	3-15
	Mac OS X Installation .....	3-15
	Starting SANsurfer Router Manager .....	3-16
	Configuring the Router .....	3-16
	Connecting Cable Devices to the Router .....	3-17
	Installing New Firmware .....	3-17
	Using SANsurfer Router Manager to Install Firmware .....	3-18
	Using the CLI to Install Firmware .....	3-18
<b>4</b>	<b>Configuration</b>	
	Enabling Virtual Port Groups .....	4-2
	Zoning Virtual Port Groups on the SAN .....	4-9
	Configuring Fibre Channel Array Hosts and LUN Assignments .....	4-12
	Connecting iSCSI Hosts to the iSR6200 .....	4-16
	Controlling per-Host LUN Access on the iSR6200 .....	4-22
<b>5</b>	<b>Fibre Channel over IP</b>	
	FCIP Attributes .....	5-1
	Configuring FCIP .....	5-2
	Configuring an FCIP Route Using the CLI .....	5-4
	E_Port Extension .....	5-6

	F_Port Extension . . . . .	5-8
	Determining WAN Characteristics . . . . .	5-10
	Round-Trip Time . . . . .	5-11
	Link Data Rate . . . . .	5-12
	Link Quality . . . . .	5-12
	Firewall . . . . .	5-15
	Data Compression . . . . .	5-16
	Bandwidth Limiting . . . . .	5-16
	TCP Window Settings . . . . .	5-17
	Router TCP Window Setup . . . . .	5-22
<b>6</b>	<b>Diagnostics and Troubleshooting</b>	
	Chassis Diagnostics . . . . .	6-1
	Input Power LED is Off . . . . .	6-2
	System Fault LED is On . . . . .	6-2
	Power-On Self-Test Diagnostics . . . . .	6-2
	LED Blink Patterns . . . . .	6-2
	Heartbeat Blink Pattern . . . . .	6-3
	System Error Blink Pattern . . . . .	6-3
	Management Port IP Address Conflict Blink Pattern . . . . .	6-3
	Over-Temperature Blink Pattern . . . . .	6-4
	Recovering a Router . . . . .	6-4
<b>7</b>	<b>Removal and Replacement</b>	
	SFP Transceivers . . . . .	7-1
	iSR6200 Chassis Blades . . . . .	7-1
	Dual-Blade Installation . . . . .	7-2
	Removing the Failed Blade . . . . .	7-2
	Installing the Replacement Blade . . . . .	7-3
	Single-Blade Installation . . . . .	7-4
	Removing the Failed Blade . . . . .	7-5
	Installing the Replacement Blade . . . . .	7-8
	Power and Cooling Modules . . . . .	7-10
	Removing the Failed PCM . . . . .	7-11
	Installing the Replacement PCM . . . . .	7-12
<b>A</b>	<b>Technical Specifications</b>	
	Interface Specifications . . . . .	A-1
	Expansion Configurations . . . . .	A-2
	Performance Features . . . . .	A-2

iSCSI Initiator Support .....	A-3
Device Management .....	A-3
Mechanical .....	A-3
High Availability .....	A-4
Protocols .....	A-4
Environmental and Safety .....	A-4

## **B Simple Network Management Protocol**

SNMP Parameters .....	B-2
SNMP Trap Configuration .....	B-3
Management Information Base (MIB) .....	B-3
Network Port Table .....	B-4
FC Port Table .....	B-7
Initiator Object Table .....	B-9
LUN Table .....	B-12
VP Group Table .....	B-14
Sensor Table .....	B-16
Notifications .....	B-18
System Information Objects .....	B-18
Notification Objects .....	B-20
Agent Startup Notification .....	B-20
Agent Shutdown Notification .....	B-20
Network Port Down Notification .....	B-21
FC Port Down Notification .....	B-21
Target Device Discovery .....	B-21
Target Presentation (Mapping) .....	B-22
VP Group Notification .....	B-22
Sensor Notification .....	B-22
Generic Notification .....	B-24

## **C Log Messages**

### **Glossary**

### **Index**

## List of Figures

Figure	Page
1-1 Remote SAN Island Connectivity . . . . .	1-2
1-2 iSR6200 Router . . . . .	1-4
1-3 iSR6200 Router Chassis—Front and Back Plates . . . . .	1-4
1-4 PCM—Back Plate . . . . .	1-5
1-5 PCM—Front . . . . .	1-5
1-6 Fibre Channel Ports on the iSR6260 Router Blade . . . . .	1-7
1-7 10GbE Ports on the iSR6250 Router Blade . . . . .	1-8
1-8 iSCSI (GE) Ports on the iSR6240 Router Blade . . . . .	1-9
1-9 Router Blade LEDs . . . . .	1-9
1-10 Router Blade Controls . . . . .	1-11
1-11 Fibre Channel LEDs . . . . .	1-13
1-12 Gigabit Ethernet Ports . . . . .	1-15
1-13 Ethernet Management Port . . . . .	1-15
1-14 Serial Port . . . . .	1-16
2-1 WAN Topology—Remote SAN Interconnect . . . . .	2-7
3-1 iSR6200 Router Chassis—Front and Back Plates . . . . .	3-9
3-2 iSR6200 Blade Ports and LEDs . . . . .	3-10
3-3 Search Support Dialog Box (Example) . . . . .	3-14
3-4 Guided Search Results . . . . .	3-14
4-1 SANsurfer Router Manager VPGGroup . . . . .	4-3
4-2 Chassis Information for Selected VPGROUP . . . . .	4-4
4-3 Set VPGroup Message Box . . . . .	4-4
4-4 FC Port Information Page . . . . .	4-8
4-5 Single Blade, Single Fibre Channel Switch . . . . .	4-9
4-6 Single Blade, Dual Fibre Channel Switch . . . . .	4-10
4-7 High-Availability, Dual Blades, Dual Fibre Channel Switches . . . . .	4-11
4-8 Correctly Configured Storage Array Using Virtual Port Groups . . . . .	4-12
4-9 Incorrectly Configuring All Groups to One Host Entity . . . . .	4-13
4-10 Incorrectly Assigning VPG WWPNs . . . . .	4-13
4-11 Correct VPG Assignments for High Availability Configuration . . . . .	4-14
4-12 Correctly Assigning LUNs to Your VPG Host Entities . . . . .	4-15
4-13 Incorrectly Presenting LUN 3 . . . . .	4-16
4-14 Selecting the iSCSI Presented Targets in SANsurfer Router Manager . . . . .	4-18
4-15 Host Access to LUNs on Storage Array . . . . .	4-21
4-16 iSCSI Host Logged into iSCSI Target for VPG0 . . . . .	4-22
4-17 iSCSI Host Logged into iSCSI Target for VPG1 . . . . .	4-22
4-18 Logging into Target Before LUN Mapping . . . . .	4-23
4-19 Logging into Target After Mapping LUN 1 . . . . .	4-25
4-20 Target Presentation/LUN Mapping Wizard—Select the Initiators . . . . .	4-26
4-21 Target Presentation/LUN Mapping Wizard—LUN Selection . . . . .	4-26
4-22 Target Presentation/LUN Mapping Wizard—LUN Masking Configuration Status . . . . .	4-27
4-23 Logging In with Mapped LUNs . . . . .	4-28
4-24 Enabling LUN Mapping . . . . .	4-30



---

4-25	Host LUN Access with LUN Masking Disabled . . . . .	4-31
5-1	E_Port Extension, Single ISL . . . . .	5-7
5-2	E_Port Extension, Dual ISLs . . . . .	5-8
5-3	F_Port Extension, Remote Storage . . . . .	5-9
5-4	F_Port Extension, Server . . . . .	5-10
6-1	Router Blade Diagnostic LEDs . . . . .	6-1
7-1	iSR6200 Router Blade with Cables Disconnected . . . . .	7-2
7-2	Removing the Chassis Blade . . . . .	7-3
7-3	Unlatching the Lever on the New Blade . . . . .	7-3
7-4	Inserting the New Blade into the Chassis Slot . . . . .	7-4
7-5	iSR6200 Router Blade with Cables Disconnected . . . . .	7-7
7-6	Removing the Chassis Blade . . . . .	7-7
7-7	Unlatching the Lever on the New Blade . . . . .	7-8
7-8	Inserting the New Blade into the Chassis Slot . . . . .	7-8
7-9	Back Side of Two PCMs with Fault (left) and Good (right) Status Indicators . . . . .	7-11
7-10	Removing the Failed PCM . . . . .	7-12
7-11	Unlatching Lever on New PCM . . . . .	7-12
7-12	Inserting the Replacement PCM . . . . .	7-13
7-13	Back Side of Two PCMs, Both With Good Status Indicators . . . . .	7-13

## List of Tables

Table	Page
1-1 Internal Temperature Sensor Limits . . . . .	1-6
1-2 10GbE Port LED Scheme . . . . .	1-8
1-3 System Fault LED Blink Patterns . . . . .	1-10
1-4 Port LEDs . . . . .	1-13
2-1 T1—1.554Mbps . . . . .	2-4
2-2 T3—45Mbps . . . . .	2-5
2-3 OC-1—51Mbps . . . . .	2-5
2-4 OC-3—156Mbps . . . . .	2-6
2-5 OC-12—621Mbps . . . . .	2-6
3-1 Management Workstation Requirements . . . . .	3-1
3-2 Worksheet for Router Blade 1 (left) Parameters . . . . .	3-3
3-3 Worksheet for Router Blade 2 (right) Parameters . . . . .	3-4
5-1 FCIP Preconfiguration Information . . . . .	5-3
5-2 WAN Data Rates . . . . .	5-12
5-3 Ports Requiring Unblocking . . . . .	5-15
5-4 T1 / DS-1—1.554Mbps . . . . .	5-17
5-6 DS-5—400Mbps . . . . .	5-18
5-5 T3 / DS-3—45Mbps . . . . .	5-18
5-8 OC-3—150Mbps . . . . .	5-19
5-7 OC-1—50Mbps . . . . .	5-19
5-9 OC-3—150Mbps . . . . .	5-20
5-10 OC-12 and Above—621Mbps . . . . .	5-20
5-11 OC-24 and Above—1.244Gbps . . . . .	5-21
5-12 Router TCP Window Settings . . . . .	5-22
6-1 System Fault LED Blink Patterns . . . . .	6-3
B-1 SNMP Parameters . . . . .	B-2
B-2 SNMP Trap Configuration Parameters . . . . .	B-3
C-1 iSR6200 Router Log Messages . . . . .	C-2

# Preface

This user's guide describes and provides installation procedures for the QLogic® iSR6200 Series intelligent Storage Router (iSR) (iSR6200), also referred to as the *iSR6200 router* or simply *router*.

## Intended Audience

This guide is for users who are responsible for installing, managing, and servicing the iSR6200 router and the SAN equipment to which it is attached.

## What's in This Guide

This guide contains the information needed to install and configure the iSR6200 router. This preface explains the typographic conventions used in this guide, lists related documents, and specifies the intended audience. This section also provides safety and communications statements, as well as technical support and contact information.

The remainder of the user's guide is organized into the following chapters and appendices:

- [Chapter 1 Introduction](#) illustrates and describes QLogic's iSR6200 intelligent Storage Router (iSR), including the components contained within the iSR6200 router chassis: router blades and power and cooling modules (PCMs).
- [Chapter 2 Planning](#) describes how to plan for the iSR6200 router by considering the devices it needs to support, Fibre Channel and iSCSI port performance requirements, performance tuning, high availability (HA), network management, disaster and recovery, services, and system security.
- [Chapter 3 Installation](#) provides site requirements and describes how to install and configure an iSR6200 router. It also provides firmware installation instructions.
- [Chapter 4 Configuration](#) describes how to configure the iSR6200 router to support virtual port groups (VPGs) and LUN mapping.
- [Chapter 5 Fibre Channel over IP](#) describes the FCIP protocol attributes and configuration.

- 
- [Chapter 6 Diagnostics and Troubleshooting](#) provides system diagnostic and troubleshooting tools available for the iSR6200 router.
  - [Chapter 7 Removal and Replacement](#) describes how to remove and replace the following field replaceable units (FRUs): small form-factor pluggable (SFP) transceivers, iSR6200 chassis blades, and PCMs.
  - [Appendix A Technical Specifications](#) summarizes the technical aspects of the iSR6200 router, including the interface, expansion configurations, performance features, iSCSI initiator support, device management, mechanical components, high availability features, data migration, supported protocols, and environment and safety measurements.
  - [Appendix B Simple Network Management Protocol](#) provides reference material for the simple network management protocol (SNMP), which you can use to manage the iSR6200 router using a third-party SNMP management application.
  - [Appendix C Log Messages](#) provides reference material on messages logged to a file, which you can retrieve using either the command line interface (CLI) (see the *iSR6200 Command Line Interface (CLI) User's Guide*) or SANSurfer Router Manager (see the *iSR6200 Router Manager User's Guide*).

Following the appendices are a glossary of terms used and an index to help you quickly find the information you need.

## Related Materials

For additional information, refer to the following documents:

- *iSR6200 Router Quick Start Guide*, part number IS0054504-00
- *iSR6200 Storage Router Rack Mounting Guide*, part number ISR653401-00
- *iSR6200 Command Line Interface (CLI) User's Guide*, part number ISR654601-00
- *iSR6200 Router Manager User's Guide*, part number ISR654602-00
- *Internet Protocol, Version 6 (IPv6) Specification*, RFC2460
- *Neighbor Discovery for IP Version 6 (IPv6)*, RFC2461
- *IPv6 Stateless Address Autoconfiguration*, RFC2462
- *Internet Control Message Protocol (ICMPv6) for the Internet Protocol Version 6 (IPv6) Specification*, RFC2463
- *Transmission of IPv6 Packets over Ethernet Networks*, RFC2464
- *iSCSI draft standard deaft-ietf-ips-iSCSI-20*

- 
- *Internet engineering task force (IETF): iSCSI Requirements and Design Considerations, iSCSI Naming and Discovery, Internet Protocol Specification (IPv4), RFC793*
  - *Transmission Control Protocol (TCP) Specification, RFC1122, Requirements for Internet Hosts-Communication Layers*
  - *TCP Extensions for High Performance, RFC1323*
  - *TCP Congestion Control, RFC2581*
  - *ANSI SCSI: SCSI-3 Architecture Model (SAM), X3T10/994D/Rev 18, SCSI-3 Controller Command Set, X3T10/Project 1047D/Rev 6c. IEEE: 802.1Q Virtual LAN (VLAN), 802.1p Priority of Service, 802.3x Flow Control, 802.3ad Link Aggregation*
  - *SCSI-3 Fibre Channel Protocol (SCSI-FCP), X3.269:1996*
  - *Fibre Channel Physical and Signaling Interface (FC-PH), X3.230:1994*
  - *Fibre Channel 2nd Generation (FC-PH-2), X3.297:1997*
  - *Third Generation Fibre Channel Physical and Signaling Interface (FC-PH-3), X3.303:1998*
  - *Fibre Channel-Arbitrated Loop (FC-AL-2), working draft, revision 6.4, August 28, 1998*
  - *Fibre Channel Fabric Loop Attachment Technical Report (FC-FLA) NCITS/TR-20:1998, Fibre Channel-Private Loop Direct Attach Technical Report (FC-PLDA)*
  - *SCSI Fibre Channel Protocol-2 (FCP-2) working draft, revision 3, October 1, 1999*
  - *ANSI Information Technology-SCSI 3 Architecture Model, revision 18, November 27, 1995*

For information about downloading documentation from the QLogic Web site, see [“Downloading Updates” on page xix](#).

## Documentation Conventions

This guide uses the following documentation conventions:

- **NOTE** provides additional information.
- **CAUTION** without an alert symbol indicates the presence of a hazard that could cause damage to equipment or loss of data.

- 
- **⚠ CAUTION** with an alert symbol indicates the presence of a hazard that could cause minor or moderate injury.
  - **⚠ WARNING** indicates the presence of a hazard that could cause serious injury or death.
  - Text in **blue** font indicates a hyperlink (jump) to a figure, table, or section in this guide. Links to Web sites are shown in underlined blue. For example:
    - ❑ [Table 9-2](#) lists problems related to the user interface and remote agent.
    - ❑ See “[Installation Checklist](#)” on page 3-6.
    - ❑ For more information, visit [www.qlogic.com](http://www.qlogic.com).
  - Text in **bold** font indicates user interface elements such as a menu items, buttons, check boxes, or column headings. For example:
    - ❑ Click the **Start** button, point to **Programs**, point to **Accessories**, and then click **Command Prompt**.
    - ❑ Under **Notification Options**, select the **Warning Alarms** check box.
  - Text in `Courier` font indicates a file name, directory path, or command line text. For example:
    - ❑ To return to the root directory from anywhere in the file structure:  
Type `cd /root` and press ENTER.
    - ❑ Enter the following command: `sh /install.bin`
  - Key names and key strokes are indicated with UPPERCASE:
    - ❑ Press CTRL+P.
    - ❑ Press the UP ARROW key.
  - Text in *italics* indicates terms, emphasis, variables, or document titles. For example:
    - ❑ For a complete listing of license agreements, refer to the *QLogic Software End User License Agreement*.
    - ❑ What are *shortcut keys*?
    - ❑ To enter the date, type *mm/dd/yyyy* (where *mm* is the month, *dd* is the day, and *yyyy* is the year).
  - Topic titles between quotation marks identify either sections within this guide or topics in the online help, which is also referred to as *the help system* throughout this document.

---

## Communications Statements

The following statements apply to this product. The statements for other products intended for use with this product appear in their accompanying manuals.

### **Federal Communications Commission (FCC) Class A Statement**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause unacceptable interference, in which case the user will be required to correct the interference at their own expense.

Neither the provider nor the manufacturer is responsible for any radio or television interference caused by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause unwanted operation.

### **Canadian Department of Communications Class A Compliance Statement**

This equipment does not exceed Class A limits for radio emissions for digital apparatus, set out in Radio Interference Regulation of the Canadian Department of Communications. Operation in a residential area may cause unacceptable interference to radio and TV reception requiring the owner or operator to take whatever steps necessary to correct the interference.

### **Avis de conformité aux normes du ministère des Communications du Canada**

Cet équipement ne dépasse pas les limites de Classe A d'émission de bruits radioélectriques par les appareils numériques, telles que prescrites par le Règlement sur le brouillage radioélectrique établi par le ministère des Communications du Canada. L'exploitation faite en milieu résidentiel peut entraîner le brouillage des réceptions radio et télé, ce qui obligerait le propriétaire ou l'opérateur à prendre les dispositions nécessaires pour en éliminer les causes.

---

## CE Statement

The CE symbol on the equipment indicates that this system complies with the EMC (Electromagnetic Compatibility) directive of the European Community (89/336/EEC) and to the Low Voltage (Safety) Directive (73/23/EEC). Such marking indicates that this system meets or exceeds the following technical standards:

- EN60950-1: *Safety of Information Technology Equipment, Including Electrical Business Equipment*
- EN 55022: *Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Equipment*
- EN 55024: *Electromagnetic compatibility—Generic immunity standard Part 1: Residential commercial, and light industry*
  - ❑ EN 61000-4-2: *Electrostatic Discharge Immunity Test*
  - ❑ EN 61000-4-3: *Radiated, Radio-Frequency, Electromagnetic Field Immunity Test*
  - ❑ EN 61000-4-4: *Electrical Fast Transient/Burst Immunity Test*
  - ❑ EN 61000-4-5: *Surge Immunity Test*
  - ❑ EN 61000-4-6: *Immunity To Conducted Disturbances, Induced By Radio-Frequency Fields*
  - ❑ EN 61000-4-8: *Power Frequency Magnetic Field Immunity Test*
  - ❑ EN 61000-4-11: *Voltage Dips, Short Interruptions And Voltage Variations Immunity Tests*
- EN 61000-3-2: *Limits For Harmonic Current Emissions (Equipment Input Current Less Than/Equal To 16 A Per Phase) Class A*
- EN 61000-3-3: *Limitation Of Voltage Fluctuations And Flicker In Low-Voltage Supply Systems For Equipment With Rated Current Less Than Or Equal To 16 A*



---

## VCCI Class A Statement

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。 VCCI-A

This is a Class A product based on the standard of the Voluntary Control Council for Interference (VCCI). If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.

## BSMI Class A Statement


### 警告使用者:

這是甲類的資訊產品。在居住的環境中使用時，可能會造成射頻干擾。在這種情況下，使用者會被要求採取某些適當的對策。

This is a Class A product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take adequate measures.

## Laser Safety Information

This product may use Class 1 laser optical transceivers to communicate over the fiber optic conductors. The U.S. Department of Health and Human Services (DHHS) does not consider Class 1 lasers to be hazardous. The International Electrotechnical Commission (IEC) 825 Laser Safety Standard requires labeling in English, German, Finnish, and French stating that the product uses Class 1 lasers. Because it is impractical to label the transceivers, the following label is provided in this manual.



CLASS 1 LASER PRODUCT  
LASER KLASSE 1  
LUOKAN 1 LASERLAITE  
APPAREIL A LASER DE CLASSE 1  
TO IEC 825 (1984) + CENELEC HD 482 S1

---

## Electrostatic Discharge Sensitivity (ESDS) Precautions

The assemblies used in the router chassis are electrostatic discharge sensitive. Observe ESDS handling procedures when handling any assembly used in the switch chassis.

## China Compulsory Certification (CCC) Warnings



For safety, use this device only at altitudes below 2000m.

为了安全，请只在海拔 2000 米以下使用此装置。



For safety, use this device only in nontropical regions.

为了安全，请只在非热带地区使用此装置。

## Accessible Parts

The the iSR6200 router supports the following FRUs:

- iSR6200 chassis blades
- PCMs
- SFP optical transceivers

## License Agreements

Refer to the *QLogic Software End User License Agreement* for a complete list of all license agreements affecting this product.

---

## Technical Support

Customers should contact their authorized maintenance provider for technical support of their QLogic products. QLogic-direct customers may contact QLogic Technical Support; others will be redirected to their authorized maintenance provider. Visit the QLogic support Web site listed in [Contact Information](#) for the latest firmware and software updates.

For details about available service plans, or for information about renewing and extending your service, visit the Service Program Web page at <http://www.qlogic.com/Support/Pages/ServicePrograms.aspx>.

## Downloading Updates

The QLogic Web site provides periodic updates to product firmware, software, and documentation.

### To download firmware, software, and documentation:

1. Go to the QLogic Downloads and Documentation page:  
<http://driverdownloads.qlogic.com>.
2. Under QLogic Products, type the QLogic model name in the search box.
3. In the search results list, locate and select the firmware, software, or documentation for your product.
4. View the product details Web page to ensure that you have the correct firmware, software, or documentation. For additional information, click the **Read Me** and **Release Notes** icons under Support Files.
5. Click **Download Now**.
6. Save the file to your computer.
7. If you have downloaded firmware, software, drivers, or boot code, follow the installation instructions in the *Readme* file.

Instead of typing a model name in the search box, you can perform a guided search as follows:

1. Click the product type tab: **Adapters**, **Switches**, **Routers**, or **ASICs**.
2. Click the corresponding button to search by model or operating system.
3. Click an item in each selection column to define the search, and then click **Go**.
4. Locate the firmware, software, or document you need, and then click the icon to download or open the item.

---

## Training

QLogic Global Training maintains a Web site at [www.qlogictraining.com](http://www.qlogictraining.com) offering online and instructor-led training for all QLogic products. In addition, sales and technical professionals may obtain Associate and Specialist-level certifications to qualify for additional benefits from QLogic.

## Contact Information

QLogic Technical Support for products under warranty is available during local standard working hours excluding QLogic Observed Holidays. For customers with extended service, consult your plan for available hours. For Support phone numbers, see the Contact Support link at [support.qlogic.com](http://support.qlogic.com).

### Support Headquarters

QLogic Corporation  
4601 Dean Lakes Blvd.  
Shakopee, MN 55379 USA

### QLogic Web Site

[www.qlogic.com](http://www.qlogic.com)

### Technical Support Web Site

<http://support.qlogic.com>

### Technical Support E-mail

[support@qlogic.com](mailto:support@qlogic.com)

### Technical Training E-mail

[training@qlogic.com](mailto:training@qlogic.com)

## Knowledge Database

The QLogic knowledge database is an extensive collection of QLogic product information that you can search for specific solutions. QLogic is constantly adding to the collection of information in the database to provide answers to your most urgent questions. Access the database from the QLogic Support Center: <http://support.qlogic.com>.

# 1 Introduction

This chapter illustrates and describes QLogic's iSR6200 intelligent Storage Router (iSR), including the components contained within the iSR6200 router chassis: router blades, chassis mid-plane, and PCMs.

The following sections describe the features and capabilities of the iSR6200 router:

- [“Router Capabilities and Features” on page 1-1](#)
- [“Licensed Features” on page 1-2](#)
- [“Remote SAN Island Connectivity” on page 1-2](#)
- [“iSR6200 Router Chassis” on page 1-3](#)
- [“Power and Cooling Module \(PCM\)” on page 1-5](#)
- [“iSR6200 Router Blades” on page 1-6](#)

## Router Capabilities and Features

The iSR6200 router is designed to provide:

- Storage consolidation on Fibre Channel arrays by providing iSCSI server connectivity for Fibre Channel arrays.
- Solution for distance replication and backup by providing SAN over WAN connectivity.

The iSR6200 router provides the following features:

- Cost-effective connectivity
- Scalability, reliability, and interoperability
- Ease of use
- Rack real estate
- PCM
- HA configurations
- OEM multipath software

## Licensed Features

The iSR6200 router has features that are available by a license key.


### Data Migration

The iSR6200 router provides data migration as an optional, licensed feature.

The iSR6200-based data migration feature is block-based and independent of a SAN, server, storage protocol (Fibre Channel and iSCSI), and storage vendor. Because application downtime during data migration is always critical, iSR6200 data migration supports both online (local and remote) and offline data migration across Fibre Channel and iSCSI storage arrays. Even offline data migration using the iSR6200 is designed to minimize application downtime by allowing you to configure all migration related tasks while the application remains online, and to migrate the data at a very high speed while the application is offline. This feature is designed such that any person with knowledge of SAN or SAN storage administration can migrate data.

### Remote SAN Island Connectivity

The iSR6200 router supports inter-connecting remote SAN islands, as shown in [Figure 1-1](#).



**Figure 1-1. Remote SAN Island Connectivity**

This configuration has the following additional requirements:

- At least one Fibre Channel port of iSR6200 connected to Fibre Channel SAN.
- Accessibility between the GbE ports on the router, port IP addresses of the remote router, and GbE port IP addresses of the local routers.
- Accessibility between the remote iSR6200 management port IP address and local iSR6200 management port IP address.

When connecting SANs over long distances, you must determine the round-trip latencies between two router connections. You can discover these round-trip latencies using the `ping` command in the CLI. (See the *iSR6200 Command Line Interface (CLI) User's Guide*.)

Using this round-trip latency number, you can determine the window scaling factor for GbE port, as described in [“Performance Tuning” on page 2-4](#). By default, window scaling is set to 1 (64K) TCP window size.

**To map remote Fibre Channel devices to a local SAN:**

1. If the remote router is not already associated with a local router, associate the two routers with each other using one of these user interfaces:
  - ☐ The Add Remote Router wizard (see the *iSR6200 Router Manager User's Guide*).
  - ☐ The CLI command `remoteppeer add` (see the *iSR6200 Command Line Interface (CLI) User's Guide*).
2. Create the initiator to target mapping using one of these methods:
  - ☐ The Map Remote Initiator/Target wizard (see the *iSR6200 Router Manager User's Guide*).
  - ☐ The CLI `remotemap add` command (see the *iSR6200 Command Line Interface (CLI) User's Guide*).

## iSR6200 Router Chassis

The iSR6200 router chassis includes the following hardware components:


- Full-wide, 1U, rack mount
- Two bays for hot-replaceable ISR blades
- Two bays for hot-replaceable PCMs
- One mid-plane with two × EEPROMs
- Dual 275-watt power supplies

The iSR6200 router chassis contains one or two router blades, along with a PCM for each blade. [Figure 1-2](#) illustrates an iSR6200 chassis with two router blades installed.



**Figure 1-2. iSR6200 Router**

[Figure 1-3](#) shows the front and back plates on an iSR6200 router chassis that contains two iSR6200 blades with optional ports installed in the options panel.




**Figure 1-3. iSR6200 Router Chassis—Front and Back Plates**




## Power and Cooling Module (PCM)

Each iSR6200 chassis blade has a PCM located on the backside of the chassis, as shown in [Figure 1-4](#).



**Figure 1-4. PCM—Back Plate**

Each PCM consists of one power supply, three fans, and one external status light emitting diode (LED), as shown in [Figure 1-5](#).



**Figure 1-5. PCM—Front**

Each blade is capable of simultaneously driving all six fans in both PCMs. Generally, only one blade controls both fans, running them at a normal speed. However, if the system detects a higher-than-expected temperature on either side of the blade, it forces the fans to run at full speed. After the temperature is back to normal, the fans resume running at their normal speed.

[Table 1-1](#) shows the internal temperature limits set to trigger events or server message block (SMB) alerts.

**Table 1-1. Internal Temperature Sensor Limits**

Sensor	High Fan Speed Temperature	Low Fan Speed Recovery Temperature	Critical Temperature (power off)	SMB_Alert Recovery Temperature
Front	60°C	55°C	70°C	55°C
Rear	45°C	40°C	55°C	45°C
CPU1	60°C	55°C	68°C	55°C
CPU2	60°C	55°C	68°C	55°C

The following describes the fan speed and temperature parameters listed in [Table 1-1](#).

- **High Fan Speed Temperature**—When a sensor detects a temperature that exceeds this value, the fans run at their maximum RPM speed. The system logs the event and the system fault LED blinks five times every two seconds.
- **Low Fan Speed Recovery Temperature**—When the fans are running at their maximum RPM and all sensors report values less than this value, the fan speed resets to normal.
- **Critical Temperature**—When a sensor detects a temperature that exceeds this value, the system powers down the blade. When this happens, the CPUs enter sleep state 5. The system sets the peripheral component interface (PCI) power state of capable devices to D3, and then turns off the power supplies not essential to wake up the CPUs. When the temperature goes below the **Recovery Temperature** value, the sensor that reported the over-temperature value generates an SMB\_ALERT.
- **Recovery Temperature**—Value at which a sensor generates an SMB\_ALERT to wake up the CPU and cause the blade to reboot.

## iSR6200 Router Blades

Each chassis supports one or two hot-pluggable blades. The base configuration of an iSR6200 router blade has a dual-core CPU, 1,024MB memory, boot Flash, and internal and external I/O ports. (For detailed specifications, see [Appendix A](#).)

The following sections illustrate and describe the physical features and functionality of the iSR6200 router blades:

- [“iSR6200 Router Family Models” on page 1-7](#)
- [“Router Blade LEDs” on page 1-9](#)
- [“Maintenance Button” on page 1-11](#)
- [“Fibre Channel Port LEDs” on page 1-13](#)
- [“Fibre Channel Transceivers” on page 1-14](#)
- [“Gigabit Ethernet Port LEDs” on page 1-15](#)
- [“Ethernet Port—Management” on page 1-15](#)
- [“Serial Port” on page 1-16](#)

## iSR6200 Router Family Models


The iSR6200 family includes router models distinguished by their expansion ports, located in the top-center area of each router blade. The following sections identify the add-on ports on the different iSR6200 router models:

- [“iSR6260 Router Blade” on page 1-7](#)
- [“iSR6250 Router Blade” on page 1-8](#)
- [“iSR6240 Router Blade” on page 1-9](#)

### iSR6260 Router Blade

The iSR6260 router blade adds two more Fibre Channel ports to the blade configuration, as shown in [Figure 1-6](#). Each port has the following capacity:

- Auto-negotiating transmission rates of 2, 4, or 8Gb
- Hot-pluggable SFP Fibre Channel connector
- N\_Port, NL\_Port, or transparent port type



**Figure 1-6. Fibre Channel Ports on the iSR6260 Router Blade**

## iSR6250 Router Blade

The iSR6250 router blade adds two 10Gb Ethernet (GbE) ports to the blade configuration, as shown in [Figure 1-7](#). Each port has the following capacity:

- 10GbE iSCSI ports that run in full duplex mode
- Support for jumbo frames
- IPv4 and IPv6 protocol support
- iSCSI header and data digest in the software



**Figure 1-7. 10GbE Ports on the iSR6250 Router Blade**

[Table 1-2](#) describes the 10GbE Port LED scheme.

**Table 1-2. 10GbE Port LED Scheme**

Green LED (SAN Traffic <sup>a</sup> )	Green LED (LAN Traffic)	Activity
Off	Off	Power off
Slow flashing (in unison)	Slow flashing (in unison)	Power on (no link)
On	On	Link established, no activity
On	Flashing	Link established, transmit and receive LAN only activity
Flashing	On	Link established, transmit and receive SAN only activity
Flashing	Flashing	Link established, transmit and receive LAN and SAN activity
Slow flashing (alternating)	Slow flashing (alternating)	Beaconing

<sup>a</sup> SAN traffic refers to FCoE traffic.

## iSR6240 Router Blade

The iSR6240 router blade adds two iSCSI Ethernet ports to the blade configuration, as shown in [Figure 1-8](#). Each port has the following capacity:


- Auto negotiating transmission rates of 100Mbps and 1000Mbps
- Full duplex transmission mode
- Support for jumbo frames (at 1000Mbps only)
- RJ45 copper Ethernet connector type
- iSCSI header and data digest in the hardware
- IPv4 and IPv6 protocol support
- iSCSI offload



**Figure 1-8. iSCSI (GE) Ports on the iSR6240 Router Blade**

## Router Blade LEDs

Each chassis blade provides LEDs and connectors that face the front of the chassis and may also provide expansion ports, depending on its model. The router blade LEDs shown in [Figure 1-9](#) provide information about the router's operational status. These LEDs include the heartbeat LED, the system fault LED, and the input power LED. The blade also includes a recessed beacon indicator used to locate the physical blade monitored using SANsurfer Router Manager.



**Figure 1-9. Router Blade LEDs**

### Heartbeat LED (Green)

The heartbeat LED blinks once per second as long as the router firmware is operational.

### System Fault LED (Amber)

The system fault LED lights up to show that a fault exists in the router firmware or hardware. Fault conditions include power on self-test (POST) errors and over-temperature conditions. The LED shows a blink code for POST errors and the over-temperature condition. See [Figure 1-9](#) and [Table 1-3](#).

**Table 1-3. System Fault LED Blink Patterns**

System Fault LED	Condition
OFF	OK (operational)
1 Blink	Beacon; synchronized with the heartbeat LED
3 Blinks	System error
4 Blinks	Management port IP address conflict
5 Blinks	Over-temperature

### Input Power LED (Green)


The power LED shows the voltage status of the router logic circuit board. During normal operation, this LED lights up to show that the router logic circuit board is receiving the DC voltage from the power supply.

### Beacon Indicator (Blue)

The iSR6200 router blade's printed circuit board (PCB) has a blue beacon light installed near the center vent hole between the Fibre Channel ports ([Figure 1-9](#)). This light enables you to locate the physical blade when monitoring the iSR6200 routers using SANsurfer Router Manager. If you enable the **Beacon On** option for a selected blade in SANsurfer Router Manager, the blue beacon light flashes through the vent hole on the chassis blade's faceplate.

## Maintenance Button

The maintenance button shown in [Figure 1-10](#) is the only router blade control. Press this button to reset the router blade or to recover it if it becomes disabled.



**Figure 1-10. Router Blade Controls**

The maintenance button is a multifunction momentary switch on the front panel. It has the following functions:

- [“Reset a Router Blade” on page 1-11](#)
- [“Reset and Select Boot Image” on page 1-12](#)
- [“Reset IP Address” on page 1-12](#)
- [“Enable DHCP” on page 1-12](#)
- [“Restore Factory Defaults” on page 1-12](#)

### Reset a Router Blade

To reset the router blade, use a pointed, nonmetallic tool to momentarily press and release (less than two seconds) the maintenance button. The router responds as follows:

1. All the router blade LEDs light up.
2. After about two seconds, the POST begins, turning off the heartbeat and system fault LEDs.
3. When the POST is complete, the power LED is on and the heartbeat LED flashes once per second.

## Reset and Select Boot Image

You can reset the router using either the primary or secondary boot image:

- **Primary Image**—To reset the router and select the primary boot image, use a pointed, nonmetallic tool to press and hold the maintenance button until the heartbeat LED flashes once, and then release the button. The router boots from the primary boot image. The boot time is less than one minute.
- **Secondary Image**—To reset the router and select the secondary boot image, use a pointed, nonmetallic tool to press and hold the maintenance button until the heartbeat LED flashes twice, and then release the button. The heartbeat LED flashes twice. The router boots from secondary boot image. The boot time is less than one minute.

## Reset IP Address

To reset the router and restore the maintenance port IP address to the default (10.0.0.1), use a pointed, nonmetallic tool to press and hold the maintenance button until the heartbeat LED flashes six times, and then release the button. The router boots and sets the maintenance port to IP address 10.0.0.1. The boot time is less than one minute.

The IP address set by this method is not persistent; to make the change persistent, use the CLI or SANSurfer Router Manager to set the IP address. For more information, see the *iSR6200 Router Manager User's Guide* and the *iSR6200 Command Line Interface (CLI) User's Guide*.

## Enable DHCP

To reset the router and configure the maintenance port to use dynamic host configuration protocol (DHCP) to acquire its IP address, use a pointed, nonmetallic tool to press and hold the maintenance button until the heartbeat LED flashes seven times, and then release the button. The router boots and configures the maintenance port for DHCP. The boot time is less than one minute.

Enabling DHCP by this method is not persistent; to make the change persistent, use the CLI or SANSurfer Router Manager to enable DHCP. For details, see the *iSR6200 Router Manager User's Guide* and the *iSR6200 Command Line Interface (CLI) User's Guide*.

## Restore Factory Defaults

To reset the router and restore it to the factory default configuration, use a pointed, nonmetallic tool to press the maintenance button and hold it until the heartbeat LED flashes 20 times, and then release the button. The router boots and is restored to the factory defaults. The boot time is less than one minute.

The router does the following when restored to the factory defaults:

- Clears all router log entries
- Resets all passwords



- Resets the maintenance port IP address to 10.0.0.1
- Disables the iSCSI ports and sets the IP address to 0.0.0.0
- Erases all presentations
- Erases all discovered initiators and targets

## Fibre Channel Port LEDs

The iSR6200 router has two Fibre Channel ports. The ports are labeled *FC1* and *FC2*, as shown in [Figure 1-11](#).



**Figure 1-11. Fibre Channel LEDs**

The port LEDs are located to the right of their respective ports and provide status and activity information.

Each port has three LEDs:

- The amber (top) LED shows activity for data passing through the port at 2Gbps speed.
- The green LED (middle) shows activity for data passing through the port at 4Gbps speed.
- The yellow LED (bottom) shows activity for data passing through the port at 8Gbps speed.

[Table 1-4](#) describes the port LED blink patterns and their meanings.

**Table 1-4. Port LEDs**

Activity	Yellow LED (8Gbps)	Green LED (4Gbps)	Amber LED (2Gbps)
Power OFF	OFF	OFF	OFF
Power ON (before firmware initialization)	ON	ON	ON
Power ON (after firmware initialization)	Flashing	Flashing	Flashing

**Table 1-4. Port LEDs (Continued)**

Activity	Yellow LED (8Gbps)	Green LED (4Gbps)	Amber LED (2Gbps)
Firmware initialization error <sup>a</sup>	Alternate flashing	Alternate flashing	Alternate flashing
Online, 2Gbps link—I/O activity	OFF	OFF	ON and flashing
Online, 4Gbps link—I/O activity	OFF	ON and flashing	OFF
Online, 8Gbps link—I/O activity	ON and flashing	OFF	OFF
Beacon	Flashing	OFF	Flashing

<sup>a</sup> Yellow, green, and amber LEDs flash alternatively to indicate firmware initialization errors.

## Fibre Channel Transceivers


Each port is served by an SFP optical transceiver and is capable of 2, 4, or 8Gbps transmission. SFPs are hot-pluggable. User ports can self-discover both the port type and transmission speed when connected to public devices or switches.

The iSR6200 router supports SFP optical transceivers for the Fibre Channel ports. A transceiver converts electrical signals to and from optical laser signals to transmit and receive data. Duplex fiber optic cables plug into the transceivers, which then connect to the devices. For example, a 2Gbps or 4Gbps Fibre Channel port can transmit at 2Gbps or 4Gbps; however, the transceiver must also be capable of delivering these rates.

The SFP transceivers are hot pluggable. You can remove or install a transceiver while the router is operating without harming the router or the transceiver. However, this interrupts communication with the connected device. For details about installing and removing SFP optical transceivers, see [“Installing the Transceivers” on page 3-6](#).

## Gigabit Ethernet Port LEDs

The gigabit Ethernet (GbE) ports shown in [Figure 1-12](#) are RJ45 connectors that provide connection to an Ethernet SAN through a 100 or 1000 Base-T Ethernet cable. The ports are labeled *GE1* and *GE2*. Each of these ports supports connections that run the iSCSI high-level TCP protocol.




**Figure 1-12. Gigabit Ethernet Ports**

GbE ports each have two LEDs:

- The activity LED (green) lights up when the port transmits or receives data over the Ethernet connection.
- The link status LED (green) lights up continuously when the port establishes an Ethernet connection.

## Ethernet Port—Management

The management Ethernet port shown in [Figure 1-13](#) is an RJ45 connector that provides a connection to a management workstation through a 10 or 100 Base-T Ethernet cable. The port is labeled *MGMT*.



**Figure 1-13. Ethernet Management Port**


A management workstation can be a Windows®, Solaris®, or a Linux® workstation that configures and manages the router. You can manage the router over an Ethernet connection using either SANSurfer Router Manager, the CLI, or SNMP.

The management Ethernet port has two LEDs:

- The link status LED (green) lights up continuously when the port establishes an Ethernet connection.
- The activity LED (green) lights up when the port transmits or receives data over the Ethernet connection.

## Serial Port

The iSR6200 router is equipped with an RS-232 serial port for maintenance purposes. [Figure 1-14](#) shows the serial port location, which is labeled *IOIOI*. You can manage the router through the serial port using the CLI.



**Figure 1-14. Serial Port**

The serial port connection requires a standard eight-wire Ethernet cable and the supplied dongle to convert the Ethernet RJ45 connector to a female DB9 connector.

# 2 Planning

This chapter describes how to plan for the iSR6200 router. The following sections describe the devices and services you need to consider when planning to use the iSR6200 router:

- [Devices](#)
- [“Device Access” on page 2-2](#)
- [“Fibre Channel Switches Required for VPGroups” on page 2-2](#)
- [“Fibre Channel Performance” on page 2-2](#)
- [“iSCSI Performance” on page 2-3](#)
- [“Performance Tuning” on page 2-4](#)
- [“Topology” on page 2-7](#)
- [“High Availability” on page 2-7](#)
- [“Management” on page 2-7](#)
- [“Recovery” on page 2-8](#)
- [“Services” on page 2-8](#)
- [“Security” on page 2-9](#)

## Devices

When planning router use, consider the number of devices and the anticipated demand. This determines the number of ports required and, in turn, the number of routers.

The router uses SFP transceivers in the 8Gbps Fibre Channel (FC) ports, but some Fibre Channel devices may not use the same transceivers. Consider whether the Fibre Channel device you want to connect the router to uses SFP or gigabit interface converters (GBIC) transceivers, and choose fibre optic cables accordingly. Use LC-type cable connectors for SFP transceivers and SC-type cable connectors for GBIC transceivers. Also consider the transmission speed compatibility of your devices, adapters, switches, and SFPs.

## Device Access

Consider device access needs within the Fibre Channel and iSCSI SANs. Controlling access to Fibre Channel device LUNs requires mapping Fibre Channel device LUNs to specific iSCSI initiators. You may map LUNs to more than one initiator. Giving multiple initiators access to a LUN requires access management.

### Fibre Channel

The Fibre Channel ports automatically discover all Fibre Channel target devices, whether connected directly (loop) or by fabric (switch).

### iSCSI

The iSCSI ports automatically present targets discovered on the Fibre Channel ports. If the Fibre Channel target's LUN 0 is a controller LUN, it becomes accessible (mapped) to all iSCSI initiators. All data LUNs are inaccessible until mapped. The exception is if LUN 0 is a controller LUN, it is mapped automatically to allow for management of the Fibre Channel target controller.

When an iSCSI initiator logs on, the router records the initiator's iSCSI name and IP address. The management interface—CLI and SANsurfer Router Manager—uses the initiator information to simplify the mapping process.

## Fibre Channel Switches Required for VPGroups

iSR6200 uses QLogic Host Bus Adapter technology and is compatible with all Fibre Channel switches from Brocade, Cisco, McData, and QLogic. If you want to use more than one VPGroup, you must use Fibre Channel switches.

## Fibre Channel Performance

The iSR6200 router supports Fibre Channel service at transmission rates of 2, 4, or 8 Gbps with a maximum frame size of 2,148 bytes. Related performance characteristics include the following:

- [Distance](#)
- [Bandwidth](#)
- [Latency](#)

### Distance

Consider the physical distance between Fibre Channel devices. Choose SFP transceivers that are compatible with the cable type and distance.

Each Fibre Channel port is supported by a data buffer with a three-credit capacity; that is, three maximum-sized frames. For fibre optic cables, this enables full bandwidth over approximately 2.5 kilometers at 2Gbps (1.2 credits/Km).

Beyond these distances, however, the connection loses some efficiency because the transmitting port must wait for an acknowledgement before sending the next frame.

## Bandwidth

Bandwidth is a measure of the volume of data that can be transmitted at a specific transmission rate. A 2Gbps Fibre Channel port can transmit or receive at nominal rates of 2Gbps, depending on the device to which it is connected. This corresponds to actual bandwidth value of 212MB.

## Latency

Latency is a measure of how fast a transaction travels through the router.

# iSCSI Performance

The iSR6200 router supports Ethernet service at transmission rates of 1000Mbps, 100Mbps, or 10Mbps with an MTU size of 1500 or 9000 (jumbo frames).

---

### NOTE

An MTU size greater than 1500 should only be used when the router is connected to a 1000Mbps Ethernet network.

---

Related performance characteristics include the following:

- [Distance](#)
- [Bandwidth](#)
- [Latency](#)

## Distance

Consider the physical distance between routers. This is usually measured in round-trip delay. Round-trip delays range anywhere from less than 1 millisecond to as great as 250 milliseconds.

## Bandwidth

Bandwidth is a measure of the volume of data that can be transmitted at a specific transmission rate. WAN data rates range from 1.5 megabits per second (T1) to greater than 600 megabits per second (OC-12).

## Latency

Latency is a measure of how fast a transaction travels through the router and LAN or WAN.

## Performance Tuning

Proper configuration maximizes the router's performance. Knowing the round-trip delay (distance between the router and iSCSI initiators) and WAN effective data rate (connection type) allows you to tune the router for optimal performance. The following tables provide **TCP Window Size** settings for specific WAN environments. The **TCP Window Size** is configured as two parameters: **Window Size** and **Scaling Factor**. See the *iSR6200 Router Manager User's Guide* and the *iSR6200 Command Line Interface (CLI) User's Guide* for configuring the TCP window size.

**Table 2-1. T1—1.554Mbps**

Round-Trip Delay (ms)	TCP Window Size (kBytes)
≤ 41.5	8
≤ 82.9	16
≤ 165.8	32
≤ 331.6	64
≤ 663.2	128
≤ 1326.5	256
≤ 2652.9	512



**Table 2-2. T3—45Mbps**

Round-Trip Delay (ms)	TCP Window Size (kbytes)
≤ 1.4	8
≤ 2.9	16
≤ 5.7	32
≤ 11.4	64
≤ 22.9	128
≤ 45.8	256
≤ 91.6	512
≤ 183.1	1024
≤ 366.2	2048 <sup>a</sup>
≤ 732.5	4096 <sup>a</sup>

<sup>a</sup> Supported in FC-IP mode only.**Table 2-3. OC-1—51Mbps**

Round-Trip Delay (ms)	TCP Window Size (kbytes)
≤ 1.2	8
≤ 2.5	16
≤ 4.9	32
≤ 9.9	64
≤ 19.8	128
≤ 39.5	256
≤ 79.0	512
≤ 158.0	1024
≤ 316.1	2048 <sup>a</sup>
≤ 632.1	4096 <sup>a</sup>

<sup>a</sup> Supported in FC-IP mode only.

**Table 2-4. OC-3—156Mbps**


Round-Trip Delay (ms)	TCP Window Size (bytes)
≤ 0.4	8
≤ 0.8	16
≤ 1.6	32
≤ 3.3	64
≤ 6.6	128
≤ 13.2	256
≤ 26.3	512
≤ 52.7	1024
≤ 105.4	2048
≤ 210.7	4096

**Table 2-5. OC-12—621Mbps**

Round-Trip Delay (ms)	TCP Window Size (bytes)
≤ 0.1	8
≤ 0.2	16
≤ 0.4	32
≤ 0.8	64
≤ 1.6	128
≤ 3.3	256
≤ 6.6	512
≤ 13.2	1024
≤ 26.3	2048
≤ 52.7	4096

## Topology

The iSR6200 router supports interconnecting remote SANs (see [Figure 2-1](#)).



**Figure 2-1. WAN Topology—Remote SAN Interconnect**

## High Availability

A dual-blade iSR6200 router supports high availability, which provides link-level, switch-level, and blade-level failure protection. To make this effective, you must connect the iSCSI hosts to both iSR6200 blades. For details, see [“Connecting iSCSI Hosts to the iSR6200” on page 4-16](#).

## Management

SANsurfer Router Manager and the CLI run on a management workstation used to configure, control, and maintain the router. Support platforms include Windows, Solaris, and Linux. The SANsurfer Router Manager utility is installed and executed on the workstation.

The router supports the following management interfaces:

- **SANsurfer Router Manager** is a graphical user interface (GUI) utility that runs on a management workstation (see the *iSR6200 Router Manager User's Guide*).
- **CLI** is the command line interface that runs on the router; users can access the CLI by means of Telnet or the serial port (see the *iSR6200 Command Line Interface (CLI) User's Guide*).
- **SNMP** provides router status, traps, and alerts (for details, see [Appendix B](#)).

## Recovery

You should have a process in place to recover from a possible router failure. Consider the following when developing a recovery process for the router:

- Save all firmware image files (updates) in a safe, well-known place, because you may:
  - ☐ Want to revert to a previous firmware version
  - ☐ Need the firmware image when replacing a single-blade router
  - ☐ Need the firmware image when adding a router to your site
- Save the router's configuration (as a new file) after every configuration change, because you may:
  - ☐ Want to revert to a previous configuration
  - ☐ Need to configure a replacement blade in a single-blade router
- Save the router's LUN mappings (as a new file) after every mapping change, because you may:
  - ☐ Want to revert to a previous LUN mapping
  - ☐ Need to LUN-map a replacement blade in a single-blade router
  - ☐ Want to duplicate the LUN mapping on a second router (for redundancy)

---

### NOTE

For more details on recovering a router blade, see [“iSR6200 Chassis Blades” on page 7-1](#).

---

## Services

You can configure your router to suit the demands of your environment using a variety of router services. Familiarize yourself with the following router services and determine which ones you need:

- **Telnet** enables you to manage the router over a Telnet connection.
- **Router management** provides for out-of-band management of the router with SANsurfer Router Manager.
- **SNMP** enables you to monitor the router using third-party applications that use SNMP.
- **Network time protocol (NTP)** enables you to synchronize the router and the workstation dates and times with an NTP server. NTP is disabled (not configured) by default.

- **File transfer protocol (FTP)** enables you to transfer files rapidly between the workstation and router using FTP.
- **Secure SHell (SSH)** provides secure and encrypted connections to traditionally non-encrypted services.

## Security

Passwords provide router security. SANsurfer Router Manager requires a password each time a user logs into the utility. After you are connected, SANsurfer Router Manager prompts for an administrative password before it accepts configuration changes.

The CLI also requires the user to enter a user ID and password to start. The CLI must be in an admin session to perform any set operations. An admin session requires a password.

The default password for both these management utilities is *password* for the default user ID of *guest*. The default administrative password is *config*.

After you have logged on, you can change the password using the utility's security features.



# 3 Installation

This chapter describes how to install and configure an iSR6200 router, including:

- [“Site Requirements” on page 3-1](#)
- [“Installing the iSR6200 Router” on page 3-2](#)
- [“Installing New Firmware” on page 3-17](#)

## Site Requirements

The following sections describe the requirements for installing an iSR6200 router:

- [Management Workstation](#)
- [“Power Requirements” on page 3-2](#)
- [“Environmental Conditions” on page 3-2](#)

## Management Workstation

[Table 3-1](#) lists the requirements for the management workstation running SANsurfer Router Manager.

**Table 3-1. Management Workstation Requirements**

Item	Description
Operating system	One of the following: <ul style="list-style-type: none"><li>■ Windows 2000, 2003</li><li>■ Solaris 8, 9, 10</li><li>■ Linux Red Hat® Enterprise Linux 3.x</li><li>■ SUSE® Linux 9.0 Enterprise</li><li>■ Mac OS® X 10.3</li></ul>
Memory	256MB or more
Disk space	150MB per installation
Processor	500MHz or faster
Hardware	CD-ROM drive, RJ45 Ethernet port, RS-232 serial port (optional)

**Table 3-1. Management Workstation Requirements (Continued)**

Item	Description
Internet browser	One of the following: <ul style="list-style-type: none"><li>■ Microsoft Internet Explorer 5.0 and later</li><li>■ Mozilla® Firefox® 1.02 and later</li><li>■ Java™ 2 runtime environment to support the Web applet</li></ul>

## Power Requirements

The iSR6200 router requires the following power supply:

- 235W maximum, 200W typical
- 100V AC to 240V AC; 50Hz to 60Hz
- 1.9A at 100–125V AC; 1.02A at 200–240V AC

## Environmental Conditions

Consider the factors that affect the climate in your facility, such as equipment heat dissipation and ventilation. The router requires the following operating conditions:

- Operating temperature range: 5–40°C (41–104°F).
- Relative humidity: 15–80 percent, non-condensing.

## Installing the iSR6200 Router

Unpack the router, accessories, and documentation. The iSR6200 router is shipped with the following components:

- iSR6200 router chassis with two blades installed
- DB9 to RJ45 cable adapter
- Power cable (6 foot black)
- Rail Mounting Kit, part number 50990-00
- *WEEE Conformance Card*
- *QLogic Global Services Card*
- *China Optics and Cable SKUs Toxic Substance Table*

### To install the iSR6200 router:

1. Complete the pre-installation checklist (see [page 3-3](#)).
2. Mount the router (see [page 3-5](#)).
3. Install the transceivers (see [page 3-6](#)).
4. Connect the router to AC power (see [page 3-7](#)).



5. Connect the management workstation to the router (see [page 3-10](#)).
6. Configure the management workstation (see [page 3-11](#)).
7. Install the management utility (see [page 3-13](#)).
8. Start the management utility (see [page 3-16](#)).
9. Configure the router (see [page 3-16](#)).
10. Cable devices to the router (Fibre Channel and iSCSI) (see [page 3-17](#)).

## Pre-installation Check List

During the initial configuration process, the system prompts you to enter information for each blade contained in the iSR6200 chassis. Use the space provided in the following tables to record the IP addresses for each blade.

**Table 3-2. Worksheet for Router Blade 1 (left) Parameters**

Symbolic Name of the iSR6200 Blade 1	
Management port IP address, subnet mask, and gateway (if not using DHCP)	
iSCSI port 1 IP address, subnet mask, and gateway (GE-1)	
IP address of the iSNS server for iSCSI port 1 (if iSNS will be enabled)	
iSCSI port 2 IP address, subnet mask, and gateway (GE-2)	
IP address of the iSNS server for iSCSI port 2 (if iSNS will be enabled)	
iSCSI port 3 IP address, subnet mask, and gateway for the optional (FC3, GE-3, or 10GE-3) port	
IP address of the iSNS server for iSCSI port 3 (if iSNS will be enabled)	

**Table 3-2. Worksheet for Router Blade 1 (left) Parameters (Continued)**

iSCSI port 4 IP address, subnet mask, and gateway for the optional (FC4, GE-4, or 10GE-4) port	
IP address of the iSNS server for iSCSI port 4 (if iSNS will be enabled)	

**Table 3-3. Worksheet for Router Blade 2 (right) Parameters**

Symbolic Name of the iSR6200 Blade 2	
Management port IP address, subnet mask, and gateway (if not using DHCP)	
iSCSI port 1 IP address, subnet mask, and gateway (GE-1)	
IP address of the iSNS server for iSCSI port 1 (if iSNS will be enabled)	
iSCSI port 2 IP address, subnet mask, and gateway (GE-2)	
IP address of the iSNS server for iSCSI port 2 (if iSNS will be enabled)	
iSCSI port 3 IP address, subnet mask, and gateway for the optional (FC3, GE-3, or 10GE-3) port	
IP address of the iSNS server for iSCSI port 3 (if iSNS will be enabled)	
iSCSI port 4 IP address, subnet mask, and gateway for the optional (FC4, GE-4, or 10GE-4) port	

**Table 3-3. Worksheet for Router Blade 2 (right) Parameters (Continued)**

IP address of the iSNS server for iSCSI port 4 (if iSNS will be enabled)	
--	--

## Mounting the Router

You can either place the router on a flat surface or mount it in a 19-inch Electronic Industries Alliance (EIA) rack. See the product specification for weight and dimensions. Rack mounting requires a QLogic rack mounting kit; contact QLogic for more information.

### **WARNING**

Mount routers in the rack so that the weight is distributed evenly. An unevenly loaded rack can become unstable, possibly resulting in equipment damage or personal injury.

### **AVERTISSEMENT**

Installer les routeurs dans l'armoire informatique de sorte que le poids soit réparti uniformément. Une armoire informatique déséquilibrée risque d'entraîner des blessures ou d'endommager l'équipement.

### **WARNING**

Bauen Sie die Router so in das Rack ein, dass das Gewicht gleichmäßig verteilt ist. Ein Rack mit ungleichmäßiger Gewichtsverteilung kann schwanken/umfallen und Gerätbeschädigung oder Verletzung verursachen.

### **ADVERTENCIA**

Monte los enrutadores en el estante de modo que el peso se distribuya de manera uniforme. Un estante cuya carga no esté distribuida de manera uniforme puede ser inestable y podría dañar el equipo o causar lesiones personales.

### **警告**

把装置安装在机架中，让重量均匀分布。负载不均匀的机架可能会变得不稳固，甚至导致设备损坏或人身伤害。

---

**CAUTION**

- If the router is mounted in a closed or multi-rack assembly, the operating temperature of the rack environment may be greater than the ambient temperature. Be sure to install the chassis in an environment that is compatible with the maximum rated ambient temperature.
  - Do not restrict chassis air flow. Allow 16cm (6.5 inches) minimum clearance at the front and rear of the router (surface mount) or rack for service access and ventilation.
  - Multiple rack-mounted units connected to the AC supply circuit may overload that circuit or overload the AC supply wiring. Consider the power source capacity and the total power usage of all routers on the circuit.
  - Reliable grounding in the rack must be maintained from the router chassis to the AC power source.
- 

## Installing the Transceivers

The router supports a variety of SFP transceivers.

---

**CAUTION**

Ensure that you insert the 8Gb or 10Gb SFP transceiver into the correct port. These transceiver types are not interchangeable.

---

- To install a transceiver, insert the transceiver into the port, and then gently press until it snaps in place.
  - To remove a transceiver, gently press the transceiver into the port to release tension, pull the release tab or lever, and then remove the transceiver. Different transceiver manufacturers have different release mechanisms. Consult the documentation for your transceiver.
- 

**NOTE**

The transceiver fits only one way. If the transceiver does not install under gentle pressure, flip it over and try again.

---

## Connecting the Router to AC Power

### **WARNING**

This product is supplied with a three-wire power cable and plug for the user's safety. Use this power cable in conjunction with a properly grounded outlet to avoid electrical shock. An electrical outlet that is not correctly wired could place hazardous voltage on metal parts of the router chassis. The customer must make sure the outlet is correctly wired and grounded to prevent electrical shock.

You may require a different power cable in some countries because the plug on the cable supplied with the equipment will not fit your electrical outlet. In this case, you must supply your own power cable. The cable must meet the following requirements:

- For 125 volt electrical service: the cable must be rated at 10 amperes and be approved by UL and CSA.
- For 250 volt electrical service: the cable must be rated at 10 amperes, meet requirements of H05VV-F, and be approved by VDE, SEMKO, and DEMKO.

### **AVERTISSEMENT**

Pour la sécurité de l'utilisateur, l'appareil est livré avec un câble d'alimentation trifilaire et une fiche. Pour éviter toute secousse électrique, enficher ce câble à une prise correctement mise à la terre. Une prise électrique dont les fils sont mal branchés peut créer une tension dangereuse dans les pièces métalliques du châssis routeur. Pour éviter toute secousse électrique, s'assurer que les fils sont correctement branchés et que la prise est bien mise à la terre.

Dans certains pays les prises électriques sont de modèle différent; on ne peut y enficher le câble de l'appareil. On doit donc en utiliser un autre ayant les caractéristiques suivantes:

- Alimentation 125 V: Câble pour courant nominal de 10 A, agréé LAC et CSA.
- Alimentation 250 V: Câble pour courant nominal de 10 A, conforme au H05VV-F, et agréé VDE, SEMKO et DEMKO.

---

### **WARNUNG**

Dieses Produkt wird mit einem 3-adrigen Netzkabel mit Stecker geliefert. Dieses Kabel erfüllt die Sicherheitsanforderungen und sollte an einer vorschriftsmäßigen Schukosteckdose angeschlossen werden, um die Gefahr eines elektrischen Schlages zu vermeiden. Elektrosteckdosen, die nicht richtig verdrahtet sind, können gefährliche Hochspannung an den Metallteilen des router-Gehäuses verursachen. Der Kunde trägt die Verantwortung für eine vorschriftsmäßige Verdrahtung und Erdung der Steckdose zur Vermeidung eines elektrischen Schlages.

In manchen Ländern ist eventuell die Verwendung eines anderen Kabels erforderlich, da der Stecker des mitgelieferten Kabels nicht in die landesüblichen Steckdosen paßt. In diesem Fall müssen Sie sich ein Kabel besorgen, daß die folgenden Anforderungen erfüllt:

- Für 125 Volt-Netze: 10 Ampere Kabel mit UL- und CSA-Zulassung.
- Für 250 Volt-Netze: 10 Ampere Kabel gemäß den Anforderungen der H05VV-F und VDE-, SEMKO- und DEMKO-Zulassung.

### **ADVERTENCIA**

Para garantizar la seguridad del usuario, este producto se suministra con un cable de alimentación de 3 hilos y un enchufe. Utilice este cable de alimentación junto con un enchufe correctamente conectado a tierra para evitar descargas eléctricas. Un enchufe eléctrico que no esté correctamente conectado puede hacer que las piezas metálicas del chasis del enrutador tengan un voltaje peligroso. Es responsabilidad del cliente asegurarse de que el enchufe esté correctamente conectado a una toma de tierra para evitar descargas eléctricas.

Es posible que en algunos países necesite un cable de alimentación diferente porque el enchufe del cable suministrado con el equipo no se ajusta a su enchufe eléctrico. En este caso, debe proveerse de su propio cable de alimentación. El cable que utilice debe cumplir los siguientes requisitos:

- Para un servicio eléctrico de 125 voltios, el cable debe tener una corriente nominal de 10 amperios y estar aprobado por UL y CSA.
- Para un servicio eléctrico de 250 voltios, el cable debe tener una corriente nominal de 10 amperios, cumplir los requisitos de H05VV-F y estar aprobado por VDE, SEMKO y DEMKO.


## 警告

为了用户安全，此产品配备 3 线电源线和插头。使用此电线配合正确接地的插座以防触电。没有正确布线的电源插座可能导致装置框架的金属部件受危险电压的影响。顾客有责任确保插座已正确布线及接地，以避免触电。

在一些国家，此设备配备的电线插头可能不适用于当地的电源插座，因此您将需要不同的电线。在这种情况下，您必须提供您自己的电源线。您使用的电源线必须符合以下要求：

- 如果电力供应是 125 伏，则电线额定电流必须是 10 安培并经 UL 及 CSA 认证。
- 如果电力供应是 250 伏，则电线额定电流必须是 10 安培，符合 H05VV-F 的要求，并经 VDE、SEMKO 和 DEMKO 认证。

Figure 3-1 shows the front and back plates of an iSR6200 router chassis that contains two router blades with add-in ports installed for its model. Each PCM provides a power connector, as well as a Status LED.




**Figure 3-1. iSR6200 Router Chassis—Front and Back Plates**

Refer to Figure 3-1 to locate the power connector and PCM status LED for the blade you are configuring.

### To power on the router:

1. Attach the AC power cord to the power connector, located on the back side of the PCM connected directly behind the router blade.
2. Connect the opposite end of the power cord to a grounded AC wall outlet or power strip.
3. Check the PCM power LED to make sure the fan is operational (green = OK, yellow = no AC power).

Figure 3-2 shows the location of the ports and LEDs on one of the blades contained within the iSR6200 unit that are referenced in the following instructions.



**Figure 3-2. iSR6200 Blade Ports and LEDs**

4. Verify that the router's input power LED is illuminated.  
The iSR6200 router runs its self test and begins normal operation—this may take a minute.
5. Verify that the heartbeat LED is blinking (once per second) and that the system fault LED is not illuminated.

If an error has occurred, the system fault LED blinks a pattern that indicates the fault reason. For more information about error blink patterns, see [page 6-2](#).

## Connecting the Management Workstation to the Router

You can manage the router using either SANsurfer Router Manager or the CLI. SANsurfer Router Manager requires an Ethernet connection to the router. The CLI can use either an Ethernet connection or a serial connection. Choose the router management method, and then connect the management workstation to the router in one of the following ways:

- **Indirect Ethernet connection** from the management workstation to the router RJ45 connector through an Ethernet switch or hub. This requires a 10 or 100 Base-T straight cable.
- **Direct Ethernet connection** from the management workstation to the router RJ45 Ethernet connector. This requires a 10 or 100 Base-T crossover cable.
- **Serial port connection** from the management workstation to the router RS-232 serial port connector. This requires a 10 or 100 Base-T straight cable and a dongle.



## Configuring the Management Workstation

The router comes from the factory with a default IP address (10.0.0.1). Prior to product installation, follow the procedures included in this section based on your configuration method:

- If you plan to configure the router through the management Ethernet port (using either SANSurfer Router Manager or the CLI through Telnet), you must initially configure the workstation as described in [“Setting the Workstation IP Address” on page 3-11](#).
- If you plan to configure the router using the management COM port, configure the workstation as described in [“Configuring the Workstation Serial Port” on page 3-12](#).

### Setting the Workstation IP Address

The IP address of a new router is 10.0.0.1. To ensure that your workstation is configured to communicate with the 10.0.0.0 subnet, refer to the following instructions for your workstation:

- Steps for different versions of Windows vary. For a Windows 2000 workstation, follow these steps:
  - a. On the Windows **Start** menu, point to **Settings**, point to **Control Panel**, and then click **Network and Dial-up Connections**.
  - b. Click **Make New Connection**.
  - c. Click **Connect to a private network through the Internet**, and then click **Next**.
  - d. Enter 10.0.0.253 for the IP address.
- For other versions of Windows, consult the Windows Help files.
- For Linux or Solaris workstation, open a command window and enter the following command, where *<interface>* is your interface name:

```
ifconfig <interface> ipaddress 10.0.0.253 netmask  
255.255.255.0 up
```

## Configuring the Workstation Serial Port

### To configure the workstation serial port:

1. Connect the cable with an RJ45 to DB9F adapter from a COM port on the management workstation to the serial port on the router.
2. Configure the workstation serial port according to your platform. These steps may vary according to the operating system version you use:

#### ☐ For Windows:

- a. Open the HyperTerminal application: On the Windows **Start** menu, click **Programs**, point to **Accessories**, point to **Communications**, and then click **HyperTerminal**.
- b. Enter a name for the router connection, choose an icon in the Connection Description window, and then click **OK**.
- c. In the COM Properties window, type the following **COM Port** settings, and then click **OK**.

**Bits per second**—115200

**Data Bits**—8

**Parity**—None

**Stop Bits**—1

**Flow Control**—None

#### ☐ For Linux:

- a. Set up minicom to use the serial port. Create or modify the `/etc/minirc.dfl` file with the following content:

```
pr portdev/ttyS0
pu minit
pu mreset
pu mhangup
```

Where `pr portdev/ttyS0` specifies port 0 on the workstation. Select the `pr` setting to match the workstation port to which you connected the router.

- b. Verify that all users have permission to run minicom. Review the `/etc/minicom.users` file and confirm that the line `ALL` exists or that there are specific user entries.

❑ **For Solaris:**

- Modify the `/etc/remoted` file to include the following line:

```
\:dv=/dev/term/a:br#115200:el=^C^S^Q^U^D:ie=%$:oe=^D
:
```

Where `/dev/term/a` refers to serial port `a`. Choose the `dv` setting to match the workstation port to which you connected the router.

3. Connect the router to the power (see [page 3-16](#)).


## Installing SANsurfer Router Manager

You can manage the router using SANsurfer Router Manager. The following sections describe how to download this utility from the QLogic Web site and install it on a Windows, Linux, or Mac OS X workstation. For information on how to use SANsurfer Router Manager, see the *iSR6200 Router Manager User's Guide*.

### Downloading the SANsurfer Router Manager Installer

1. Go to the QLogic Downloads and Documentation page located here:  
<http://driverdownloads.qlogic.com>
2. Under **QLogic Products**, click the **Guided Search** link.
3. Complete the Search Support dialog box as follows:
  - a. In the **Select a Product Type** box, click **Routers**.  
The **Select by Model or OS** box defaults to **By Model**.
  - b. In the **Select the Product Technology** box, click **Intelligent Storage Routers**.
  - c. In the **Select the Model** box, click the router model number.
  - d. In the **Select the Desired Item** box, click **Management Tools**.
  - e. Click **Search**.

Figure 3-3 shows an example of the Search Support dialog box in Windows Internet Explorer.




The image shows a web browser window titled "Search Support - Windows Internet Explorer provided by MSN & Bing". The main content area is titled "Enter your search criteria." and contains five dropdown menus for selecting search criteria. The selected values are: "Routers" for "Select a Product Type:", "by Model" for "Select by Model or by OS:", "Intelligent Storage Routers" for "Select the Product Technology:", "iSR6260" for "Select the Model:", and "Management Tools" for "Select the Desired Item:". A "Search" button is located below the dropdown menus.

Field	Selected Value
Select a Product Type:	Routers
Select by Model or by OS:	by Model
Select the Product Technology:	Intelligent Storage Routers
Select the Model:	iSR6260
Select the Desired Item:	Management Tools

**Figure 3-3. Search Support Dialog Box (Example)**

The Downloads page lists the search results; Figure 3-4 shows an example.



The image shows a "Downloads" page with a search bar containing the text "intelligent storage routers isr6260 management tools". Below the search bar is a table with four columns: "Product", "Operating System", "Category", and "Resource Name". The table lists four search results for the iSR6260 router, all categorized as "Management Tools".

Product	Operating System	Category	Resource Name
iSR6260	-	Management Tools	SANsurfer Router Manager for Windows V-3.3.0 build 6
iSR6260	-	Management Tools	SANsurfer Router Manager for Mac OS V-3.2.0 build 4
iSR6260	-	Management Tools	iSR6200 Router SNMP MIB V-201002230000Z, February 2010
iSR6260	-	Management Tools	SANsurfer Router Manager for Linux V-3.3.0 build 6

**Figure 3-4. Guided Search Results**

4. Under **Resource Name**, click the **SANsurfer Router Manager for <operating system> <version>** that you want to install.

5. Under **SANsurfer Router Manager for <operating system>**, click the **Download** link.
6. On the File Download dialog box, click **Save**.
7. On the Save As dialog box, specify a location on your local machine to store the installation file, and then click **Save**.  
The installer shows the download progress.
8. Continue with the steps for your operating system, either:
  - [Windows Installation](#)
  - [Linux Installation](#)
  - [Mac OS X Installation](#)

## Windows Installation

**To install SANsurfer Router Manager on a Windows PC workstation:**

1. Follow the download instructions in [“Downloading the SANsurfer Router Manager Installer” on page 3-13](#).
2. Close all programs that are currently running.
3. On the Download Complete dialog box, click **Run**.
4. If your Internet browser displays a security warning, you can safely bypass the warning.
5. Follow the prompts in the SANsurfer iSCSI-FC Router Manager installation wizard.

## Linux Installation

**To install SANsurfer Router Manager on a Linux workstation:**

1. Follow the download instructions in [“Downloading the SANsurfer Router Manager Installer” on page 3-13](#).
2. On the Download Complete dialog box, click **Open**.
3. Double-click the `.bin` file to start the installation wizard.
4. Follow the prompts in the SANsurfer iSCSI-FC Router Manager installation wizard.

## Mac OS X Installation

**To install SANsurfer Router Manager on a Mac OS X workstation:**

1. Follow the download instructions in [“Downloading the SANsurfer Router Manager Installer” on page 3-13](#).
2. On the Download Complete dialog box, click **Open**.

3. Double-click the **install.app** icon to start the installation wizard.
4. Follow the prompts in the SANsurfer iSCSI-FC Router Manager installation wizard.

## Starting SANsurfer Router Manager

To start SANsurfer Router Manager, use the applicable method:

- For Windows, either double-click the SANsurfer Router Manager desktop shortcut, or click **Start**, point to **All Programs**, point to **QLogic Management Suite**, and then click **SANsurfer Router Manager**, depending on how you installed the SANsurfer Router Manager utility.

- From a Windows command line, issue the following command:

```
<install_directory>SANsurferRouterManager.exe
```

- From a Linux command prompt, issue the following command:

```
<install_directory>./SANsurferRouterManager
```

## Configuring the Router

You can configure the router using either SANsurfer Router Manager or the CLI.

In SANsurfer Router Manager, configure router ports by selecting a Fibre Channel or iSCSI port in the left pane (tree pane), and then completing the Information and Advanced Configuration pages for that port in the right pane. For details, see the *ISR6200 Router Manager User's Guide*, “FC Ports” and “iSCSI Ports” sections.

### To configure the router using the command line interface:

1. Open a command window according to the type of workstation and connection:
  - ❑ **Ethernet** (all platforms): Open a Telnet session with the default router IP address and log into the router with the default account name (guest) and password (password):

```
telnet 10.0.0.1
username: guest
password: *****
```
  - ❑ **Serial, Windows**: Open the HyperTerminal application on a Windows platform as follows:
    - a. From the Windows **Start** menu, click **Programs**, point to **Accessories**, point to **Communications**, and then click **HyperTerminal**.
    - b. Select the connection you created earlier, and then click **OK**.

- ❑ **Serial, Linux:** Open a command window and enter the following command:

```
minicom
```

2. Open an admin session, select a blade (1 or 2), and then enter the commands to set up both iSCSI ports and the management interface. (See the *iSR6200 Command Line Interface (CLI) User's Guide* for command descriptions.)

```
iSR6200 #> admin start
Password : *****
iSR6200 (admin) #> set mgmt
.....
iSR6200 (admin) #> set iscsi 1
.....
iSR6200 (admin) #> set iscsi 2
.....
```

## Connecting Cable Devices to the Router

Connect cables to the SFP transceivers and their corresponding devices. Devices can have SFP (or small form factor, SFF) transceivers or GBICs. Choose the fiber optic cable with the connector combination that matches the device being connected to the router:

- LC-type duplex fiber optic cable connectors are designed for SFP transceivers.
- SC-type connectors are designed for GBICs.
- OM-3 connectors are designed for 10Gb ports.

## Installing New Firmware

The router comes with the current firmware installed. You can upgrade the firmware from the management workstation when new firmware becomes available.

### To locate and download new firmware:

1. Go to the QLogic Downloads and Documentation page located here:  
<http://driverdownloads.qlogic.com>
2. Under **QLogic Products**, type `router firmware` in the search box.  
(Alternatively, you can click the **Guided Search** link to obtain assistance in locating the firmware to download.)

3. In the results box under **Resource Name**, click the router firmware that you want to install, and then download the file.

You can use either SANsurfer Router Manager or the CLI to install new firmware, as shown in the following sections.

---

**NOTE**

Installing new firmware disrupts the router blade connectivity because you must reboot the router blade to activate the new firmware.

---

## Using SANsurfer Router Manager to Install Firmware

SANsurfer Router Manager provides the FW Update Wizard with the steps required to update the iSR6200 firmware on selected iSR6200 router blades.

### To install firmware using SANsurfer Router Manager:

1. On the **File** menu, click **FW Update Wizard**.
2. On the Router Selection dialog box, click the router blade to update its firmware, and then click **Next**.
3. On the Firmware File Selection dialog box, locate and select the firmware image file, and then click **Next**.
4. On the Confirm Changes dialog box, review the firmware status, and then click **Next** to confirm the changes.
5. On the Firmware Update Status dialog box, respond to the message prompts, and then click **Next**.
6. On the final dialog box, reboot to finish the firmware update.

## Using the CLI to Install Firmware

To use the CLI to install the firmware, transfer the firmware image file from a workstation to the router. Then use the CLI `image unpack` command to install the new firmware image.

### To install firmware in the CLI:

1. At the workstation prompt, use the `ftp` command to go to the location on the router where you want to transfer the firmware image. For example:

```
C:\fwImage>ftp 172.17.137.190
Connected to 172.17.137.190.
220 (none) FTP server (GNU inetutils 1.4.2) ready.
```



2. Enter your user name and password. For example:

```
User (172.17.137.190:(none)): ftp
331 Guest login ok, type your name as password.
Password: ftp
230 Guest login ok, access restrictions apply.
```

3. At the `ftp` prompt, type `bin` to set binary mode. For example:

```
ftp> bin
200 Type set to I.
```

4. Use the `put` command to transfer the firmware image file from the workstation to the router. For example:

```
ftp> put isr-6200-3_0_0_5.bin
200 PORT command successful.
150 Opening BINARY mode data connection for
'isr-6200-3_0_0_5.bin'.
226 Transfer complete.
ftp: 4822816 bytes sent in 0.41Seconds 11878.86Kbytes/sec.
```

5. Enter `quit`.

The firmware image has been transferred to the router.

6. At a Telnet prompt, log on to the router as an administrator.

7. Select one of the blades.

8. Enter the following command from the router, where `x` indicates the firmware image name:

```
image unpack isr-62xx-x_x_x_x.bin
```

The following message appears:

```
Unpack Completed. Please reboot the system for FW to take
effect.
```

9. Enter `reboot`.

The following message appears:

```
Are you sure you want to reboot the System (y/n):
```

10. To reboot the system, type `y`.

11. If a second blade is installed, repeat this procedure.



# 4 Configuration

This chapter describes how to configure the iSR6200 router to support virtual port groups (VPGs or VPGs) and LUN mapping.

Some storage arrays limit the number of LUNs exposed to a host to 256 LUNs. Each iSR6200 router blade supports up to four VPGs, making it possible for these storage arrays to present up to 1,024 LUNs per blade.

When configuring VPGs on the iSR6200 router, follow these guidelines:

- All Fibre Channel (FC) virtual ports from a single VPG must be part of only one logical host on the storage array.
- Fibre Channel ports from different VPGs must not be part of the same logical host on the storage array.
- A specific LUN can be presented to one and only one VPG. It can be presented to other Fibre Channel hosts, but only one VPG on a specific iSR6200 router (chassis).

The following sections describe how to configure VPGs and the Fibre Channel arrays connected to them:

- [“Enabling Virtual Port Groups” on page 4-2](#)
- [“Zoning Virtual Port Groups on the SAN” on page 4-9](#)
- [“Configuring Fibre Channel Array Hosts and LUN Assignments” on page 4-12](#)
- [“Connecting iSCSI Hosts to the iSR6200” on page 4-16](#)
- [“Controlling per-Host LUN Access on the iSR6200” on page 4-22](#)

## Enabling Virtual Port Groups

Each iSR6250 router blade has one virtual port group (VPG) enabled by default, which gives iSCSI hosts access to 256 LUNs. You can enable and configure additional VPGs to give iSCSI hosts access to more than 256 distinct LUNS from a specific Fibre Channel target array.

Each blade has VPG 1 enabled by default; VPG 1 is the primary virtual port group and cannot be disabled. Enabling additional virtual port groups creates additional logical Fibre Channel adapter initiator ports on the fabric. These ports act as separate Fibre Channel adapter host ports, and additional 256 LUNs can be presented to each of them. With all four VPGs enabled, a single iSR6250 blade can access up to 1,024 LUNs from a single target world wide port number (WWPN).

You can view Virtual Port Group information using the `show vpgroups` command in the CLI, as shown in the following example.

```
iSR6200 <1> (admin) #> show vpgroups
```


```
VpGroup Information
-----
Index                1
VpGroup Name         VPGROUP_1
Status               Enabled
WWPNs                21:00:00:c0:dd:13:16:f8
                    21:00:00:c0:dd:13:16:f9

Index                2
VpGroup Name         VPGROUP_2
Status               Disabled
WWPNs                N/A

Index                3
VpGroup Name         VPGROUP_3
Status               Disabled
WWPNs                N/A

Index                4
VpGroup Name         VPGROUP_4
Status               Disabled
WWPNs                N/A
```

Using SANsurfer Router Manager, select one of the VP Group nodes in the left pane to view that VP Group's information in the right pane, as shown in Figure 4-1.




**Figure 4-1. SANsurfer Router Manager VPGroup**

You can enable or disable virtual port groups on your blade using either SANsurfer Router Manager or the CLI.

**To enable or disable a VPGroup using SANsurfer Router Manager:**

1. In the system tree pane on the left, click the VP Group.  
The right panel shows information about the selected VP Group.


- 
2. In the **Status** list, select **Enabled** or **Disabled** (see [Figure 4-2](#)).



**Figure 4-2. Chassis Information for Selected VPGROUP**

- 
- 
3. Click **Save**.
4. In the System Check dialog box, type the system password, and then click **OK**.

The Set VPGroup message box opens, as shown in [Figure 4-3](#).



**Figure 4-3. Set VPGroup Message Box**

- 
- 
- 
- 
5. Click **OK** to close the message box.

### To enable or disable a VPGroup using the CLI:

The following example shows how to enable VPGroups 2 and 3 by issuing the CLI `set vpgroups` command.

```
iSR6200 <1> (admin) #> set vpgroups
```

The following wizard will query for attributes before persisting and activating the updated mapping in the system configuration. If you wish to terminate this wizard before reaching the end of the list press 'q' or 'Q' and the ENTER key to do so.

Configuring VpGroup: 1

-----

```
Status (0=Enable, 1=Disable)           [Enabled      ]
VpGroup Name (Max = 64 characters)      [VPGROUP_1    ]
```

All attribute values for VpGroup 1 that have been changed will now be saved.

Configuring VpGroup: 2

-----

```
Status (0=Enable, 1=Disable)           [Disabled     ] 0
VpGroup Name (Max = 64 characters)      [VPGROUP_2    ]
```

All attribute values for VpGroup 2 that have been changed will now be saved.

Configuring VpGroup: 3

-----

```
Status (0=Enable, 1=Disable)           [Disabled     ] 0
VpGroup Name (Max = 64 characters)      [VPGROUP_3    ]
```

All attribute values for VpGroup 3 that have been changed will now be saved.

Configuring VpGroup: 4

-----

```
Status (0=Enable, 1=Disable)           [Disabled     ]
```

All attribute values for VpGroup 4 that have been changed will now be saved.

The following example shows CLI command output using an iSR6200 blade with three virtual port groups enabled. You can view information about the virtual port groups configured on your iSR6200 by issuing the `show vpgroups` command.

```
iSR6200 <1> (admin) #> show vpgroups
```

```
VpGroup Information
-----
Index                1
VpGroup Name         VPGROUP_1
Status               Enabled
WWPNs                21:00:00:c0:dd:13:16:f8
                    21:00:00:c0:dd:13:16:f9

Index                2
VpGroup Name         VPGROUP_2
Status               Enabled
WWPNs                21:01:00:c0:dd:13:16:f8
                    21:01:00:c0:dd:13:16:f9

Index                3
VpGroup Name         VPGROUP_3
Status               Enabled
WWPNs                21:02:00:c0:dd:13:16:f8
                    21:02:00:c0:dd:13:16:f9

Index                4
VpGroup Name         VPGROUP_4
Status               Disabled
WWPNs                N/A
```

In the preceding examples, the second byte from the left (in **bold** text) denotes the virtual port group ID, and the right-most byte (in *italic* text) denotes the physical Fibre Channel port. In these examples VPGs 1 through 3 have corresponding virtual ports with **00**, **01**, and **02** presented out of physical FC ports 0 and 1, with WWPNs ending in *f8* and *f9*, respectively.



The following example shows the information grouped by physical Fibre Channel port.

```
iSR6200 <1> (admin) #> show fc
```

FC Port Information

-----

FC Port	1
Port Status	Enabled
Link Status	Up
Current Link Rate	4Gb
Programmed Link Rate	Auto
WWNN	20:00:00:c0:dd:13:16:f8 (VPGROUP_1)
WWPN	21:00:00:c0:dd:13:16:f8 (VPGROUP_1)
Port ID	0a-04-00 (VPGROUP_1)
WWNN	20:01:00:c0:dd:13:16:f8 (VPGROUP_2)
WWPN	21:01:00:c0:dd:13:16:f8 (VPGROUP_2)
Port ID	0a-04-01 (VPGROUP_2)
WWNN	20:02:00:c0:dd:13:16:f8 (VPGROUP_3)
WWPN	21:02:00:c0:dd:13:16:f8 (VPGROUP_3)
Port ID	0a-04-02 (VPGROUP_3)
Firmware Revision No.	4.05.00
Frame Size	2048
Execution Throttle	32768
Connection Mode	Point-to-Point
Programmed Connection Option	Loop Preferred
SFP Type	8Gb
FC Port	2
Port Status	Enabled
Link Status	Up
Current Link Rate	4Gb
Programmed Link Rate	Auto
WWNN	20:00:00:c0:dd:13:16:f9 (VPGROUP_1)
WWPN	21:00:00:c0:dd:13:16:f9 (VPGROUP_1)
Port ID	0a-05-00 (VPGROUP_1)
WWNN	20:01:00:c0:dd:13:16:f9 (VPGROUP_2)
WWPN	21:01:00:c0:dd:13:16:f9 (VPGROUP_2)
Port ID	0a-05-01 (VPGROUP_2)
WWNN	20:02:00:c0:dd:13:16:f9 (VPGROUP_3)
WWPN	21:02:00:c0:dd:13:16:f9 (VPGROUP_3)

## 4-Configuration


### Enabling Virtual Port Groups

Port ID	0a-05-02 (VPGROUP_3)
Firmware Revision No.	4.05.00
Frame Size	2048
Execution Throttle	32768
Connection Mode	Point-to-Point
Programmed Connection Option	Loop Preferred
SFP Type	8Gb

```
iSR6200 <1> (admin) #>
```

Notice also the VP index in the second byte from the left, and the Fibre Channel port indicator in the right-most byte.

To see this information using SANsurfer Router Manager, select one of the Fibre Channel ports, as shown in [Figure 4-4](#).




**Figure 4-4. FC Port Information Page**

#### NOTE

For more details on using the utility, use the SANsurfer Router Manager Help or refer to the *iSR6200 Router Manager User's Guide*.


## Zoning Virtual Port Groups on the SAN

When zoning the iSR6200 virtual port group WWPNs to a Fibre Channel array, you must ensure all WWPNs of a virtual port group are zoned to any single Fibre Channel target WWPN. [Figure 4-5](#) shows the proper zoning for a single blade iSR6200 with three VP groups enabled using a single Fibre Channel switch.




**Figure 4-5. Single Blade, Single Fibre Channel Switch**

When connecting a single-bladed iSR6200 to two independent SANs, connect one Fibre Channel port from your iSR6200 blade to each SAN (see [Figure 4-6](#)). This topology ensures Fibre Channel link-level and switch-level failure protection.



**Figure 4-6. Single Blade, Dual Fibre Channel Switch**

When connecting a dual-blade iSR6200 for high availability, connect one Fibre Channel port from each blade to each of your fabrics (see [Figure 4-7](#)). This topology provides link-level, switch-level, and blade-level failure protection. To make this effective, you must connect the iSCSI hosts to both iSR6200 blades. For details, see [“Connecting iSCSI Hosts to the iSR6200” on page 4-16](#).




**Figure 4-7. High-Availability, Dual Blades, Dual Fibre Channel Switches**

## Configuring Fibre Channel Array Hosts and LUN Assignments

When configuring Fibre Channel array hosts, you must treat each iSR6200 virtual port group (VPG) as its own unique Fibre Channel host within the virtualized storage array. This means if you have only one VPG enabled, the iSR6200 will have only one host entity. If you enable two more VPGs, the iSR6200 presents three separate host entities to your storage array.


Each host entity must contain WWPNs from the same VPG. [Figure 4-8](#) shows a correct configuration.



**Figure 4-8. Correctly Configured Storage Array Using Virtual Port Groups**


Do not simply group all Fibre Channel ports from the iSR6200 router into a single host entity. Doing so defeats the purpose of virtual port groups, limiting you to 256 LUNs. It will also cause problems when you later try to restore access to additional LUNs.

Figure 4-9 illustrates this incorrect configuration.




**Figure 4-9. Incorrectly Configuring All Groups to One Host Entity**

Figure 4-10 shows an incorrect assignment of virtual port group WWPNs. Notice that host entity 1 and host entity 2 both contain ports from more than one VPGGroup.



**Figure 4-10. Incorrectly Assigning VPG WWPNs**

If you are using two blades in a high availability configuration, assign each VPG from the second 6200 blade in the same chassis to the same host entity as VPG from blade 1, as shown in [Figure 4-11](#).




**Figure 4-11. Correct VPG Assignments for High Availability Configuration**

Do not put VPG ports in host entities with other Fibre Channel hosts.




When assigning LUNs to your VPG host entities, do not assign the same LUN to two VPG host entities. [Figure 4-12](#) shows a valid LUN presentation. Each LUN is presented to only one VPG. Any of these LUNs can be presented to any number of other Fibre Channel hosts on the array, but can be presented to one and only one VPG of the iSR6200.



**Figure 4-12. Correctly Assigning LUNs to Your VPG Host Entities**

Figure 4-13 shows presenting LUN 3 incorrectly. If an iSCSI host logged into both VPG0 and VPG1, it would have access to LUN 3 through two virtual port groups. This is invalid and will lead to serious problems.



**Figure 4-13. Incorrectly Presenting LUN 3**

Presenting the LUN at different LUN indexes for each VP will confuse the iSCSI host MPIO software because it will see the same LUN WWLUNID at two different indexes. This can cause the multipath I/O (MPIO) driver to panic and show a blue screen. Without an MPIO driver, the system could corrupt data on the LUN, without crashing—a situation you want to avoid.

## Connecting iSCSI Hosts to the iSR6200

Upon logging into a Fibre Channel target WWPN, an iSR6200 blade presents an iSCSI target to which iSCSI initiators can connect. This target is defined by its iSCSI qualified name (IQN) string. To correctly connect iSCSI initiators to Fibre Channel targets through the iSR6200, it is important to understand the composition of the iSCSI target IQN string.

The following example shows the anatomy of a sample IQN string from an iSR6200 router:

**iqn.2004-08.com.qlogic:iSR6200.0834e00019.b1.01.20030020c2075970**

- 1. Vendor name and registration date**
- 2. Product Name**
- 3. iSR6200 Chassis Serial Number**
- 4. Blade (b1 or b2)**
- 5. VPGGroup (01 through 04)**
- 6. Fibre Channel target WWPN**

Notice that the IQN string does not contain any information about the physical iSR6200 iSCSI port. iSCSI load balancing and failover are handled by the iSCSI host and not the iSR6200. Also notice that the IQN string does not contain any information indicating which physical iSR6200 Fibre Channel port the target device is connected.

You can view the complete list of IQN strings that your iSR6200 is presenting with the `show presented_targets` command in the CLI. For example:

```
iSR6200 <1> (admin) #> show presented_targets
```

```
Presented Target Information
```

```
-----
```

```
iSCSI Presented Targets
```

```
-----
```

```
Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.00.20030020c2075970
```

```
Alias
```

```
<MAPS TO>
```

```
WWNN      10:00:00:20:c2:07:59:70
```

```
WWPN      20:03:00:20:c2:07:59:70
```

```
Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.00.21040020c2075970
```

```
Alias
```

```
<MAPS TO>
```


```
WWNN      10:00:00:20:c2:07:59:70
```

```
WWPN      21:04:00:20:c2:07:59:70
```

## 4-Configuration

### Connecting iSCSI Hosts to the iSR6200

To view presented target information using SANsurfer Router Manager, expand the **iSCSI Presented Targets** node in the left pane, and then select the device, as shown in [Figure 4-14](#).



**Figure 4-14. Selecting the iSCSI Presented Targets in SANsurfer Router Manager**

Enabling additional VP Groups creates multiple IQN strings for the same Fibre Channel target WWPNN. The following example shows two Fibre Channel target WWPNNs and three VP groups, resulting in six presented iSCSI qualified names. For information about how to enable and configure additional VP Groups, see [“Enabling Virtual Port Groups” on page 4-2](#).

```
iSR6200 <1> (admin) #> show targets
```

```
Target Information
-----
WWNN          10:00:00:20:c2:07:59:70
WWPN          20:03:00:20:c2:07:59:70
Port ID       0a-02-00
State         Online

WWNN          10:00:00:20:c2:07:59:70
WWPN          21:04:00:20:c2:07:59:70
Port ID       0a-03-00
State         Online
```

```
iSR6200 <1> #> show vpgroups
```

```
VpGroup Information
-----
Index          1
VpGroup Name   VPGROUP_1
Status         Enabled
WWPNs          21:00:00:c0:dd:13:16:f8
                21:00:00:c0:dd:13:16:f9

Index          2
VpGroup Name   VPGROUP_2
Status         Enabled
WWPNs          21:01:00:c0:dd:13:16:f8
                21:01:00:c0:dd:13:16:f9

Index          3
VpGroup Name   VPGROUP_3
Status         Enabled
WWPNs          21:02:00:c0:dd:13:16:f8
                21:02:00:c0:dd:13:16:f9

Index          4
```

## 4-Configuration

### Connecting iSCSI Hosts to the iSR6200

---

VpGroup Name	VPGROUP_4
Status	Disabled
WWPNs	N/A

iSR6200 <1> (admin) #> **show presented\_targets**

Presented Target Information

iSCSI Presented Targets

```
-----
Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.01.20030020c2075970
Alias
<MAPS TO>
WWNN      10:00:00:20:c2:07:59:70
WWPN      20:03:00:20:c2:07:59:70

Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.01.21040020c2075970
Alias
<MAPS TO>
WWNN      10:00:00:20:c2:07:59:70
WWPN      21:04:00:20:c2:07:59:70

Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.02.20030020c2075970
Alias
<MAPS TO>
WWNN      10:00:00:20:c2:07:59:70
WWPN      20:03:00:20:c2:07:59:70

Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.02.21040020c2075970
Alias
<MAPS TO>
WWNN      10:00:00:20:c2:07:59:70
WWPN      21:04:00:20:c2:07:59:70

Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.03.20030020c2075970
Alias
<MAPS TO>
WWNN      10:00:00:20:c2:07:59:70
WWPN      20:03:00:20:c2:07:59:70

Name      iqn.2004-08.com.qlogic:iSR6200.0834e00019.r1.03.21040020c2075970
```

Alias


<MAPS TO>

WWNN 10:00:00:20:c2:07:59:70

WWPN 21:04:00:20:c2:07:59:70


iSCSI host LUN access is determined by the specific iSCSI target to which the host connects. Pay special attention to the VPG index portion of the IQN string; it is critical to understanding which group of storage array LUNs the host will access.

In [Figure 4-15](#), the iSCSI host has logged into iSCSI target for VPG0. The host can access VPG0 LUNs 1 and 2 from the storage array.




**Figure 4-15. Host Access to LUNs on Storage Array**

In [Figure 4-16](#), the iSCSI host has logged into iSCSI target for VPG1. The host can access VPG1 LUN #3 from the storage array.



**Figure 4-16. iSCSI Host Logged into iSCSI Target for VPG0**

In [Figure 4-17](#), the iSCSI host has logged into iSCSI targets for both VPG1 and VPG2. The host can access both VPG1 and VPG2 LUNs 3 and 4.



**Figure 4-17. iSCSI Host Logged into iSCSI Target for VPG1**

## Controlling per-Host LUN Access on the iSR6200


The iSR6200 allows multiple iSCSI initiators to connect to a single Fibre Channel target through a specific VPG. Controlling individual LUN access for each iSCSI host requires *LUN mapping* devices connected through the iSR6200.



**NOTE**

Before proceeding with this section, be sure you have read and understand the previous sections of this chapter.

Figure 4-18 shows that even after logging into the VPG0 iSCSI target, the host cannot access data LUNs on the storage array. To allow the iSCSI host access to each LUN, you must configure the iSR6200 using either SANsurfer Router Manager or the CLI.



**Figure 4-18. Logging into Target Before LUN Mapping**

The following example shows how to map the LUN targets with initiators using CLI commands.

```
iSR6200 <1> (admin) #> lunmask add
```

Index	Mapped	(WWNN,WWPN/iSCSI Name)
-----	-----	-----
0	Yes	iqn.1991-05.com.microsoft:winhaz38

Please select an Initiator from the list above ('q' to quit): 0

Index	(VpGroup Name)
-----	-----
1	VPGROUP_1
2	VPGROUP_2
3	VPGROUP_3
4	VPGROUP_4

Multiple VpGroups are currently 'ENABLED'.

Please select a VpGroup from the list above ('q' to quit): 1

Index	(WWNN,WWPN/iSCSI Name)
-----	-----
0	50:06:01:60:c1:e0:0d:a2,50:06:01:60:41:e0:0d:a2
1	50:06:01:60:c1:e0:0d:a2,50:06:01:68:41:e0:0d:a2


Please select a Target from the list above ('q' to quit): 0

Index	(LUN/VpGroup)	Vendor
-----	-----	-----
1	1/VPGROUP_1	DGC
2	2/VPGROUP_1	DGC
3	3/VPGROUP_1	DGC

Please select a LUN to present to the initiator ('q' to quit): 1

All attribute values that have been changed will now be saved.

Figure 4-19 shows the effect of mapping an initiator to LUN 1 using the CLI commands shown in the preceding example.




**Figure 4-19. Logging into Target After Mapping LUN 1**

You can accomplish the same LUN mapping using the SANsurfer Router Manager's Target Presentation/LUN Mapping Wizard.

**To map LUN 1 to an initiator using SANsurfer Router Manager:**


1. On the **Wizards** menu, click **Presentation Wizard**.  
The Target Presentation/LUN Mapping Wizard opens.

2. On the Select the Initiators for the LUN Presentation window, select an initiator as shown in [Figure 4-20](#), and then click **Next**.



**Figure 4-20. Target Presentation/LUN Mapping Wizard—Select the Initiators**

3. On the LUN Selection window, select LUN1 as shown in [Figure 4-21](#), and then click **Next**.




**Figure 4-21. Target Presentation/LUN Mapping Wizard—LUN Selection**

The LUN Masking Configuration Status window opens, and the Security Check dialog box prompts you to enter the admin password.

4. In the Security Check dialog box, type the system password (the default is *config*), and then click **Next**.

The LUN Masking Configuration Status window lists the mapping requests, as shown in [Figure 4-22](#).




**Figure 4-22. Target Presentation/LUN Mapping Wizard—LUN Masking Configuration Status**

5. Verify the completion status shown on the LUN Masking Configuration Status window, and then click **Finish** to close the wizard.

You can map additional LUNs using either SANsurfer Router Manager or the CLI. The iSCSI host cannot access mapped LUNs until it logs into the presented target for the corresponding iSR6200 virtual port group and Fibre Channel target WWPN.

Figure 4-23 uses color coding to identify the LUN mapping that became available after the host logs into the presented targets.



**Figure 4-23. Logging In with Mapped LUNs**

If you plan to allow all iSCSI hosts unrestricted access to all discovered Fibre Channel LUNs, you can completely disable LUN mapping using either SANsurfer Router Manager or CLI commands.

The following example shows how to do this using the `set system` CLI command. The red text shows entering the command that enables the LUN mapping.

```
iSR6200 <1> (admin) #> set system
```

A list of attributes with formatting and current values will follow.

Enter a new value or simply press the ENTER key to accept the current value.

If you wish to terminate this process before reaching the end of the list press 'q' or 'Q' and the ENTER key to do so.

WARNING:

If enabled by operator, the Symbolic Name can be embedded as part of the iSCSI Name. Changes to the iSCSI name will be effective after a reboot.

Only valid iSCSI name characters will be accepted. Valid characters include alphabetical (a-z, A-Z), numerical (0-9), colon, hyphen, and period.

Changes to the Settings below will be effective after a reboot.


System Symbolic Name (Max = 64 characters)	[Blade-1	]
Embed Symbolic Name (0=Enable,1=Disable)	[Disabled	]
Target Presentation Mode (0=Auto, 1=Manual)	[Auto	]
<b>Lun Mapping (0=Enable, 1=Disable)</b>	<b>[Disabled</b>	<b>]</b>
Controller Lun AutoMap (0=Enable, 1=Disable)	[Enabled	]
Target Access Control (0=Enable, 1=Disable)	[Disabled	]
Telnet (0=Enable, 1=Disable)	[Enabled	]
SSH (0=Enable, 1=Disable)	[Enabled	]

All attribute values that have been changed will now be saved.

#### NOTE

- You must reboot the router to change the LUN mapping status, whether you are enabling it or disabling it.
- If you are running a dual-blade HA configuration, make sure both blades have the same setting.


Figure 4-24 shows how to enable LUN mapping on an iSR6200 blade 1. To apply these changes, you must click **Save**, type the system password, and then reboot the router blade.



**Figure 4-24. Enabling LUN Mapping**



Figure 4-25 shows host LUN access with **LUN Mapping** disabled.



**Figure 4-25. Host LUN Access with LUN Masking Disabled**

**NOTE**

The iSR6200 router can access LUNs only after the host logs into iSR6200 presented iSCSI target(s).



# 5 Fibre Channel over IP

Fibre Channel over IP (FCIP) is a protocol used to transport Fibre Channel frames over TCP/IP, thus providing SAN over WAN capabilities. FCIP is commonly used to interconnect (merge) SANs that are separated by such a distance that a direct connection is cost prohibitive or technically unfeasible.

This chapter provides the following information:

- [FCIP Attributes](#) lists the attributes of FCIP implementation in the iSR6200.
- [“Configuring FCIP” on page 5-2](#) explains the parameters used in setting up FCIP, E\_Port and F\_Port extensions, WAN characteristics, data compression, bandwidth, and TCP window settings.

## FCIP Attributes

The iSR6200 system FCIP implementation has the following attributes:

- Compatible with all Fibre Channel vendor fabrics (all Fibre Channel switches)
- E\_Port extension—Bridges same Fibre Channel vendor SANs (such as Fibre Channel switches)
- F\_Port extension—Does not merge fabrics
- Supported configurations:
  - ☐ Two same-vendor Fibre Channel SAN islands
  - ☐ Direct connect from one N\_Port to a remote SAN island
- Support for 1GbE and 10GbE connections:
  - ☐ 100MBps on each 1Gb Ethernet or 8Gb Fibre Channel route
  - ☐ 400MBps on each 10Gb Ethernet or 8Gb Fibre Channel route
- Compression at 1.5Gbps
- TCP/IP selective acknowledgement (SACK) of packets
- Support for bandwidth throttling
- Distances up to 250ms with TCP window size up to 16M
- Trace route and ping support

- Links up to two locations per blade, four locations per chassis (two blades)
- FICON® support

## Configuring FCIP

To successfully configure FCIP, you need to assess both the SAN and WAN environments. The following list is provided to support the assessment.

- Extension port type:
  - ☐ E\_Port—See [“E\\_Port Extension” on page 5-62.2](#) for a description and examples.
  - ☐ F\_Port—See [“F\\_Port Extension” on page 5-8](#) for a description and examples.
- For E\_Ports, the number of ISLs (inter-switch links):
  - ☐ One
  - ☐ Two
- WAN characteristics:
  - ☐ Round-trip time (RTT)—See [“Round-Trip Time” on page 5-11](#)
  - ☐ Data rate—See [“Link Data Rate” on page 5-12](#)
  - ☐ Quality—See [“Link Quality” on page 5-12](#)
  - ☐ Firewall—See [“Firewall” on page 5-15](#)
  - ☐ Available WAN bandwidth—See [“Bandwidth Limiting” on page 5-16](#)

Table 5-1 provides space for you to write down the information that you must obtain prior to configuring an FCIP route.

**Table 5-1. FCIP Preconfiguration Information**

Router Being Configured	
IP Address	
Subnet Mask	
Gateway	
VLAN ID and Priority	
Peer Router (Remote)	
IP Address	

## Configuring an FCIP Route Using the CLI

This section shows an example of the `fciproute add` command and provides the steps to configure an FCIP route in the CLI (the GUI procedure is essentially the same).

```
iSR6200 <1> (admin) #> fciproute add
```

A list of attributes with formatting and current values will follow.  
Enter a new value or simply press the ENTER key to accept the current value.  
If you wish to terminate this process before reaching the end of the list  
press 'q' or 'Q' and the ENTER key to do so.

**WARNING:**

The following command might cause a loss of connections to both GE ports.

Configuring FCIP Route:

-----

FCIP Interfaces FC & GE (0=Enable, 1=Disable)	[Enabled	]
FC Port (1=FC1 2=FC2)	[	] <b>1</b>
GE Port (1=GE1 2=GE2)	[	] <b>1</b>
IP Address (IPv4 or IPv6; 0=IPv6 Link Local)	[0.0.0.0	] <b>192.168.1.227</b>
Subnet Mask	[0.0.0.0	] <b>255.255.255.0</b>
Gateway IP Address	[0.0.0.0	]
Remote IP Address	[0.0.0.0	] <b>192.168.1.228</b>
MTU Size (0=Normal, 1=Jumbo, 2=Other)	[Normal	]
TCP Window Size (0=8KB, 1=16KB, 2=32KB)	[32768	]
Window Scaling (0=Enable, 1=Disable)	[Enabled	]
Window Scaling Factor (Min=0, Max=9)	[7	]
TCP Port No. (Min=1024, Max=65535)	[3225	]
GE Port Speed (0=Auto, 1=100Mb, 2=1Gb)	[Auto	]
Bandwidth, Mbit/sec (Min=1, Max=1000)	[1000	]
VLAN (0=Enable, 1=Disable)	[Disabled	]
FCIP SW Compression (0=Enable, 1=Disable)	[Disabled	]

All attribute values for FCIP Route 1 will now be saved.

---

### NOTE

No action is taken on any of the settings until you complete the last step. To cancel FCIP route configuration, enter `q` for any parameter.

---

**To configure FCIP in the CLI:**

1. From a command prompt, enter the `fciproute add` command.
2. Enable (or disable) the FCIP Interfaces `FC` & `GE` ports to be used by the FCIP route.
3. At the `FC Port` prompt, enter the number corresponding to the FC port to be used for this FCIP route.
4. At the `GE Port` prompt, enter the number corresponding to the GE port to be used for this FCIP route.
5. At the `IP Address` prompt, enter the router's GE port IP address (the router being configured).
6. At the `Subnet Mask` prompt, enter the router's GE port subnet mask.
7. At the `Gateway IP Address` prompt, enter the router's GE port gateway IP address.
8. At the `Remote IP Address` prompt, enter the remote (peer) router's IP address.
9. At the `MTU Size` prompt, specify the maximum transmission unit (MTU), either `0=Normal`, `1=Jumbo`, or `2=Other`.

The MTU size is typically set to `Normal` (1,500 bytes). If all segments of the WAN support jumbo frames (9,000 bytes), select `Jumbo`. The `Other` option is typically used for WANs using encryption that requires the frame to be less than 1,500 bytes due to encryption overhead.
10. At the `TCP Window Size` prompt, specify the window size for the WAN as determined in [“TCP Window Settings” on page 5-17](#).
11. At the `Window Scaling` prompt, enable or disable this setting. Window scaling must be enabled when using a `Window Scaling Factor` (see next step) greater than zero.
12. At the `Window Scaling Factor` prompt, enter a value from 0 through 9 as scaling factor, based on the `TCP Window Size` for the WAN specified in [Step 10](#) (see [“TCP Window Settings” on page 5-17](#)).
13. (Optional) Changing the TCP port number at the `TCP Port No.` prompt should not be required. If you change this value, do *not* use a well-known TCP port number. The TCP port numbers on both the local and remote routers should be the same.


14. At the `GE Port Speed` prompt, select a GE port speed that matches that of the Ethernet switch port to which it is connected. QLogic recommends that you use a gigabit managed switch that is capable of automatically negotiating the port speed. If the Ethernet switch port speed is not capable of auto negotiation, set both the router and Ethernet switch to the same port speed.
15. At the `Bandwidth, Mbit/sec` prompt, enter a value from 1 through 1000 for the route bandwidth. To determine this value, see [“Bandwidth Limiting” on page 5-16](#).
16. At the `VLAN` prompt, enable or disable VLAN support as needed. Enable VLAN only if it is supported by the Ethernet switch.
17. At the `FCIP SW Compression` prompt, enable or disable data compression (see [“Data Compression” on page 5-16](#) to determine if compression should be enabled).

## E\_Port Extension

The FCIP configuration used to interconnect (merge) two SANs separated by distance is referred to as an *E\_Port extension*. The SANs to be interconnected (merged) must be made up of similar Fibre Channel switches, from the same manufacturer, and support ISLs using the E\_Port protocol.




Figure 5-1 shows an example of a single FCIP route (single ISL).



**Figure 5-1. E\_Port Extension, Single ISL**

Figure 5-2 shows an example of a two FCIP routes (dual ISLs). This example assumes that the Fibre Channel switches have the ability to load-balance between the ISLs to enhance performance.




**Figure 5-2. E\_Port Extension, Dual ISLs**

## F\_Port Extension


The FCIP configuration used to connect a distant F\_Port to a SAN is referred to as an *F\_Port extension*. This configuration is used to connect remote (stranded) servers to a SAN or to connect remote storage to a SAN. In the F\_Port extension configuration, one of the FCIP routers (local) is connected to a Fibre Channel switch (SAN), and the other FCIP router (remote) is directly connected to a Fibre Channel port on the server or storage.

Figure 5-3 shows an example of F\_Port extension used to connect a remote storage array.



**Figure 5-3. F\_Port Extension, Remote Storage**

Figure 5-4 shows an example of F\_Port extension used to connect a remote (stranded) server.



*Figure 5-4. F\_Port Extension, Server*

## Determining WAN Characteristics

To correctly configure an FCIP route for maximum performance and reliability requires precise understanding of the IP link (WAN) characteristics, including the following link characteristics:

- Link RTT
- Link data rate end-to-end:
  - ☐ Available link bandwidth
  - ☐ Allocated link bandwidth
- Link (WAN) quality: congestion (dropped packets) and packet errors

## Round-Trip Time

RTT is the time required for a packet to travel from the sender to the receiver, and then return to the sender. The router's ping feature, either CLI or GUI, can help determine the RTT. The following is an example of the CLI `ping` command executed on GE port 1.

```
iSR6200 <1> (admin) #> ping
```

A list of attributes with formatting and current values will follow.  
Enter a new value or simply press the ENTER key to accept the current value.  
If you wish to terminate this process before reaching the end of the list  
press 'q' or 'Q' and the ENTER key to do so.

```
IP Address (IPv4 or IPv6)           [0.0.0.0] 172.35.14.250
Iteration Count (0=Continuously)    [0        ] 10
Outbound Port (0=Mgmt, 1=GE1, 2=GE2, ...) [Mgmt    ] 1
Size Of Packet (Min=1, Max=1472 Bytes) [56       ]
```

Pinging 172.35.14.250 with 56 bytes of data:

```
Reply from 172.35.14.250: bytes=64 time=284.2ms
Reply from 172.35.14.250: bytes=64 time=284.6ms
Reply from 172.35.14.250: bytes=64 time=283.9ms
Reply from 172.35.14.250: bytes=64 time=284.4ms
Reply from 172.35.14.250: bytes=64 time=283.8ms
Reply from 172.35.14.250: bytes=64 time=284.3ms
Reply from 172.35.14.250: bytes=64 time=284.0ms
Reply from 172.35.14.250: bytes=64 time=284.0ms
Reply from 172.35.14.250: bytes=64 time=283.9ms
Reply from 172.35.14.250: bytes=64 time=284.4ms
```

Ping Statistics for 172.35.14.250:

Packets: Sent = 10, Received = 10, Lost = 0

Approximate round trip times in milliseconds:

Minimum = 283.8ms, Maximum = 284.6ms, Average = 284.1ms

```
iSR6200 <1> (admin) #>
```

## Link Data Rate

The available link data rate is not typically the same as the connection speed at the router's GE port. The GE port is typically connected to a local IP switch with ports running at 1 gigabit. The provider of the long-distance connection (WAN) provides the link data rate. [Table 5-2](#) lists some examples of data rates for commonly used WANs.

**Table 5-2. WAN Data Rates**

Link Type	Speed
T1 and DS-1	1.554Mbps
T3 and DS-3	45Mbps
OC-1	50Mbps
OC-3	150Mbps
DS-5	400Mbps
OC-12	621Mbps
OC-24	1.5Gbps

In some configurations, the data rate (bandwidth) supported by the WAN may not be dedicated to a single application such as FCIP. The ability to set the router's FCIP bandwidth usage provides for such configurations (see [“Bandwidth Limiting” on page 5-16](#)).

## Link Quality

The link (WAN) quality can be difficult to determine; however, monitoring the router's statistics should provide an indication of the overall link quality. Typically, low link level errors are not seen at the router because they generally occur in the WAN.

The following TCP statistics are a useful indicator of WAN congestion or packet errors:

- **TCP Received Duplicate ACKs**—Receiving a duplicate ACK indicates that the receiver did not receive the packet following the ACK'd packet (packet whose sequence number follows the ACK'd packet). This is typically the result of the following:
  - ❑ Congestion: An IP switch or router somewhere in the WAN has dropped the packet due to its inability to transmit or buffer the packet.
  - ❑ Error: The packet was dropped somewhere in the WAN as a result of the detection of a data error (corruption).

- **TCP Retransmit Timer Expired**—The sender of a packet did not receive an ACK for a packet within the retransmit time-out window. The sender will retransmit the packet. This is typically the result of the ACK being dropped somewhere in the WAN due to congestion or corruption of the ACK (less likely).

The following example shows the FCIP link statistics from the router's CLI `show statistics` command. The `TCP Timer Expired` value consists of two counters:

- The upper 16 bits is a count of the number of retransmits resulting from receiving duplicate ACKs (count = 34 in the example).
- The lower 16 bits is a count of the number of retransmits resulting from retransmit time outs (count = 10 in the example).

```
FCIP Link Statistics
-----
FCIP Link                               1
FC Xmit Frames                          647245
FC Xmit Bytes                          1290829908
FC Rcvd Frames                          664413
FC Rcvd Bytes                          1276994796
IP Xmit Packets                         3747952
IP Xmit Byte Count                      2849890416
IP Xmit Fragments                       0
IP Rcvd Packets                         3649896
IP Rcvd Byte Count                      2856931542
IP Rcvd Fragments                       0
IP Datagram Reassembly Count            0
IP V6Pkt Rcvd                          34
IP Error Packets                        0
IP Reassembly Errors                    0
TCP Xmit Segment Count                  3747952
TCP Xmit Byte Count                     2729955868
TCP Xmit Acks                           52598
TCP Rcvd Segment Count                  3649888
TCP Rcvd Byte Count                     2740134348
TCP Rcvd Acks                           37708
TCP Rcvd Window Probes                  0
```

<b>TCP Timer Expired</b>	<b>340010</b>
TCP ECC Error Corrections	0
MAC Xmit Frames	1890446
MAC Xmit Bytes	1534059818
MAC Xmit Multi Count	6
MAC Xmit Broad Count	2
MAC Xmit Pause Count	0
MAC Xmit Control Frames	0
MAC Xmit Deferrals	0
MAC Xmit Late Collisions	0
MAC Xmit Aborted	0
MAC Xmit Multiple Collisions	0
MAC Xmit Single Collisions	0
MAC Xmit Collisions	0
MAC Xmit Dropped Frames	0
MAC Xmit Jumbo Frames	0
MAC Rcvd Frames	1761672
MAC Rcvd Bytes	1537825039
MAC Rcvd Multi Count	35
MAC Rcvd Broad Count	6
MAC Rcvd Pause Count	0
MAC Rcvd Control Frames	0
MAC Rcvd Dribbles	0
MAC Rcvd Frame Length Errors	0
MAC Rcvd Jabbers	0
MAC Rcvd Carrier Sense Errors	0
MAC Rcvd Dropped Frames	0
MAC Rcvd CRC Errors	0
MAC Rcvd Encoding Error	0
MAC Rcvd Length Errors	0



## Firewall

When configuring an FCIP route in a WAN containing a firewall, the TCP and server ports used by the FCIP route must be unblocked. [Table 5-3](#) lists the well-known ports and server ports that require unblocking in the firewall.

**Table 5-3. Ports Requiring Unblocking**

Port	Protocol	Description
20	TCP	FTP—data
21	TCP	FTP—control (command)
23	TCP	Telnet protocol—unencrypted text communications
111	TCP, UDP	Sun remote procedure call (RPC)
161	TCP, UDP	SNMP
835	TCP, UDP	Port number on which the server listens for user requests

To verify the listen port number, run the following command (from a Linux system), where the IP address specified is that of the remote router's management port:

```
rpcinfo -p <IP address>
```

Look for the following program numbers:

Router	Program Number
iSR6142	351514
iSR6200	351515
	351516
	351517

The output of the `rpcinfo` command should be similar to the following. The numbers in the `Port #` column (714, 835, and 896 in these examples) are the port number(s) that you need to unblock.

Program #			Port #
-----			-----
351517	1	udp	714
351517	1	tcp	714
351516	1	udp	714
351516	1	tcp	714
351514	1	udp	835
351514	1	tcp	835
351515	1	udp	896
351515	1	tcp	896

## Data Compression

Data compression is an option that in some configurations can provide a data throughput rate greater than the capability of the IP link. The iSR6200 is capable of compressing data at rates up to 190Mbps. The iSR6200 can automatically enable or disable compression to achieve maximum throughput on a real-time basis, depending on the compressibility of the data and the configured bandwidth for the FCIP route. QLogic recommends that you always enable data compression and monitor the resulting performance to determine improvement. The FCIP route bandwidth must be correctly configured to realize the affects of automatic compression.

## Bandwidth Limiting

The router provides the ability to set the maximum bandwidth used by an FCIP route. This setting is very important because most WANs do not support the 1-gigabit data rate of the router's GE ports. Bandwidth limiting is also needed for those configurations where the FCIP route is only allocated a portion of the total bandwidth.

---

### NOTE

The bandwidth parameter should never be set higher than the total WAN bandwidth; otherwise, performance suffers due to WAN congestion (dropped packets).

---

When a configuration requires that the bandwidth available to the FCIP route be a percentage of the total WAN bandwidth, it is important to correctly calculate the bandwidth and set it accordingly. For instance if the FCIP route is being allocated 50 percent of an OC-3 link (150Mbps link), the route bandwidth setting should be as follows:

$$\text{Bandwidth Allocated} = 50\% \times \text{Link Rate}$$

$$75\text{Mbps} = 0.5 \times 150\text{Mbps}$$

For more information, see [“Configuring an FCIP Route Using the CLI” on page 5-4](#).

## TCP Window Settings

The TCP window size defines the amount of data sent before seeing an acknowledgement. It is used to avoid overwhelming the receiver and still maintain a constant flow of data. The TCP window size is typically calculated based on the RTT and WAN speed.

The following tables show the suggested TCP window size settings for IP links based on link speed and RTT.

**Table 5-4. T1 / DS-1—1.554Mbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	64K	1
100	32K	0
50	32K	0
25	32K	0
20	32K	0
15	32K	0
10	32K	0
5	32K	0
2.5	32K	0
1 or less	32K	0

**Table 5-5. T3 / DS-3—45Mbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	1M	5
100	512K	4
50	256K	3
25	128K	2
20	128k	2
15	64K or 128K	1 or 2
10	64K	1
5	32K	0
2.5	32K	0
1 or less	32K	0

**Table 5-6. DS-5—400Mbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	8M or 16M	8 or 9
100	4M	7
50	2M	6
25	1M	5
20	1M	5
15	1M	5
10	512K	4
5	256K	3
2.5	128K	2
1 or less	64K	1

**Table 5-7. OC-1—50Mbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	1M or 2M	5 or 6
100	512K	4
50	256K	3
25	128K	2
20	128k	2
15	64K or 128K	1 or 2
10	64K	1
5	32K	0
2.5	32K	0
1 or less	32K	0

**Table 5-8. OC-3—150Mbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	1M or 2M	5 or 6
100	1M or 2M	5 or 6
50	1M	5
25	512K	4
20	512K	4
15	256K	3
10	256K	3
5	128K	2
2.5	64K	1
1 or less	32K	0

**Table 5-9. OC-3—150Mbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	4M	7
100	1M or 2M	5 or 6
50	1M	5
25	512K	4
20	512K	4
15	256K	3
10	256K	3
5	128K	2
2.5	64K	1
1 or less	32K	0

**Table 5-10. OC-12 and Above—621Mbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	16M	9
100	8M	8
50	4M	7
25	2M	6
20	1M	5
15	1M	5
10	1M	5
5	512K	4
2.5	256K	3
1 or less	64K	1

**Table 5-11. OC-24 and Above—1.244Gbps**

Round-Trip Time (ms)	Window Size (bytes)	Scaling Factor (2 <sup>n</sup> )
250	16M	9
100	16M	9
50	8M	8
25	4M	7
20	2M or 4M	6 or 7
15	2M	6
10	2M	6
5	1M	5
2.5	512K	4
1 or less	128K	2

## Router TCP Window Setup

Table 5-12 contains router settings for the listed TCP window sizes.

**Table 5-12. Router TCP Window Settings**

Required TCP Window Size (bytes)	Router TCP Window Size (bytes)	Router Window Scaling Factor (2 <sup>n</sup> )
8K	8,192	0
16K	16,384	0
32K	32,768	0
64K	32,768	1
128K	32,768	2
256K	32,768	3
512K	32,768	4
1M	32,768	5
2M	32,768	6
4M	32,768	7
8M	32,768	8
16M	32,768	9



# 6 Diagnostics and Troubleshooting


Diagnostic information about the router is available through the chassis LEDs and the port LEDs. Diagnostic information is also available through SANsurfer Router Manager and CLI event logs and error displays. This chapter describes the following types of diagnostics:

- [Chassis Diagnostics](#)
- [“Power-On Self-Test Diagnostics” on page 6-2](#)
- [“LED Blink Patterns” on page 6-2](#)

This chapter also describes how to use maintenance mode to recover a disabled router (see [“Recovering a Router” on page 6-4](#)).

## Chassis Diagnostics

[Figure 6-1](#) shows the chassis diagnostic LEDs, including the power LED and the system fault LED.



**Figure 6-1. Router Blade Diagnostic LEDs**

## Input Power LED is Off

The input power LED lights up to show that the router logic circuitry is receiving proper voltages. If the input power LED is off, follow these steps:

- Inspect power cord and connectors. Is the cord unplugged? Is the cord or connector damaged?
  - ☐ **Yes**—Make necessary corrections or repairs. If the condition remains, continue.
  - ☐ **No**—Continue.
- Inspect AC power source. Is the power source delivering the proper voltage?
  - ☐ **Yes**—Continue.
  - ☐ **No**—Make the necessary repairs. If the condition remains, continue.
- Replace the router.

## System Fault LED is On

The system fault LED blinks a specific pattern to indicate the problem. If the system fault LED lights up, take necessary actions (see [“LED Blink Patterns” on page 6-2](#)).

## Power-On Self-Test Diagnostics

The router performs a series of tests as part of its power-on procedure. The POST diagnostic program performs the following tests:

- Memory
- FLASH validation
- PCI device discovery
- Management Ethernet port

## LED Blink Patterns

The heartbeat and system fault LEDs show the operational status of the router. When the POST completes with no errors, these LEDs blink at a steady rate of once per second. When the router is in maintenance mode, the heartbeat and system fault LEDs are on continuously.

All other system fault blink patterns show critical errors. The heartbeat LED shows an error blink pattern for the conditions listed in [Table 6-1](#).

**Table 6-1. System Fault LED Blink Patterns**

System Fault LED	Condition
OFF	Okay, operational
3 Blinks, followed by pause	System error
4 Blinks, followed by pause	Management port IP address conflict
5 Blinks, followed by pause	Over-temperature


**Heartbeat Blink Pattern**

A blink pattern on the heartbeat LED of one second ON followed by one second OFF means that the router is operating normally. The heartbeat LED shows this pattern when the router firmware is operational.




**System Error Blink Pattern**

The system fault LED generates a three-blink pattern (once per second) followed by a two-second pause to indicate a system error.



**Management Port IP Address Conflict Blink Pattern**

The system fault LED generates a four-blink pattern (once per second) followed by a two-second pause when the router detects an IP address conflict on the management Ethernet port.



You can clear the IP address conflict blinking using the CLI or SANsurfer Router Manager. Use the beacon OFF function.

## Over-Temperature Blink Pattern

The system fault LED generates a five-blink pattern (once per second) followed by a two-second pause when the router is in an over-temperature condition. That is, the air temperature inside the router is over the failure temperature of 70°C (158°F).



If the system fault LED shows the over-temperature blink pattern, follow these steps:

- Inspect the chassis air vents. Are the intake and exhaust vents clear?
  - ☐ **Yes**—Continue.
  - ☐ **No**—Remove any debris from the fan intake and exhaust if necessary. If the condition remains, continue.
- Consider the ambient air temperature near the router and clearance around the router. Make necessary corrections. If the condition remains, open a command line window and log on to the router. Enter the `shutdown` command, and then power down the router. Contact your authorized maintenance provider.

## Recovering a Router

You may have to recover a router for one of the following reasons:

- The password was changed and has been forgotten.
- The router's management IP address is unknown.

To recover the router's password, reset the password to the default by using the maintenance button (see [page 1-11](#)).

You can recover the router's IP address using either of the following methods:

- Connect to the serial console port (see [page 1-16](#)), and then use the CLI `set mgmt` command to reconfigure the management port (see the *iSR6200 Command Line Interface (CLI) User's Guide*).
- Use the maintenance button to reset the management port's IP to the factory default of 10.0.0.1 (see [page 1-11](#)).

# 7 Removal and Replacement

This chapter describes how to remove and replace the following FRUs:

- [SFP Transceivers](#)
- [iSR6200 Chassis Blades](#)
- [“Power and Cooling Modules” on page 7-10](#)

## SFP Transceivers

You can remove and replace the SFP transceivers while the iSR6200 router is operating without damaging the router or the transceiver. However, this interrupts transmission on the affected port until you install the transceiver.

- To remove a transceiver, gently press the transceiver into the port to release the tension, pull the release tab or lever, and then remove the transceiver. Different transceiver manufacturers have different release mechanisms. Consult the documentation for your transceiver.
- To install a transceiver, insert it into the port and gently press until it snaps into place.

---

### NOTE

The SFP transceiver fits only one way. If the SFP does not install under gentle pressure, flip it over and try again.

---

## iSR6200 Chassis Blades

The iSR6200 router provides an enhanced feature you can use to replace any blade in the field. In a dual-blade chassis, the iSR6200 automatically restores a replacement blade's configuration. When replacing a blade in a single-blade chassis, you can use the iSR6200 router's management tools to save and restore a blade's configuration.

The blade replacement feature ensures that the replaced unit retains the MAC addresses for the management ports and iSCSI ports, as well as the world wide port number (WWPN) and world wide node number (WWNN) for the Fibre Channel ports. Retaining these values ensures that the Fibre Channel zoning, LUN masking, and iSCSI login sessions previously established are still valid after replacing the blade. This feature retains the management IP address configuration across blade replacements.

## Dual-Blade Installation

If the iSR6200 router chassis contains dual blades prior to replacing a specific blade, you do not need to use the management tool's Save and Restore FRU features because the blade already mirrors the configuration of its peer blade. When you replace a blade, it automatically restores all the configuration data from the other blade.

The following sections show how to remove and replace a failed blade in a dual-blade chassis installation:

- [“Removing the Failed Blade” on page 7-2](#)
- [“Installing the Replacement Blade” on page 7-3](#)

### Removing the Failed Blade

**To remove a failed blade from an iSR6200 chassis with a dual blade:**

1. Prior to replacing the iSR6200 router blade, log out all iSCSI initiators from the iSR6200 blade you are replacing.
2. Disconnect all cables from the iSR6200 blade you are replacing, including Fibre Channel, iSCSI, management, Ethernet, and serial cables (see [Figure 7-1](#)).



**Figure 7-1. iSR6200 Router Blade with Cables Disconnected**

3. Remove the old blade from the chassis. [Figure 7-2](#) shows how to release the latch and pull down on the lever on the right side (1), and then pull straight back on the handle (2).



**Figure 7-2. Removing the Chassis Blade**

### Installing the Replacement Blade

Before replacing a blade for a dual-blade router installation, you must first remove it (as described on [page 7-2](#)).

**To install a replacement blade in an iSR6200 chassis with a dual blade:**

1. Unlatch the lever on the new blade prior to inserting it into the chassis, as shown in [Figure 7-3](#).



**Figure 7-3. Unlatching the Lever on the New Blade**



2. Insert the new blade into the chassis slot. [Figure 7-4](#) shows how to push the blade straight into the chassis (1), and then seat the blade onto the chassis mid-plane by pushing up the right side lever and latching it into place (2). The blade powers on and boots up.



**Figure 7-4. Inserting the New Blade into the Chassis Slot**

3. Reconnect all cables to the new blade.

## Single-Blade Installation

For a single-blade configuration, you must save the configuration of the original blade using the `fru save` command whenever the blade configuration changes. You can save the configuration of the blade on a server you can later access to use for the replacement blade. After physically replacing the blade, you can then use the `fru restore` command to restore the saved configuration to the replacement blade. This enables the replacement blade to retain all user-configured settings.

The following sections show how to remove and replace a failed blade in a single-blade chassis installation:

- [“Removing the Failed Blade” on page 7-5](#)
- [“Installing the Replacement Blade” on page 7-8](#)



## Removing the Failed Blade

**To remove a failed blade from an iSR6200 chassis with a single blade:**

1. Prior to replacing the iSR6200 router blade, log out all iSCSI initiators from the iSR6200 blade you are replacing.
2. Save the blade's FRU using either SANsurfer Router Manager or the CLI `fru save` command. The following example shows how to perform this using CLI commands.

```
iSR6200 login: guest
Password: ***** (default is password)

*****
*
*                               *
*                               *
*                               *
*                               *
*****

iSR6200 #> blade 1
iSR6200 <1> #> admin start

Password      : *****

iSR6200 <1> (admin) #> fru save

FRU save completed. Configuration File is iSR6200_FRU.bin
Please use FTP to extract the file out from the System.
```

3. Use an FTP client to get the FRU file from the iSR6200 blade. For both the user name and password, enter **ftp**. Remember to issue the **bin** command before you issue the **get** command. For example:

```
ftp <your router IP>
Connected to <your router IP>
220 (vsFTPD 2.0.5)
User (<your router IP>:(none)): ftp
331 Please specify the password.
Password:ftp
230 Login successful.
ftp> bin
200 Switching to Binary mode.
ftp> ls
200 PORT command successful. Consider using PASV.
150 Here comes the directory listing.
iSR6200_FRU.bin
226 Directory send OK.
ftp: 17 bytes received in 0.00Seconds 17000.00Kbytes/sec.
ftp> get iSR6200_FRU.bin
200 PORT command successful. Consider using PASV.
150 Opening BINARY mode data connection for iSR6200_FRU.bin (20010 bytes).
226 File send OK.
ftp: 20010 bytes received in 0.00Seconds 20010000.00Kbytes/sec.
ftp> bye
221 Goodbye.
```

4. Disconnect all cables from the iSR6200 blade. This includes all Fibre Channel, Ethernet, and serial cables. You can leave the power cables connected. (See [Figure 7-5](#).)

#### NOTE

After you have installed the new blade, you must access it. Use a computer with a TCP/IP interface capable of using Telnet to connect to the new blades default IP address of 10.0.0.1. Make sure you have such a computer available before you remove your old blade, and that the computer has the FRU file on it you saved in step 3.



**Figure 7-5. iSR6200 Router Blade with Cables Disconnected**

5. Remove the old blade from the chassis. [Figure 7-6](#) shows how to release the latch and pull down on the lever on the right side (1), and then pull straight back on the handle (2).



**Figure 7-6. Removing the Chassis Blade**

### Installing the Replacement Blade

Before replacing a blade for a single-blade router installation, you must first remove it (as described on [page 7-5](#)).

**To install a replacement blade in an iSR6200 chassis with a single blade:**

1. Unlatch the lever on the new blade prior to inserting it into the chassis, as shown in [Figure 7-7](#).



**Figure 7-7. Unlatching the Lever on the New Blade**

2. Insert the new blade into the chassis slot. [Figure 7-8](#) shows how to push the blade straight into the chassis (1), seat the blade onto the chassis mid-plane by pushing the right side lever up, and then latching it into place (2). The blade powers on and boots up.



**Figure 7-8. Inserting the New Blade into the Chassis Slot**

3. Wait until the blade finishes booting up.  
The system runs the POST. The heartbeat and system fault LEDs show the operational status of the router. When the POST completes with no errors, these LEDs blink at a steady rate of once per second.
4. Connect to the blade's Ethernet management interface to your computer.
5. Open a command line, change to the directory that contains your FRU file, and then enter **ftp 10.0.0.1**. For both the user name and password, use **ftp**. Remember to enter the **bin** command before you enter the **put** command. For example:

```
>ftp 10.0.0.1
Connected to 10.0.0.1.
220 (vsFTPD 2.0.5)
User (10.0.0.1:(none)): ftp
331 Please specify the password.
Password: ftp
230 Login successful.
ftp> bin
200 Switching to Binary mode.
ftp> put iSR6200_FRU.bin
200 PORT command successful. Consider using PASV.
150 Ok to send data.
226 File receive OK.
ftp: 20010 bytes sent in 0.00Seconds 20010000.00Kbytes/sec.
ftp> bye
221 Goodbye.

10: Telnet to 10.0.0.1, and run the 'fru restore' command.
```

```
iSR6200 login: guest
Password: ***** (default is password)
```

```
*****
*
*                               iSR6200
*
*
*****
```

```
iSR6200 #> blade 1
```

```
iSR6200 <1> #> admin start
```

Password : \*\*\*\*\*

iSR6200 <1> (admin) #> **fru restore**

A list of attributes with formatting and current values will follow.  
Enter a new value or simply press the ENTER key to accept the current value.  
If you wish to terminate this process before reaching the end of the list  
press 'q' or 'Q' and the ENTER key to do so.

Type of restore (0=full, 1=mappings only) [full] 0

FRU restore completed.

Please reboot the system for configuration to take affect.

iSR6200 <1> (admin) #> **reboot**

Are you sure you want to reboot the System (y/n): **y**  
System will now be rebooted...

iSR6200 #>

Connection to host lost.

The replacement blade should now be operational.

## Power and Cooling Modules

Each iSR6200 chassis blade has a PCM, located on the back side of the chassis.  
Each PCM consists of one power supply, three fans, and one external status LED.

The PCM's external status LED shows its status:

- Green = GOOD status, indicating that the PCM is running as expected.
- Amber = FAULT status, indicating that the PCM has failed.

You can remove and replace a failed PCM as described in the following sections:

- [“Removing the Failed PCM” on page 7-11](#)
- [“Installing the Replacement PCM” on page 7-12](#)

## Removing the Failed PCM

To remove a failed PCM from the iSR6200 chassis:

1. Locate the failed PCM unit on the back side of the iSR6200 chassis. A failed PCM unit shows an amber colored status LED.

Figure 7-9 shows the back side of two PCMs installed in a chassis configured with two iSR6200 chassis blades. The PCM on the left side shows its fault indicator in amber, which indicates a FAULT status. The PCM on the right side shows its fault indicator in green, which indicates a GOOD status.



**Figure 7-9. Back Side of Two PCMs with Fault (left) and Good (right) Status Indicators**

2. Check the second (GOOD) PCM to make sure it is ready to support storage connectivity while you are replacing the failed PCM unit. Make sure the second PCM's power cable is connected to the cable with the other end plugged into a live power source, and that it shows a green status LED.


### CAUTION

Failure to verify the functionality of the second PCM can result in lost host storage connectivity.

3. Remove the power cable from the failed PCM unit. The LED remains amber even after the removing the power cable.



4. Release the chassis latch on the left side of the unplugged PCM. As shown in [Figure 7-10](#), pull down on the lever to unseat the PCM (1), and then remove the PCM by pulling straight back on the handle (2).



**Figure 7-10. Removing the Failed PCM**

## Installing the Replacement PCM

To install a replacement PCM in the iSR6200 chassis:


1. Before you insert the new PCM into the chassis, unlatch the lever on the new PCM (see [Figure 7-11](#).)



**Figure 7-11. Unlatching Lever on New PCM**



2. Insert the replacement PCM into the iSR6200 chassis. As shown in [Figure 7-10](#), push the PCM straight into the chassis (1), and then make sure the PCM is properly seated into the chassis mid-plane by pushing the lever up and locking the latch in the up position (2). The PCM fans turn on and the LED should show an amber color.



**Figure 7-12. Inserting the Replacement PCM**

3. Connect the power cable to the newly inserted PCM. Its status LED color should change from amber to green within five seconds ([Figure 7-13](#)).



**Figure 7-13. Back Side of Two PCMs, Both With Good Status Indicators**

4. Verify that the airflow through both PCMs is in the same direction.



# A Technical Specifications

This appendix provides the following technical specification for the iSR6200 router:

- [Interface Specifications](#)
- [“Expansion Configurations” on page A-2](#)
- [“Performance Features” on page A-2](#)
- [“iSCSI Initiator Support” on page A-3](#)
- [“Device Management” on page A-3](#)
- [“Mechanical” on page A-3](#)
- [“High Availability” on page A-4](#)
- [“Protocols” on page A-4](#)
- [“Protocols” on page A-4](#)
- [“Environmental and Safety” on page A-4](#)

## Interface Specifications

The iSR6200 router can support one or two installed blades. The following interfaces apply to each router blade.

- **Gigabit Ethernet:**
  - ☐ Two ports: copper 1000 Base-T, RJ45
  - ☐ Full duplex, auto negotiating 100Mbps or 1000Mbps
- **Fibre Channel:**
  - ☐ Two optical ports, full duplex
  - ☐ Auto negotiation: 8, 4, or 2Gbps
  - ☐ N\_Ports, NL\_Ports, F\_Ports, FL\_Ports
  - ☐ Class 2, 3 connection-less

- **Management Ports:**
  - ❑ Ethernet 10 or 100 Base-T with RJ45
  - ❑ RS-232 serial port with RJ45

## Expansion Configurations

One expansion card per router blade can add one of the following optional port configurations to the system:

- Two 1Gb Ethernet modules
- Two 10Gb Ethernet FCoE or iSCSI modules (standard configuration)
- Two 8Gb Fibre Channel ports

## Performance Features

- **Maximum Data Rates:**
  - ❑ iSCSI: 2.6Gbps aggregate (1.3Gbps per blade)
  - ❑ Fibre Channel: 12.8Gbps aggregate (6.4Gbps per blade)
- **Input/output Operations per Second (IOPS):**
  - ❑ 200K IOPS aggregate (100K per blade)
- **VLAN Support:**
  - ❑ Up to two VLANs per GbE port (one for IPv4 and one for IPv6)
- **iSCSI Host Support:**
  - ❑ 2,048 iSCSI hosts (1,024 per router blade)
- **WAN Device Support:**
  - ❑ 252 WWNNs (63 per Fibre Channel port)
  - ❑ Simultaneous target and initiator mode for Fibre Channel ports
- **Supported SFP Types:**
  - ❑ Shortwave (optical)
  - ❑ Longwave (optical)
- **Interoperability:**
  - ❑ Compatible with FC-SW-2 complaint switches
  - ❑ Management interoperability with leading SAN management utilities

## iSCSI Initiator Support

- **Microsoft:** Windows 2000, 2003, and 2008
- **Solaris:** SPARC 2.6, 8, 9, 10; X86
- **Linux:** Red Hat AS 3, 4, 5; SUSE Enterprise Server 8, 9, 10
- **VMware:** ESX Server v3.0.x, v3.5x
- **AIX:** AIXL 5
- **HP-UX:** versions 9, 10
- **QLogic iSCSI adapters:** QLA4010, QLA4050, QLA4052, QLE4060, and QLE4062
- **Apple:** Mac OS X (via the ATTO® driver)

## Device Management

- **Management Methods:**
  - ☐ Wizard-based configuration tools
  - ☐ Command line interface (CLI)
  - ☐ SNMP and SMI-S
- **Access Methods:**
  - ☐ Dedicated out-of-band Ethernet 10 and 100 Base-T, RJ45, and RS-232 serial port
- **Diagnostics:**
  - ☐ POST of all functions except media modules
- **User Interface:**
  - ☐ LED front panel indicators, CLI, and browser utilities

## Mechanical

- **Enclosure Type:**
  - ☐ 1U, full rack width, mounting rails included
- **Dimensions:**
  - ☐ Width: 431.8mm (17.0 inches)
  - ☐ Height: 43.7mm (1.72 inches)
  - ☐ Depth: 631.4mm (24.9 inches)

- **Power Supply:**
  - ❑ 235W maximum (two blades and two expansion cards)
  - ❑ 106W typical (one blade and two power modules)
  - ❑ 100V AC to 240V AC; 50Hz to 60Hz
  - ❑ 1.9A at 100–125V AC; 1.02A at 200–240V AC
  - ❑ Dual, redundant, hot-swap power supplies
- **Cooling:**
  - ❑ Six redundant fans with back-to-front airflow

## High Availability

High availability (HA) specifications include the following:

- Hot-swap router blades and power supplies
- Router blade persistence: all zoning and addressing maintained in non-volatile memory.
- Fan modules powered by both power supplies.

## Protocols

Supported protocols include the following:

- iSCSI to FCP
- FCIP
- CHAP security and authentication
- IPv6 and IPv4

## Environmental and Safety

Environmental and safety specifications include the following:

- **Operating:**
  - ❑ Temperature: +5°C to +40°C (41°F to 104°F)
  - ❑ Humidity: 5 percent to 90 percent non-condensing
  - ❑ Altitude: 0 to 10,000 feet
  - ❑ Vibration: IEC 68-2, 5–500Hz, random, 0.21G rms, 10 minutes
  - ❑ Shock: IEC 68-2, 4g, 11ms, 20 repetitions

■ **Non-operating:**

- ❑ Temperature: –40°C to +70°C (–40°F to 158°F)
- ❑ Humidity: 5 percent to 93 percent non-condensing
- ❑ Altitude: 0 to 50,000 feet
- ❑ Vibration: IEC 68-2, 5–500Hz, random, 2.09G rms, 10 minutes
- ❑ Shock: IEC 68-3, 30g, 292ips, 3 repetitions, 3 axis





# **B** Simple Network Management Protocol

*Simple network management protocol* (SNMP) provides monitoring and trap functions for managing the router through third-party applications that support SNMP. The router firmware supports SNMP versions 1 and 2 and a QLogic management information base (MIB) (see [page B-3](#)). You may format traps using SNMP version 1 or 2.

This appendix provides the following SNMP information for the iSR6200:

- [“SNMP Parameters” on page B-2](#)
- [“SNMP Trap Configuration” on page B-3](#)
- [“Management Information Base \(MIB\)” on page B-3](#)
- [“Notifications” on page B-18](#)

## SNMP Parameters

You can set the SNMP properties using SANsurfer Router Manager or the CLI. For SNMP configuration details, see the *iSR6200 Router Manager User's Guide* or the *iSR6200 Command Line Interface (CLI) User's Guide*.

Table B-1 describes the SNMP parameters.

**Table B-1. SNMP Parameters**

Parameter	Description
Read community	A password that authorizes an SNMP management server to read information from the router. This is a write-only field. The value on the router and the SNMP management server must be the same. The read community password can be up to 32 characters, excluding the number sign (#), semicolon (;), and comma (,). The default password is <i>private</i> .
Trap community	A password that authorizes an SNMP management server to receive traps. This is a write-only field. The value on the router and the SNMP management server must be the same. The trap community password can be up to 32 characters, excluding the number sign (#), semicolon (;), and comma (,). The default password is <i>private</i> .
System location	Specifies the name of the router location. The name can be up to 64 characters, excluding the number sign (#), semicolon (;), and comma (,). The default is undefined.
System contact	Specifies the name of the person to be contacted to respond to trap events. The name can be up to 64 characters, excluding the number sign (#), semicolon (;), and comma (,). The default is undefined.
Authentication traps	Enables or disables the generation of authentication traps in response to authentication failures. The default is <i>disabled</i> .

## SNMP Trap Configuration

SNMP trap configuration lets you set up to eight trap destinations. Choose from Traps 1–Trap 8 to configure each trap. [Table B-2](#) describes the parameters for configuring an SNMP trap.

**Table B-2. SNMP Trap Configuration Parameters**

Parameter	Description
Trap <i>n</i> enabled	Enables or disables trap <i>n</i> . If disabled, the trap is not configured.
Trap address*	Specifies the IP address to which the SNMP traps are sent. A maximum of eight trap addresses are supported. The default address for traps is 0 . 0 . 0 . 0.
Trap port*	Port number on which the trap is sent. The default is 162. If the trap destination is not enabled, this value is 0 (zero). Most SNMP managers and management software listen on this port for SNMP traps.
Trap version	Specifies the SNMP version (1 or 2) with which to format traps.

Table Note

\* Trap address (other than 0 . 0 . 0 . 0.) and trap port combinations must be unique. For example, if trap 1 and trap 2 have the same address, they must have different port values. Similarly, if trap 1 and trap 2 have the same port value, they must have different addresses.

## Management Information Base (MIB)

This section describes the QLogic management information base (MIB). The MIB includes the following tables:

- [“Network Port Table” on page B-4](#)
- [“FC Port Table” on page B-7](#)
- [“Initiator Object Table” on page B-9](#)
- [“LUN Table” on page B-12](#)
- [“VP Group Table” on page B-14](#)
- [“Sensor Table” on page B-16](#)

## Network Port Table

The network port table contains a list of network ports that are operational on the router. The entries in this table include the management port (labeled MGMT), and the gigabit Ethernet ports (labeled GE1 and GE2).

### qsrNwPortTable

<b>Syntax</b>	SEQUENCE OF QsrNwPortEntry
<b>Access</b>	Not accessible
<b>Description</b>	Entries in this table include the management port, and the iSCSI ports on the router.

### qsrNwPortEntry

<b>Syntax</b>	QsrNwPortEntry
<b>Access</b>	Not accessible
<b>Description</b>	Each entry (row) contains information about a specific network port.

A network port entry consists of the following sequence of objects:

qsrNwPortRole	QsrPortRole
qsrNwPortIndex	unsigned32
qsrNwPortAddressMode	INTEGER
qsrIPAddressType	InetAddressType
qsrIPAddress	InetAddress
qsrNetMask	InetAddress
qsrGateway	InetAddress
qsrMacAddress	MacAddress
qsrNwLinkStatus	QsrLinkStatus
qsrNwLinkRate	QsrLinkRate

#### **qsrNwPortRole**

**Syntax**     `QsrPortRole`

**Access**     Not accessible

**Description**     Operational role of this port: management port or iSCSI port.

#### **qsrNwPortIndex**

**Syntax**     `Unsigned32`

**Access**     Not accessible

**Description**     A positive integer indexing each network port in a specific role.

#### **qsrNwPortAddressMode**

**Syntax**     `INTEGER`  
              1 = Static  
              2 = DHCP  
              3 = Bootp  
              4 = RARP

**Access**     Read-only

**Description**     Method by which the port gets its IP address.

#### **qsrIPAddressType**

**Syntax**     `InetAddressType`

**Access**     Read-only

**Description**     IP address type: `ipv4` or `ipv6`.

#### **qsrIPAddress**

**Syntax**     `InetAddress`

**Access**     Read-only

**Description**     IP address of the port.

#### **qsrNetMask**

**Syntax**     `InetAddress`

**Access**     Read-only

**Description**     Subnet mask for this port.

#### **qsrGateway**

**Syntax**     `InetAddress`

**Access**     Read-only

**Description**     Gateway for this port.

#### **qsrMacAddress**

**Syntax**     `IMacAddress`

**Access**     Read-only

**Description**     MAC address for this port.

#### **qstNwLinkStatus**

**Syntax**     `QsrLinkStatus`

**Access**     Read-only

**Description**     Operational link status for this port.

#### **qsrNwLinkRate**

**Syntax**     `QsrLinkRate`

**Access**     Read-only

**Description**     Operational link rate for this port.

## FC Port Table

This table contains a list of the Fibre Channel (FC) ports on the router. There are as many entries in this table as there are Fibre Channel ports on the router.

### qsrFcPortTable

<b>Syntax</b>	SEQUENCE OF <code>QsrFcPortEntry</code>
<b>Access</b>	Not accessible
<b>Description</b>	A list of the Fibre Channel ports on the router. The table contains as many entries as there are Fibre Channel ports on the router.

### qsrFcPortEntry

<b>Syntax</b>	<code>QsrFcPortEntry</code>
<b>Access</b>	Not accessible
<b>Description</b>	Each entry (row) contains information about a specific Fibre Channel port.

A Fibre Channel port entry consists of the following sequence of objects

<code>qsrFcPortRole</code>	<code>QsrPortRole</code>
<code>qsrFcPortIndex</code>	<code>Unsigned32</code>
<code>qsrFcPortNodeWwn</code>	<code>PhysAddress</code>
<code>qsrFcPortWwn</code>	<code>PhysAddress</code>
<code>qsrFcPortId</code>	<code>PhysAddress</code>
<code>qsrFcPortType</code>	<code>Unsigned32</code>
<code>qsrFcLinkStatus</code>	<code>QsrLinkStatus</code>
<code>qsrFcLinkRate</code>	<code>QsrLinkRate</code>

#### **qsrFcPortRole**

**Syntax**     `QsrPortRole`

**Access**     Not accessible

**Description**     Operational role of this port: FCP mode or frame shuttle mode.

#### **qsrFcPortIndex**

**Syntax**     `Unsigned32`

**Access**     Not accessible

**Description**     A positive integer indexing each Fibre Channel port in a specific role.

#### **qsrFcPortNodeWwn**

**Syntax**     `PhysAddress`

**Access**     Read-only

**Description**     World wide name of the node that contains this port.

#### **qsrFcPortWwn**

**Syntax**     `PhysAddress`

**Access**     Read-only

**Description**     World wide name for this port.

#### **qsrFcPortId**

**Syntax**     `PhysAddress`

**Access**     Read-only

**Description**     Interface's 24-bit Fibre Channel address identifier.



### qsrFcPortType

**Syntax**     Unsigned32

**Access**     Read-only

**Description**     Type of Fibre Channel port, as indicated by the use of the appropriate value assigned by the Internet Assigned Numbers Authority (IANA). The IANA-maintained registry for Fibre Channel port types is located here:

[www.iana.org/assignments/fc-port-types](http://www.iana.org/assignments/fc-port-types)

### qsrFcLinkStatus

**Syntax**     QsrLinkStatus

**Access**     Read-only

**Description**     Current link status for this port.

### qsrFcLinkRate

**Syntax**     QsrLinkRate

**Access**     Read-only

**Description**     Current link rate for this port.

## Initiator Object Table

The initiator object table is a list of the iSCSI initiators that have been discovered by the router. There are as many entries in this table as there are iSCSI initiators on the router.

### qsrlsInitTable

**Syntax**     SEQUENCE OF QsrIsInitEntry

**Access**     Not accessible

**Description**     Entries in this table contain information about initiators.

### **qsrlsInitEntry**

**Syntax**     QsrIsInitEntry

**Access**     Not accessible

**Description**     Each entry (row) contains information about a specific iSCSI initiator.

iSCSI initiator information entry consists of the following sequence of the object:

qsrlsInitIndex	Unsigned32,
qsrlsInitName	SnmpAdminString,
qsrlsInitAlias	SnmpAdminString,
qsrlsInitAddressType	InetAddressType,
qsrlsInitAddress	InetAddress,
qsrlsInitStatus	INTEGER,
qsrlsInitOsType	SnmpAdminString,
qsrlsInitChapEnabled	INTEGER

### **qsrlsInitIndex**

**Syntax**     Unsigned32

**Access**     Not accessible

**Description**     An arbitrary positive integer denoting each iSCSI initiator discovered by the router.

### **qsrlsInitName OBJECT-TYPE**

**Syntax**     SnmpAdminString

**Access**     Not accessible

**Description**     iSCSI name of the initiator.

### **qsrlsInitAlias OBJECT-TYPE**

**Syntax**     SnmpAdminString

**Access**     Read-only

**Description**     Alias for the iSCSI initiator.

#### **qsrlsInitAddressType**

<b>Syntax</b>	<code>InetAddressType</code>
<b>Access</b>	Read-only
<b>Description</b>	Type of iSCSI initiator's IP address (IPv4 or IPv6).

#### **qsrlsInitAddress**

<b>Syntax</b>	<code>InetAddress</code>
<b>Access</b>	Read-only
<b>Description</b>	IP address of the iSCSI initiator.

#### **qsrlsInitStatus**

<b>Syntax</b>	<code>Integer</code> : 1 = unknown, 2 = loggedIn, 3 = loggedOut, 4 = recovery
<b>Access</b>	Read-only
<b>Description</b>	Status of the iSCSI initiator; that is, whether or not it is logged into the router.

#### **qsrlsInitOsType**

<b>Syntax</b>	<code>SnmpAdminString</code>
<b>Access</b>	Read-only
<b>Description</b>	The type of the iSCSI initiator's operating system.

#### **qsrlsInitChapEnabled**

<b>Syntax</b>	<code>Integer</code> : 0 = enabled; 2 = disabled
<b>Access</b>	Read-only
<b>Description</b>	A value indicating whether CHAP is enabled or not for this iSCSI initiator.

## LUN Table

These tables contains information about the logical unit number (LUN) list.

### qsrLunTable

<b>Syntax</b>	SEQUENCE OF QsrLunEntry
<b>Access</b>	Not accessible
<b>Description</b>	A list of the LUNs on the Fibre Channel targets discovered by the router. There are as many entries in this table as there are Fibre Channel targets on the router.

### qsrLunEntry

<b>Syntax</b>	QsrLunEntry
<b>Access</b>	Not accessible
<b>Description</b>	Each entry (row) contains information about a specific LUN. This table extends <code>scsiDscLunTable</code> in <code>QLOGIC-SCSI-MIB</code> . The entries in this table show other attributes of the LUN.

The `QsrLunEntry` consists of the following sequences of objects.

<code>qsrLunWwuln</code>	<code>PhysAddress</code> ,
<code>qsrLunVendorId</code>	<code>SnmpAdminString</code> ,
<code>qsrLunProductId</code>	<code>SnmpAdminString</code> ,
<code>qsrLunProdRevLevel</code>	<code>SnmpAdminString</code> ,
<code>qsrLunSize</code>	<code>Unsigned32</code> ,
<code>qsrLunState</code>	<code>INTEGER</code> ,
<code>qsrLunVPGroupId</code>	<code>INTEGER</code> ,
<code>qsrLunVPGroupName</code>	<code>SnmpAdminString</code>

### qsrLunWwuln

<b>Syntax</b>	<code>PhysAddress</code>
<b>Access</b>	Read-only
<b>Description</b>	The worldwide unique LUN name (WWULN) for the LUN.

#### **qsrLunVendorId**

**Syntax**     `SnmpAdminString`

**Access**     Read-only

**Description**     Vendor ID for the LUN.

#### **qsrLunProductId**

**Syntax**     `SnmpAdminString`

**Access**     Read-only

**Description**     Product ID for the LUN.

#### **qsrLunProdRevLevel**

**Syntax**     `SnmpAdminString`

**Access**     Read-only

**Description**     Product revision level for the LUN.

#### **qsrLunSize OBJECT-TYPE**

**Syntax**     `Unsigned32`

**Units**     Megabytes

**Access**     Read-only

**Description**     Size of the LUN (in megabytes).

#### **qsrLunState**

**Syntax**     `Integer`  
              1 = online,  
              2 = offline,  
              3 = reserved

**Access**     Read-only

**Description**     State of the LUN (online or offline).

### **qsrLunVPGroupid**

**Syntax** Integer

**Access** Read-only

**Description** ID of the VP group to which this LUN belongs.

### **qsrLunVPGroupname OBJECT-TYPE**

**Syntax** SnmpAdminString

**Access** Read-only

**Description** VP group name to which this LUN belongs.

## **VP Group Table**

This table contains a list of virtual port groups (VPGs). There are four entries in this table at any point of time.

### **qsrVPGroupTable**

**Syntax** SEQUENCE OF QsrVPGroupEntry

**Access** Not accessible

**Description** Table for the VP group.

### **qsrVPGroupEntry OBJECT-TYPE**

**Syntax** QsrVPGroupEntry

**Access** Not accessible

**Description** Each entry in the VP group table.

**Index** { qsrVPGroupIndex }  
 ::= { qsrVPGroupTable 1 }

The QsrVPGroupEntry contains the following sequence of objects:

qsrVPGroupIndex	Unsigned32,
qsrVPGroupId	INTEGER,
qsrVPGroupName	SnmpAdminString,
qsrVPGroupWWNN	VpGroupWwnnAndWwpn,
qsrVPGroupWWPN	VpGroupWwnnAndWwpn,
qsrVPGroupStatus	INTEGER

**qsrVPGroupIndex OBJECT-TYPE**

**Syntax**     Unsigned32

**Access**     Read-only

**Description**   VP group index.

**qsrVPGroupId OBJECT-TYPE**

**Syntax**     Integer

**Access**     Read-only

**Description**   VP group ID.

**qsrVPGroupName**

**Syntax**     SnmpAdminString

**Access**     Read-only

**Description**   VP group name or host group name.

**qsrVPGroupWWNN**

**Syntax**     VpGroupWwnnAndWwpn

**Access**     Read-only

**Description**   Worldwide node name (WWNN) for VP group.

**qsrVPGroupWWPN OBJECT-TYPE**

**Syntax**     VpGroupWwnnAndWwpn

**Access**     Read-only

**Description**   Worldwide port number (WWPN).

**qsrVPGroupStatus OBJECT-TYPE**

**Syntax**     Integer: 0 = enabled; 1 = disabled

**Max-Access**   Read-only

**Description**   Maintain the status of the VP group (enabled or disabled)

## Sensor Table

The sensor table lists all the sensors on the router. Each table row specifies a single sensor.

### qsrSensorTable

<b>Syntax</b>	SEQUENCE OF QsrSensorEntry
<b>Access</b>	Not accessible
<b>Description</b>	List of all the sensors on the router. The table contains as many entries (rows) as there are sensors.

### qsrSensorEntry

<b>Syntax</b>	QsrSensorEntry
<b>Access</b>	Not accessible
<b>Description</b>	Each entry (row) corresponds to a single sensor.

A sensor entry consists of the following sequence of objects:

qsrSensorType	INTEGER
qsrSensorIndex	Unsigned32
qsrSensorUnits	INTEGER
qsrSensorValue	Integer32
qsrUpperThreshold	Integer32
qsrLowerThreshold	Integer32
qsrSensorState	INTEGER

### qsrSensorType

<b>Syntax</b>	INTEGER Temperature = 1
<b>Access</b>	Not accessible
<b>Description</b>	Type of data being measured by this sensor.



#### **qsrSensorIndex**

**Syntax**     `Unsigned32`

**Access**     Not accessible

**Description**     A positive integer identifying each sensor of a specific type.

#### **qsrSensorUnits**

**Syntax**     `INTEGER`  
                Celsius = 1

**Access**     Read-only

**Description**     Unit of measurement for the sensor.

#### **qsrSensorValue**

**Syntax**     `Integer32`

**Access**     Read-only

**Description**     Current value of the sensor.

#### **qsrUpperThreshold**

**Syntax**     `Integer32`

**Access**     Read-only

**Description**     Upper-level threshold for this sensor.

#### **qsrLowerThreshold**

**Syntax**     `Integer32`

**Access**     Read-only

**Description**     Lower-level threshold for this sensor.

### qsrSensorState

**Syntax**     INTEGER

**Access**     Read-only

**Description**     State of this sensor, indicating the health of the system:  
Unknown = The sensor value/thresholds cannot be determined.  
Normal = The sensor value is within normal operational limits.  
Warning = The sensor value is approaching a threshold.  
Critical = The sensor value has crossed a threshold.

## Notifications

The router provides the following notification types described in this section:

- [“System Information Objects” on page B-18](#)
- [“Notification Objects” on page B-20](#)
- [“Agent Startup Notification” on page B-20](#)
- [“Agent Shutdown Notification” on page B-20](#)
- [“Network Port Down Notification” on page B-21](#)
- [“FC Port Down Notification” on page B-21](#)
- [“Target Device Discovery” on page B-21](#)
- [“Target Presentation \(Mapping\)” on page B-22](#)
- [“VP Group Notification” on page B-22](#)
- [“Sensor Notification” on page B-22](#)
- [“Generic Notification” on page B-24](#)

---

### NOTE

Every notification uses `qsrBladeSlot` as one of the objects. This determines the originator blade for the same notification.

---

## System Information Objects

The system information objects provide the system serial number, version numbers (hardware, software, and agent), and number of ports (Fibre Channel and GbE).

**qsrSerialNumber**

**Syntax** `SnmpAdminString`

**Access** Read-only

**Description** System serial number.

**qsrHwVersion**

**Syntax** `SnmpAdminString`

**Access** Read-only

**Description** System hardware version number.

**qsrSwVersion**

**Syntax** `SnmpAdminString`

**Access** Read-only

**Description** System software (firmware) version number.

**qsrNoOfFcPorts**

**Syntax** `Unsigned32`

**Access** Read-only

**Description** Quantity of Fibre Channel ports on the system.

**qsrNoOfGbEPorts**

**Syntax** `Unsigned32`

**Access** Read-only

**Description** Quantity of GbE ports on the system.

**qsrAgentVersion**

**Syntax** `SnmpAdminString`

**Access** Read-only

**Description** Version number of the agent software on the system.

## Notification Objects

This section defines the objects used in notifications.

### **qsrEventSeverity**

**Syntax**     `INTEGER`

**Access**     Accessible for notify

**Description**     Indicates the severity of the event. The value *clear* specifies that a condition that caused an earlier trap is no longer present.

### **qsrEventDescription**

**Syntax**     `SnmpAdminString`

**Access**     Accessible for notify

**Description**     A text description of the event that occurred.

### **qsrEventTimeStamp**

**Syntax**     `DateAndTime`

**Access**     Accessible for notify

**Description**     Indicates when the event occurred.

## Agent Startup Notification

The agent startup notification indicates that the agent on the router has started running.

**qsrAgentStartup** uses the following object:

- `qsrEventTimeStamp`

## Agent Shutdown Notification

The agent shutdown notification indicates that the agent on the router is shutting down.

**qsrAgentShutdown** uses the following object:

- `qsrEventTimeStamp`

## Network Port Down Notification

The network port down notification indicates that the specified network port is **down**. The next time the port comes up, this event is sent with the `qsrEventSeverity` object set to `clear`.

`qsrNwPortDown` uses the following objects:

- `qsrNwLinkStatus`
- `qsrEventTimeStamp`
- `qsrEventSeverity`

Network notifications are sent for the following events:

- Management port: down or up
- iSCSI port: down or up
- Port number (1–4)

## FC Port Down Notification

The FC port down notification indicates that the specified Fibre Channel port is **down**. The next time the port comes up, this event is sent with the `qsrEventSeverity` object set to `clear`.

`qsrFcPortDown` uses the following objects:

- `qsrFcLinkStatus`
- `qsrEventTimeStamp`
- `qsrEventSeverity`

FC notifications are sent for the following events:

- Fibre Channel port: down or up
- Port number (1–4)

## Target Device Discovery

The Fibre Channel target device discovery notification indicates that the specified Fibre Channel target is online or offline.

`qsrDscTgtStatusChanged` uses the following objects:

- `qsrBladeSlot`
- `qsrEventTimeStamp`
- `qsrFcTgtState`
- `qsrEventSeverity`

Fibre Channel target device discovery notifications are sent for the following event:

- Fibre Channel Target
  - State: Discovered, went offline, or went online

- ☐ Target WWPN
- ☐ Blade number (1 or 2)

## Target Presentation (Mapping)

The target presentation notification indicates that the specified target has been presented (mapped) or unpresented (unmapped).

**qsrPresTgtMapped** uses the following objects:

- `qsrBladeSlot`
- `qsrEventTimeStamp`
- `qsrPresTgtMapped`
- `qsrPresTgtUnmapped`
- `qsrEventSeverity`

Target presentation notifications are sent for the following event:

- Target Presentation
  - ☐ State: Presented (mapped) or unpresented (unmapped)
  - ☐ Target name
  - ☐ Blade number (1 or 2)

## VP Group Notification

The VP group notification indicates that the specified VP group is enabled or disabled, or that its name has been changed.

**qsrVPGroupStatusChanged** uses the following objects:

- `qsrBladeSlot`
- `qsrVPGroupIndex`
- `qsrVPGroupStatus`
- `qsrEventTimeStamp`
- `qsrEventSeverity`

VP group notifications are sent for the following events:

- Change in name of a VP group
- Enabling and disabling a VP group

## Sensor Notification

The sensor notification indicates that the state for the specified sensor is not normal. When the sensor returns to the normal state, this event is sent with the `qsrEventSeverity` object set to `clear`.

**qsrSensorNotification** uses the following objects:

- `qsrSensorValue`
- `qsrSensorState`

- `qsrEventTimeStamp`
- `qsrEventSeverity`

Sensor notifications are sent for the following events:

- Over-temperature:
  - ☐ Blade number (1 or 2)
  - ☐ Sensor number (1 of 3)
- Temperature returned to normal
  - ☐ Blade number (1 or 2)
  - ☐ Sensor number (1 of 3)
- Fans at high speed:
  - ☐ PCM number (1 or 2)
- Fans returned to normal speed:
  - ☐ PCM number (1 or 2)
- PCM installed:
  - ☐ PCM number (1 or 2)
- PCM removed:
  - ☐ PCM number (1 or 2)
- PCM powered (AC power connected):
  - ☐ PCM number (1 or 2)
- PCM not powered (AC power removed):
  - ☐ PCM number (1 or 2)
- Fan failed:
  - ☐ PCM number (1 or 2)
  - ☐ Fan number (1 of 3)
- Fan returned to operational state:
  - ☐ PCM number (1 or 2)
  - ☐ Fan number (1 of 3)

## Generic Notification

The generic notification reports events other than the defined event types. It provides a description object that identifies the event in clear text.

**qsrGenericEvent** uses the following objects:

- `qsrEventTimeStamp`
- `qsrEventSeverity`
- `qsrEventDescription`

Generic notifications are sent for the following events:

- Fibre Channel port configuration change:
  - ☐ Blade number (1 or 2)
  - ☐ Port number (1 of 4)
- iSCSI port configuration change:
  - ☐ Blade number (1 or 2)
  - ☐ Port number (1 of 4)
- iSNS configuration change:
  - ☐ Blade number (1 or 2)
- NTP configuration change:
  - ☐ Blade number (1 or 2)
- Router configuration change:
  - ☐ Blade number (1 or 2)
- Management port configuration change:
  - ☐ Blade number (1 or 2)
- Firmware upgrade complete:
  - ☐ Blade number (1 or 2)
- Reboot blade:
  - ☐ Blade number (1 or 2)



# C Log Messages

This appendix provides details about messages logged to a file. (For details about viewing the router logs, see the *iSR6200 Command Line Interface (CLI) User's Guide* or the *iSR6200 Router Manager User's Guide*.) The message log is persistent because it is maintained across router power cycles and reboots.

Information in [Table C-1](#) is organized as follows:

- The **ID** column specifies the message identification numbers in ascending order.
- The **Log Message** column indicates the message text shown in the CLI or SANsurfer Router Manager router log. Note that:
  - ❑ Log messages for the iSCSI driver module are common to both iSCSI ports. Log messages beginning with #0 denote iSCSI port 1 (GE1) and log messages beginning with #1 denote iSCSI port 2 (GE2).
  - ❑ Log messages for the Fibre Channel driver module are common to both Fibre Channel ports. Log messages beginning with #0 denote Fibre Channel port 1 (FC1) and log messages beginning with #1 denote Fibre Channel port 2 (FC2).
- The **Module Type** column specifies the message reporting module, where:
  - ❑ **App** = Application module
  - ❑ **FC** = Fibre Channel driver
  - ❑ **FCIP** = Fibre Channel IP driver
  - ❑ **iSCSI** = iSCSI driver
  - ❑ **System** = System module

- ☐ **TOE** = TCP/IP offload engine module
- ☐ **User** = User module
- The **Msg. Type** column specifies the log message type, where:
  - ☐ **Error** = Error log message
  - ☐ **Fatal** = Fatal log message
  - ☐ **Info** = Informational log message
- The **Description** column provides additional information about the log message.

**Table C-1. iSR6200 Router Log Messages**

ID	Log Message	Module Type	Msg. Type	Description
40967	QLBA_NullDoorbell: driver unloaded, port disabled	App	Error	NULL doorbell routine for unloaded drivers. When a driver is unloaded, the doorbell routine is redirected to this NULL routine.
40996	QLBA_ProcessTrb: Processing unsupported ordered tag command	App	Error	Processing unsupported ordered tag task management command.
41004	QLBA_ProcessTrb: Processing unsupported head of queue tag command	App	Error	Processing unsupported head-of-queue task management command.
41058	QLBA_CreateTargetDeviceObject: Too many devices	App	Error	Unable to create an object for the target device; exceeded the maximum number of target devices.
41060	QLBA_CreateTargetNodeObject: Too many devices	App	Error	Unable to create an object for the target node; exceeded the maximum number of target devices.
41067	QLBA_CreateLunObject: LunObject memory unavailable	App	Error	Memory unavailable for LUN object.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
41077	QLBA_CreateInitiatorObject: Too many initiators	App	Error	Unable to create an object for initiator object; exceeded the maximum number of initiators.
41096	QLBA_DisplayTargetOperationStatus: PCI Error, Status 0x%.2x	App	Error	Process control block status indicates that a peripheral component interconnect (PCI) error occurred during a target operation.
41106	QLBA_DisplayInitiatorOperationStatus: DMA Error, Status 0x%.2x	App	Error	Process control block status indicates that a direct memory access (DMA) error occurred during an initiator operation.
41107	QLBA_DisplayInitiatorOperationStatus: Transport Error, Status 0x%.2x	App	Error	Process control block status indicates that a transport error (protocol) occurred during an initiator operation.
41111	QLBA_DisplayInitiatorOperationStatus: Data Overrun, Status 0x%.2x	App	Error	Process control block status indicates that a data overrun error occurred during an initiator operation.
41234	QLIS_LoginPduContinue: Operation failed. Initiator 0x%x, TPB status 0x%x	App	Error	iSCSI login failed between receipt of protocol data unit (PDU) and request for the data segment.
41238	QLKV_ValidateLoginTransitCsgNsgVersion failed (status 0x%x)	App	Error	iSCSI login failed due to unsupported version number in received login PDU.
41257	QLIS_LoginPduContinue: Invalid initiator name. Initiator:	App	Error	iSCSI Login PDU contains invalid initiator name. The format and character set used to form the initiator name is invalid.
41265	QLIS_LoginPduContinue: Target not configured for Portal	App	Error	iSCSI target login was attempted to a portal (iSCSI1 or iSCSI2) on which the target is not presented.
41267	QLIS_LoginPduContinue: Target not found. Target name:	App	Error	iSCSI Login PDU received for a target with a target name unknown to the router.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
41268	QLIS_LoginPduContinue: Missing target name	App	Error	iSCSI Login PDU received without a target name for a normal session.
41270	QLIS_LoginPduContinue: TSIH is 0 but InitiatorName key/value not provided	App	Error	iSCSI Login PDU received without an initiator name key or value.
41272	QLIS_LoginPduContinue: CONN_STATE_IN_LOGIN, Unknown InitTaskTag	App	Error	iSCSI Login PDU received with an incorrect initiator task tag for a session that is partially logged in. This would occur if a login PDU other than the initial login PDU used an initiator task tag that was different from the initiator task tag provided in the initial login PDU.
41283	QLIS_LoginPduContinue: TSIH 0x%x out of range	App	Error	iSCSI login PDU was received with a target session identifying handle (TSIH) out of range. This would occur if the iSCSI initiator attempting the login failed to use the TSIH value provided in the Target Login Response PDU (router is target) in subsequent login PDUs.
41284	QLIS_LoginPduContinue: Session does not exist, invalid TSIH 0x%x	App	Error	iSCSI Login PDU was received with an invalid TSIH value. The TSIH is invalid because there is no session with that TSIH value. This would occur if the iSCSI initiator attempting the login failed to use the TSIH value provided in the target login response PDU (router is target) in subsequent login PDUs.
41353	QLIS_LoginPduContinue: Session does not exist, invalid TSIH 0x%x	App	Error	iSCSI Login rejected due to a CHAP authentication error.
41354	QLIS_LoginPduContinue: Unexpected CHAP key detected	App	Error	iSCSI Login rejected due to a CHAP key error.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
41508	QLBI_SetPortInfo: QLUT_AllocatePortalObject failed (PortType 0x%x, PortId 0x%x)	App	Error	Failed to allocate an object for <i>Set Port Info</i> IOCTL processing:  PortType: 0 = Fibre Channel, 1 = iSCSI PortId: 0 = FC1 or iSCSI1(GE1), 1 = FC2 or iSCSI2 (GE2)
41626	QLBI_GetLunInfo: INQUIRY failed, TPB status 0x%x	App	Error	Inquiry command failed. The Inquiry command was issued by the router as part of its discovery process.
41629	QLBI_GetLunInfo: INQUIRY failed, TPB status 0x%x	App	Error	Pass-Through command for Inquiry command for page 83 failed. The Inquiry command was issued by the router as part of its discovery process.
41635	QLBI_Passthru: Invalid data length %d bytes	App	Error	Pass-Through command for Read Capacity command failed. The Read Capacity command was issued by the router as part of its discovery process.
41636	QLBI_GetLunInfo: INQUIRY failed, TPB status 0x%x	App	Error	Read Capacity command failed. The Read Capacity command was issued by the router as part of its discovery process.
41696	QLBI_GetLunInfo: INQUIRY failed, TPB status 0x%x	App	Error	Pass-Through command issued by management application (such as GUI) was aborted.
41700	QLBI_Passthru: Invalid CDB length %d bytes	App	Error	Pass-Through command issued by management application (such as GUI) failed due to invalid command descriptor block (CDB) length.
41701	QLBI_Passthru: Invalid data length %d bytes	App	Error	Pass-Through command issued by management application (such as GUI) failed due to invalid data length.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
41717	QLBI_Passthru: Invalid data length %d bytes	App	Error	Pass-Through command issued by management application (such as GUI) was interrupted or timed out.
41750	QLBI_Ioctl: ERROR: Operation (0x%x) not supported in this mode	App	Error	IOCTL operation unsupported. Operation code provided in log message.
41768	QLBI_GetLunList: REPORT LUNS command failed	App	Error	Report LUNs command failed. The Report LUNs command was issued by the router as part of its discovery process.
41769	QLBI_GetLunList: REPORT LUNS command failed with CHECK CONDITION, SCSI STATUS 0x%02X	App	Error	Report LUNs command failed with check condition status. The Report LUNs command was issued by the router as part of its discovery process.
41771	QLBI_GetLunList: Lun allocation failed for LunId %d	App	Error	Failed to allocate LUN object; out of resources.
41994	QLFC_Login: VpIndex (%d) out of range	App	Error	Login attempted using Fibre Channel virtual port (VP) index that is out-of-range (range = 0–31). Index reported in log message.
41995	QLFC_Login: VP Index 0x%x not configured	App	Error	Login attempted using Fibre Channel VP index that has not been configured. Operation attempted on an unconfigured VP.
42002	QLFC_Login: Can't open connection	App	Error	Attempting login but Fibre Channel connection cannot be opened.
42024	QLFC_Logout: No active path to device. WWPN: %.2X%.2X%.2X%.2X%.2X%.2X%.2X%.2X	App	Error	Attempting logout of device for which there is no active path (WWPN not found).

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
42027	QLFC_Logout: VP Index 0x%x not configured	App	Error	Logout attempted using Fibre Channel VP index that has not been configured. Operation attempted on an unconfigured VP.
42068	QLFC_HandleTeb: System Error	App	Error	Event notification; Fibre Channel processor encountered a system error (unrecoverable firmware error).
42069	QLFC_HandleTeb: Driver Fatal Error	App	Error	Event notification; Fibre Channel driver encountered a fatal error.
42072	QLFC_HandleTeb: Driver Fatal Error	App	Error	Event notification; Fibre Channel port logged out.
42242	QLIS_AllocateSessionObject: Out of session resources	App	Error	Failed to allocate object for iSCSI session; out of session resources.
42252	QLIS_EnqueueiScsiPdu: Duplicate PDU, CmdSN %d (0x%x), dropping it	App	Error	Received iSCSI PDU with duplicate command sequence number (CmdSN). Command PDU will be dropped.
42258	QLIS_InstantiateSession: Can't add Initiator to the database	App	Error	Unable to allocate iSCSI initiator object while instantiating session.
42259	QLIS_InstantiateSession: Maximum number (%d) of allowed hosts already logged in	App	Error	iSCSI session login rejected because the maximum number of allowed hosts are already logged in.
42404	QLIS_InstantiateSession: Maximum number (%d) of allowed hosts already logged in	App	Error	Failed to execute iSCSI Command PDU because its CmdSN is out-of-range. Log message contains the incorrect CmdSN, the valid CmdSN range, the first byte of the CDB, and the data length.
42648	QLIS_HandleTeb: Driver Fatal Error	App	Error	Event notification; iSCSI driver encountered a fatal error.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
42649	QLIS_HandleTeb: Unload Driver	App	Error	Event notification; an IOCTL request was received to unload the iSCSI driver.
42654	QLIS_HandleTeb: iSNS Connection Failed	App	Error	Event notification; attempt to connect to the iSNS server failed.
43265	QLUT_AllocateTpbExtension: TPB allocation failed	App	Error	Failed to allocate memory for TPB extension.
43267	QLUT_AllocateTpbExtension: Alloc of DSD failed for buffer len %d	App	Error	Failed to allocate data segment descriptor (DSD) (buffer length %d).
43268	QLUT_AllocateTpbExtension: Data buffer allocation failed (length %d)	App	Error	Failed to allocate data buffer (length %d).
44549	QLDM_HandleMigError: Migration Job %d stopped for Src Lun %hd Dest Lun %hd Error %x AdditionalErrorStatus %x at line %d	App	Error	An error occurred on an I/O that was issued for a migration job. The message provides the job ID, source, and destination LUN IDs, as well as the error.
53254	System Booting Up.	App	Info	Router is booting up.
53357	QLBA_ProcessTpb: De-compression failed. Disabling compression temporarily	App	Info	Decompression failed. Disabling compression temporarily.
53584	QLIS_LoginPduContinue: [0x%x] SES_STATE_LOGGED_IN NORMAL	App	Info	iSCSI session full feature login.
53585	QLIS_LoginPduContinue: [0x%x] SES_STATE_LOGGED_IN DISCOVERY	App	Info	iSCSI session discovery login.
53586	QLIS_LoginPduContinue: Initiator: %s	App	Info	iSCSI login of Initiator: %s.
53587	QLIS_LoginPduContinue: Target: %s	App	Info	iSCSI login of Target: %s.



**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
54274	QLFC_Login: Origin 0x%x, VP Index 0x%x, Id 0x%x	App	Info	Fibre Channel login occurred, origin xx (1 = adapter, 2 = target, 3 = initiator), VP (virtual port) xx, ID (loop ID) xx.
54275	QLFC_Login: Port ID %.2x%.2x%.2x	App	Info	Fibre Channel login occurred with port ID xx.xx.xx.
54276	QLFC_Login: Node Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	Fibre Channel login occurred with WWNN xx.xx.xx.xx.xx.xx.xx.xx.
54277	QLFC_Login: Port Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	Fibre Channel login occurred with WWPN xx.xx.xx.xx.xx.xx.xx.xx.
54306	QLFC_Logout: Origin 0x%x, VP Index 0x%x, Id 0x%x	App	Info	Fibre Channel Logout: Origin 0x%x, VP Index 0x%x, Id 0x%x.
54307	QLFC_Logout: Port ID %.2x%.2x%.2x	App	Info	Fibre Channel Logout: Port ID %.2x%.2x%.2x
54308	QLFC_Logout: Node Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	Fibre Channel Logout: Node Name xx xx xx xx xx xx xx xx.
54309	QLFC_Logout: Port Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	Fibre Channel Logout: Port Name xx xx xx xx xx xx xx xx.
54359	QLFC_Logout: Port Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	Fibre Channel login event notification, VP (virtual port) xx.
54683	QLIS_OpenConnectionNotification: Target connection opened (Port %d, DDB %d)	App	Info	iSCSI target connection opened for port %d, data description block (DDB) %d.
54938	QLIS_OpenConnectionNotification: Target connection opened (Port %d, DDB %d)	App	Info	Event notification; iSCSI open connection request.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
54939	QLIS_HandleTeb: UTM_EC_CLOSE_CONNECTION or UTM_EC_CONNECTION_CLOSED	App	Info	Event notification; iSCSI close connection request or connection closed.
54940	QLIS_HandleTeb: UTM_EC_CLOSE_CONNECTION or UTM_EC_CONNECTION_CLOSED	App	Info	Event notification; iSCSI connection closed.
54941	QLIS_HandleTeb:iSNS Server Open Connection succeeded	App	Info	Event notification; connection opened with iSNS server.
54943	QLIS_HandleTeb: UTM_EC_ISNS_SCN	App	Info	Event notification; iSNS registered state change notification (RSCN) received.
54945	QLIS_HandleTeb: UTM_EC_ISNS_CLIENT_DISCOVERED	App	Info	Event notification; iSNS client discovered.
56321	QLMP_Logout: Virtual Target Logged out	App	Info	An array went offline because all the target ports of the array went offline.
56322	QLMP_Logout: Node Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	WWNN of the array that went offline. This is tied with ID 56321.
56323	QLMP_Logout: Port Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	WWPN of the array that went offline. This is tied with ID 56321.
56346	QLMP_CombineMPDevice: Virtual Target Online	App	Info	An array came online.
56347	QLMP_CombineMPDevice: Node Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	WWNN of the array that came online. This is tied with ID 56346.
56348	QLMP_CombineMPDevice: Port Name %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x	App	Info	WWPN of the array that came online. This is tied with ID 56346.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
56842	QLDM_ResumeMigration: Failed to resume job: %d, job's current state: 0x%x, error: %d	App	Info	Failed to resume a paused job.
56865	QLDM_DelayedStart:%d Failed to start job : Job ID: %d	App	Info	Failed to start a delayed schedule job.
56866	Lun is already used for of some other migration job	App	Info	Migration add failed because LUN is part of another migration job.
56867	Selected Lun is a Controller Lun	App	Info	Migration being added with a LUN that is a controller LUN. Data LUNs are required for configuring migration jobs.
56868	Selected Lun is Masked, It cant be used for Offline Migration	App	Info	Migration job being added for a LUN that is masked to an initiator on the router. Mapped LUNs cannot be used for offline migration jobs.
56869	Read Capacity is not available for the Lun	App	Info	Migration job being added for a LUN for which no read capacity Information is available. Migration add will fail.
56870	QLDM_CreateMigrationObject: Failed to create Source Lun Object	App	Info	Failed to allocate memory for the source LUN of a migration job.
56871	QLDM_CreateMigrationObject: Failed to create Destination Lun Object	App	Info	Failed to allocate memory for the destination LUN of a migration job.
56872	QLDM_CreateMigrationObject: MigrationObject memory unavailable	App	Info	Failed to allocate memory for the migration job.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
56880	Start time got from user %lu Cur Time: %lu Diff: %d	App	Info	The log shows the configured start time and current time for a delayed migration job.
56881	Failed to stop migration job id %u	App	Info	Failed to stop a migration job; the error message includes the job ID.
56884	QLDM_DeleteMigrationJobByLun: Could not find migration object	App	Info	Did not find a migration job for the associated LUN object.
69652	##d: qlutm_init: Diagnostic failed, invalid SRAM	iSCSI	Fatal	iSCSI processor SRAM test failed.
69653	##d: qlutm_init: Diagnostic failed, fail reboot	iSCSI	Fatal	iSCSI processor failed diagnostic reboot.
69654	##d: qlutm_init: Diagnostic failed, invalid NVRAM	iSCSI	Fatal	iSCSI processor failed NVRAM diagnostic.
69655	##d: qlutm_init: Diagnostic failed, invalid DRAM	iSCSI	Fatal	iSCSI processor failed DRAM diagnostic.
69656	##d: qlutm_init: Failed to return diagnostic result to Bridge	iSCSI	Fatal	iSCSI processor failed to return diagnostic results.
69941	##d: QLUtmProcessResponseQueue: Invalid handle %x EntryType %x	iSCSI	Fatal	Response queue entry contains an invalid handle.
69951	##d: QLSetNvram: QLRebootTimer failed AF %x RS %x Time %d	iSCSI	Fatal	Set NVRAM reboot timer failed.
69964	##d: QLDisable: QLRebootTimer failed AF %x RS %x Time %d	iSCSI	Fatal	Port disable reboot timer failed.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
69966	##d: QLEnable: QLRebootTimer failed AF %x RS %x Time %d	iSCSI	Fatal	Port enable reboot timer failed.
70224	##d: QLProcSrblessiSNSResponse: Invalid handle %x	iSCSI	Fatal	iSNS response contains an invalid handle.
70400	##d: QLInitializeDevice: QLStartAdapter failed	iSCSI	Fatal	Start iSCSI processor failed.
70417	##d: QLInitializeAdapter: QLInitializeFW failed	iSCSI	Fatal	iSCSI processor firmware initialization failed.
70432	##d: QLDoInterruptServiceRoutine: PortFatal interrupt. PortFatalErrorStatus %08x CSR %08x AS %x AF %x	iSCSI	Fatal	iSCSI processor port fatal error.
70448	##d: QLStartAdapter: QLRebootTimer failed AF %x RS %x Time %d	iSCSI	Fatal	Start iSCSI processor reboot timer failed.
70489	##d: QLIsrDecodeMailbox: System Error 8002 MB[1-7] %04x %04x %04x %04x %04x %04x	iSCSI	Fatal	iSCSI processor fatal system error.
70499	##d: QLProcessResponseQueue: Invalid handle for ET_PASSTHROUGH_STATUS	iSCSI	Fatal	Response queue invalid handle for ET pass-through.
70501	##d: QLProcessResponseQueue: Invalid entry type in response queue %x	iSCSI	Fatal	Response queue invalid entry type.
70502	##d: QLProcessResponseQueue: Invalid handle %x EntryType %x	iSCSI	Fatal	Response queue invalid handle for specified entry type.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
70524	##d: QLProcessAen: Invalid event %x	iSCSI	Fatal	Asynchronous event for unknown event type.
70544	##d: QLRebootTimer: Reboot failed!	iSCSI	Fatal	Reboot timer failed.
70563	##d: QLRebootTimer: Reboot failed!	iSCSI	Fatal	iSCSI driver missed iSCSI processor heartbeat. iSCSI processor rebooted.
70564	##d: QLRebootTimer: Reboot failed!	iSCSI	Fatal	iSCSI processor failed to complete operation before timeout.
70609	##d: QLRebootTimer: Reboot failed!	iSCSI	Fatal	iSCSI processor system error restart.
70610	##d: QLProcessSystemError: RebootHba failed	iSCSI	Fatal	iSCSI processor reboot failed.
70784	##d: QLConfigChip: invalid NVRAM	iSCSI	Fatal	iSCSI processor NVRAM invalid (checksum error).
70835	##d: QLStartFw: MBOX_CMD_SET_FLASH failed %x	iSCSI	Fatal	The iSCSI controller Set Flash command failed.
70836	##d: QLStartFw: Invalid Fw loader state 0x%x	iSCSI	Fatal	The iSCSI controller failed to load firmware.
70837	##d: QLStartFw: Load Fw loader timeout	iSCSI	Fatal	The iSCSI controller firmware load operation timed out.
70938	##d: ql_adapter_up: Failed to initialize adapter	iSCSI	Fatal	The iSCSI controller failed to initialize.
72351	##d: QLProcSrblessiSNSResponse: Invalid handle %x	iSCSI	Fatal	The iSCSI controller reported that an iSNS response had an invalid handle.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
73990	##d: QLUtmIoctlEnable: Initialize FW failed	iSCSI	Error	The iSCSI processor failed firmware initialization.
74056	##d: QLRUNDiag: MBOX Diag test internal loopback failed %x %x	iSCSI	Error	The iSCSI processor failed the internal loopback test.
74057	##d: QLRUNDiag: MBOX Diag test external loopback failed %x %x	iSCSI	Error	The iSCSI processor failed the external loopback test.
74068	##d: QLUtmReceiveScsiCmd: Invalid ATIO Continuation type %x	iSCSI	Error	The iSCSI processor reported an invalid Accept Target I/O (ATIO) Continuation type x.
74069	##d: QLUtmProcessResponseQueue: Immediate data addr %08x:%08x in unsupported PduType	iSCSI	Error	The iSCSI processor reported an Immediate data address (xxxxxxxx:xxxxxxxx) in an unsupported PDU Type.
74241	##d: QLiSNSEnableCallback: iSNS Server TCP Connect failed	iSCSI	Error	The iSCSI processor could not connect with the iSCSI name server (iSNS).
74577	##d: QLIsrDecodeMailbox: NVRAM invalid	iSCSI	Error	The iSCSI processor reported that the iSCSI port NVRAM contains invalid data (checksum error).
74580	##d: QLIsrDecodeMailbox: AEN %04x, Duplicate IP address detected, MB[1-5] %04x %04x %04x %04x %04x	iSCSI	Error	The iSCSI processor reported a duplicate IP address was detected (address xxxx xxxx xxxx xxxx xxxx).
74587	##d: QLIsrDecodeMailbox: Link down	iSCSI	Error	The iSCSI processor reported a link down condition.
74656	##d: QLReadyTimer: Adapter missed heartbeat for %d seconds. Time left %d	iSCSI	Error	The driver failed to receive a heartbeat from the iSCSI processor for the specified number of seconds.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
74659	##d: QLReadyTimer: Adapter missed heartbeat for 0x%x seconds	iSCSI	Error	The iSCSI processor (adapter) failed to provide a heartbeat for x seconds.
74660	##d: QLReadyTimer: Abort pTpb=%p failed, DrvCount 0x%x	iSCSI	Error	The iSCSI processor failed to complete an abort request.
74661	##d: QLTimer: Abort pTpb=%p, Type %x, Timeout 0x%x DrvCount 0x%x, DdbIndex 0x%x	iSCSI	Error	The driver timed out an iSCSI processor operation and is aborting the operation.
74663	##d: QLReadyTimer: MBOX_CMD %04x %04x %04x %04x %04x %04x %04x %04x timed out	iSCSI	Error	The driver timed out an iSCSI processor mailbox command.
74665	##d: QLReadyTimer: QLiSNSReenable failed.	iSCSI	Error	The driver timed out while attempting to reconnect with the iSNS.
74705	##d: QLProcessSystemError: Restart RISC	iSCSI	Error	The iSCSI processor was restarted.
74746	##d: QLInitializeFW: MBOX_CMD_INITIALIZE_FIRMWARE failed %04x %04x %04x %04x %04x	iSCSI	Error	The iSCSI processor rejected the firmware initialize command.
74784	##d: QLUpdateInitiatorData: No more room in Initiator Database.	iSCSI	Error	The driver's initiator database is full. The driver is capable of storing 1024 iSCSI initiators in its database. Use the CLI or GUI to remove unwanted or unused iSCSI initiators.
74800	##d: QLSetTargetData: No more room in Target Database.	iSCSI	Error	The driver's target database is full. Use the CLI or GUI to remove unwanted or unused iSCSI targets.
75008	##d: ql_process_error: OB_TCP_IOCB_RSP_W returned DdbInx 0x%x pTpb %p	iSCSI	Error	A TCP retry for a frame failed on the connection ddbIndex. Tpb contains the frame memory address.



**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
86347	##d: QLDisable: Restart RISC	iSCSI	Info	Restart iSCSI processor (RISC).
86349	##d: QLEnable: Restart RISC to update EEPROM	iSCSI	Info	EEPROM updated, restart iSCSI processor (RISC).
86874	##d: QLIsrDecodeMailbox: Link up	iSCSI	Info	Link up reported by iSCSI processor for GE1 or GE2.
87346	##d: QLGetFwStateCallback: link 100Mb FDX	iSCSI	Info	The iSCSI controller reported a link speed or configuration of 100Mb full-duplex (FDX).
87348	##d: QLGetFwStateCallback: link 1000Mb FDX	iSCSI	Info	The iSCSI controller reported a link speed/configuration of 1000Mb FDX.
87350	##d: QLGetFwStateCallback: Invalid link speed 0x%x	iSCSI	Info	The iSCSI controller reported an invalid link speed.
102419	##d: qlutm_init: Diagnostic failed, port 1 invalid SRAM	FC	Fatal	FC1 processor SRAM test failed.
102420	##d: qlutm_init: Diagnostic failed, port 1 POST failed	FC	Fatal	FC1 processor power-on self-test (POST) failed.
102421	##d: qlutm_init: Diagnostic failed, port 2 invalid SRAM	FC	Fatal	FC2 processor SRAM test failed.
102422	##d: qlutm_init: Diagnostic failed, port 2 POST failed	FC	Fatal	FC2 processor POST failed.
102423	##d: qlutm_init: Failed to return diagnostic result to Bridge	FC	Fatal	Fibre Channel processor failed to return diagnostic results.
102656	##d: QLInitializeAdapter: Reset ISP failed	FC	Fatal	Fibre Channel processor failed reset.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
102657	##d: QLInitializeAdapter: Load RISC code failed	FC	Fatal	Fibre Channel processor firmware load failed.
102658	##d: QLInitializeAdapter: Load ISP2322 receive sequencer code failed	FC	Fatal	Fibre Channel processor receive sequencer code load failed.
102659	##d: QLInitializeAdapter: Load ISP2322 transmit sequencer code failed	FC	Fatal	Fibre Channel processor transmit sequencer code load failed.
102662	##d: QLInitializeAdapter: Verify Checksum command failed (%x)	FC	Fatal	Fibre Channel processor firmware checksum failed.
102680	##d: QLInitializeFW: FAILED	FC	Fatal	Fibre Channel processor firmware initialization failed.
102688	##d: QLInterruptServiceRoutine: Risc pause %x with parity error hccr %x, Disable adapter	FC	Fatal	Fibre Channel processor paused due to internal parity error.
102689	##d: QLInterruptServiceRoutine: Invalid interrupt status: %x	FC	Fatal	Fibre Channel processor returned an invalid interrupt status.
102716	##d: QLIsrEventHandler: System error event (%x), MB1=%x, MB2=%x, MB3=%x, MB4=%x, MB5=%x, MB6=%x, MB7=%x	FC	Fatal	Fibre Channel processor system error.
102746	##d: QLProcessResponseQueue: Invalid handle %x, type %x	FC	Fatal	Response queue entry contains an invalid handle.
102752	##d: QLTimer: Ext Ram parity error exceed limit cnt 0x%x, limit 0x%x, Disabled adapter	FC	Fatal	Fibre Channel processor external SRAM parity error count exceeded limit; Fibre Channel port disabled.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
102755	##d: QLTimer: Heartbeat failed	FC	Fatal	Fibre Channel processor heartbeat failed.
102800	##d: QLRestartRisc: restart RISC	FC	Fatal	Fibre Channel processor being restarted.
106583	##d: QLUtmReceiveIo: Path invalid/FW No resource count %x	FC	Error	The Fibre Channel processor received a SCSI command for an unknown target path or has run out of resources to execute additional commands.
106589	##d: QLIoctlEnable: Adapter disabled	FC	Error	The Fibre Channel processor was disabled by an IOCTL request to the driver.
106590	##d: QLIoctlEnable: Initialize FW error	FC	Error	The Fibre Channel processor firmware failed initialization. The request to initialize was received by the driver in an IOCTL request.
106592	##d: QLIoctlRunDiag: Diagnostic loopback command failed %x % %x %x	FC	Error	The Fibre Channel processor failed the external loopback test.
106593	##d: QLIoctlDisable: Re-initialize adapter failed	FC	Error	The Fibre Channel processor failed to re-initialize in response to an IOCTL disable request.
106803	##d: QLIsrEventHandler: Link down (%x)	FC	Error	The Fibre Channel processor reported a link down condition.
106813	##d: QLIsrEventHandler: Unexpected async event (%x), MB1=%x, MB2=%x, MB3=%x, MB4=%x, MB5=%x, MB6=%x, MB7=%x	FC	Error	The Fibre Channel processor reported an unexpected asynchronous event. The mailbox registers provide status, event code, and data related to the event.
106847	##d: QLProcessResponseQueue: Invalid EntryStatus %x, type %x	FC	Error	The Fibre Channel controller reported an invalid Entry Status %x, type %x.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
106851	##d: QLTimer: Heartbeat failed	FC	Error	The Fibre Channel controller failed to provide a heartbeat.
106853	##d: QLTimer: Link error count (0x%x) exceeded, link down	FC	Error	The driver has determined that the Fibre Channel link is unreliable and unusable due to the number of errors encountered. The link has been taken down.
106912	##d: QLReserveLoopId: out of loop Ids	FC	Error	The Fibre Channel processor was unable to obtain the number of loop IDs required. This failure occurs only when the Fibre Channel processor is running multi-ID firmware.
106928	##d: QLMarkDeviceOffline: Device Id: %x marked offline, cLinkDownTimeout = %x, cPortDownRetryCount=%x	FC	Error	The driver was unable to re-establish connection to the target within the timeout and retry counts, and is therefore marking it <i>offline</i> .
106948	##d: QLSnsGetAllNext: Name server login FAILED %x	FC	Error	The Fibre Channel processor is unable to log into the Fibre Channel fabric name server.
107029	##d: QLUpdateDeviceData: out of slots in host database	FC	Error	The driver's host (initiator) database is full.
107030	##d: QLUpdateDeviceData: out of slots in target database	FC	Error	The driver's target database is full.
107041	##d: QLUpdateDeviceDatabase 0x%x: GET_ID failed %x	FC	Error	The driver's host (initiator) database is full. Maximum host database is 64.
107056	##d: QLUpdateDeviceDatabase 0x%x: out of slots in host database	FC	Error	The drivers host (initiator) database is full.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
107078	##d: QLUpdatePort 0x%x: out of slots in host database	FC	Error	The driver was unable to re-establish connection to the target within the timeout and retry counts, and is therefore marking it <i>offline</i> .
107984	##d: QLWriteFlashDword: Write fails at addr 0x%x data 0x%x	FC	Error	The Fibre Channel controller failed a Flash write (address x data x).
108032	##d: QLGetVpDatabase: MBOX_CMD_GET_VP_DATABASE for VP %d fatal error	FC	Error	The Fibre Channel controller failed the Get VP Database command (for virtual port %d).
108033	##d: QLGetVpDatabase: MBOX_CMD_GET_VP_DATABASE for VP %d failed %x	FC	Error	The Fibre Channel controller failed the Get VP Database command (for virtual port %d) with status x.
108049	##d: QLVerifyMenloFw: EXECUTE_COMMAND_IOCTL failed MB0 %x MB1 %x	FC	Error	The Fibre Channel controller reported failure status for an Execute IOCB (input/output control block) command.
108050	##d: QLVerifyMenloFw: EXECUTE_COMMAND_IOCTL fatal error	FC	Error	The Fibre Channel controller reported a fatal error while processing an Execute IOCB command.
108064	##d: QLGetFwState: Get Firmware State failed 0-3 %x %x %x %x	FC	Error	The Fibre Channel controller reported failure status for a Get Firmware State command.
118882	##d: QLIoctlDisable: Reset adapter	FC	Info	Request to reset the Fibre Channel processor (adapter) received from IOCTL interface.
119088	##d: QLIsrEventHandler: LIP occurred (%x): mailbox1 = %x	FC	Info	Fibre Channel loop initialization process (LIP) occurred. The LIP type is reported, as is the contents of the Fibre Channel processor's mailbox 1 register.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
119089	##d: QLIsrEventHandler: LIP reset occurred (%x): mailbox1 = %x	FC	Info	Fibre Channel LIP reset occurred. The LIP reset type is reported, as is the contents of the Fibre Channel processor's mailbox 1 register.
119090	##d: QLIsrEventHandler: Link up (%x) mailbox1 = %x	FC	Info	Fibre Channel link up occurred. Event status is reported, as is the contents of the Fibre Channel processor's mailbox 1 register.
119092	##d: QLIsrEventHandler: Link mode up (%x): RunTimeMode=%x	FC	Info	Fibre Channel link up occurred. Event status is reported, as is the RunTimeMode (0 = loop, 1 = point-to-point).
119093	##d: QLIsrEventHandler: RSCN update (%x) rscnInfo: %x	FC	Info	An RSCN was received. Event status is reported, as is the RSCN information.
119097	##d: QLIsrEventHandler: Port update (%x) mbl-3 %x %x %x	FC	Info	Fibre Channel port update. Event status is reported, as is the contents of the Fibre Channel processor's mailbox 1, 2, and 3 registers.
119144	##d: QLTimer: VP %d discover a reject device PID %02x%02x%02x	FC	Info	A virtual port logged into a device, but the device rejects the login.
120278	##d: QLFlashGetNvram: Invalid Serial Link Control 0x%x for port %d	FC	Info	Update NVRAM for the invalid Serial Link Control for mezzanine platform.
120373	##d: QLIsrEventHandler: DCBX Completed (%x)	FC	Info	For FCoE protocol, the data center bridging exchange (DCBX) protocol completes.
120374	##d: QLIsrEventHandler: IDC Completion (%x) %x, %x, %x, %x, %x, %x, %x	FC	Info	For FCoE protocol, the inter-driver communications (IDC) completes.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
120375	##d: QLIsrEventHandler: IDC Notification (%x), %x, %x, %x, %x, %x, %x, %x	FC	Info	For FCoE protocol, the IDC notification comes from another driver.
120376	##d: QLIsrEventHandler: IDC Time Extended (%x), %x, %x, %x, %x, %x, %x, %x	FC	Info	For FCoE protocol, the IDC time extended notification receives.
120377	##d: QLIsrEventHandler: DCBX Started (%x)	FC	Info	For FCoE protocol, the DCBX protocol has started.
120378	##d: QLIsrEventHandler: FCF Config Error (%x), MBl=%x	FC	Info	For FCoE protocol, the FCoE Forwarder (FCF) configuration error occurred.
120379	##d: QLIsrEventHandler: DCBX Parameter Changed (%x)	FC	Info	For FCoE protocol, the DCBX parameters are changed.
139265	QBRPC_Initialize: Entered	User	Error	RPC (remote procedure call) server initialization entry point.
139266	QBRPC_Initialize:GetBridge Mem Allocation error	User	Error	Get System API memory allocation failed.
139267	QBRPC_Initialize:GetBridgeAdv Mem Allocation error	User	Error	Get System Advanced API memory allocation failed.
139268	QBRPC_Initialize:GetMgmt Mem Allocation error	User	Error	Get Management API memory allocation failed.
139269	QBRPC_Initialize:GetIscsi Mem Allocation error	User	Error	Get iSCSI API memory allocation failed.
139270	QBRPC_Initialize:GetIscsiAdv Mem Allocation error	User	Error	Get iSCSI advanced API memory allocation failed.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
139271	QBRPC_Initialize:GetIsns Mem Allocation error	User	Error	Get iSNS API memory allocation failed.
139272	QBRPC_Initialize:GetFcIntfc Mem Allocation error	User	Error	Get Fibre Channel Interface API memory allocation failed.
139273	QBRPC_Initialize:GetFcAdv Mem Allocation error	User	Error	Get Fibre Channel Advanced API memory allocation failed.
139280	QBRPC_Initialize:GetFcSfp Mem Allocation error	User	Error	Failed memory allocation for Get Fibre Channel SFP API.
139281	QBRPC_Initialize:GetLog Mem Allocation error	User	Error	Failed memory allocation for Get Log API.
139282	QBRPC_Initialize:GetStats Mem Allocation error	User	Error	Failed memory allocation for Get Statistics API.
139283	QBRPC_Initialize:InitListMem Allocation error	User	Error	Failed memory allocation for Get Initiator List API.
139284	QBRPC_Initialize:TargetList Mem Allocation error	User	Error	Failed memory allocation for Get Target List API.
139285	QBRPC_Initialize:LunList MemAllocation error	User	Error	Failed memory allocation for Get LUN List API.
139286	QBRPC_Initialize:PresTarget Mem Allocation error	User	Error	Failed memory allocation for Get Presented Targets List API.
139287	QBRPC_Initialize:LunMask Mem Allocation error	User	Error	Failed memory allocation for Get LUN Mask API.



**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
139288	QBRPC_Initialize:Init Mem Allocation error	User	Error	Failed memory allocation for Initiator API.
139289	QBRPC_Initialize:TgtDevice Mem Allocation error	User	Error	Failed memory allocation for Target Device API.
139296	QBRPC_Initialize:FcTgt Mem Allocation error	User	Error	Failed memory allocation for Fibre Channel Target API.
139297	QBRPC_Initialize:BridgeStatus Mem Allocation error	User	Error	Failed memory allocation for System Status API.
139298	QBRPC_Initialize:Diag Mem Allocation error	User	Error	Failed memory allocation for Diagnostic API.
139299	QBRPC_Initialize:DiagLog Mem Allocation error	User	Error	Failed memory allocation for Diagnostic Log API.
139300	QBRPC_Initialize:FruImage Mem Allocation error	User	Error	Failed memory allocation for FRU Image API.
139301	QBRPC_Initialize:OemMfg Mem Allocation error	User	Error	Failed memory allocation for OEM Manufacturing API.
139302	QBRPC_Initialize:Status Mem Allocation error	User	Error	Failed memory allocation for Status API.
139303	QBRPC_Initialize:TcpIpStats Mem Allocation error	User	Error	Failed memory allocation for TCP/IP Statistics API.
139304	QBRPC_Initialize:NtpStats Mem Allocation error	User	Error	Failed memory allocation for NTP Status API.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
139305	QBRPC_Initialize:LunList MemAlloc error	User	Error	Failed memory allocation for LUN List API.
139315	QBRPC_FreeResources:Entered	User	Error	RPC free resources entry point.
139553	checkDuplicateIp: Detected Error %08x %08x%04x	User	Error	Detected duplicate IP address for management port.
139930	FcipRoute#%d Failed with Memory Allocation Error	User	Error	Memory resources could not be allocated to an FCIP route. The route was not created. The router must be rebooted to clear this error.
139931	FcipRoute#%d Failed with Invalid Arg Error	User	Error	Invalid argument specified by user. The preceding message in the log indicates which parameter is in error.
139932	FcipRoute#%d Failed with Unknown Device Error	User	Error	Specified route or port (Fibre Channel or Ethernet) does not exist. Verify that the value entered is a valid value.
139933	FcipRoute#%d Failed with Kernel Error	User	Error	Invalid memory address was encountered while reading/writing or modifying FCIP route definition. Reboot the router.
139934	FcipRoute#%d Failed with Network Configuration Error	User	Error	Network device configuration failed; could not add or remove a network device instance. Verify the IP addresses, mask, gateway, and Ethernet port specified in the route definition
139935	FcipRoute#%d Failed with Persistence Read Failure	User	Error	Read of FCIP Route definition from persistent memory failed. Reboot the router

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
139936	FcipRoute#%d Failed with Persistence Write Failure	User	Error	Write of FCIP route definition to persistent memory failed. Retry the route add or modify if the retry failed reboot the router.
139937	FcipRoute#%d Failed with IP Address Reuse Error	User	Error	Specified IP address is already in use in another FCIP route definition. Verify that the address specified in the definition is correct. If you want to reuse the address, you must first remove it from the other route definition.
139938	FcipRoute#%d Add Failed because relevant FCIP Licence not available	User	Error	Router is not licensed for FCIP. Contact your sales representative for information on how to obtain a license
151842	FW Upgrade performed: new version is: %d.%d.%d.%d	User	Info	A firmware upgrade was performed, the new version is: <i>d.d.d.d</i> .
151843	REBOOT/SHUTDOWN Command from user. Code=%d	User	Info	User issued a REBOOT or SHUTDOWN command.
151889	#%d: qapisetfcinterfaceparams_1_svc: FC port configuration changed	User	Info	The Fibre Channel port configuration has changed.
151890	#%d: qapisetiscsiinterfaceparams_1_svc: iSCSI port configuration changed	User	Info	The iSCSI port configuration has changed.
151891	#%d: qapisetisns_1_svc: iSNS configuration changed	User	Info	The iSNS configuration has changed.
151892	qapisetntpparams_1_svc: NTP configuration changed	User	Info	The NTP configuration has changed.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
151893	#%d: qapisetvlanparams_1_svc: VLAN configuration changed	User	Info	The VLAN configuration has changed.
151894	qapisetlunmask_1_svc: Lunmask added for LUN %d	User	Info	A LUN mask was added for LUN %d.
151895	qapisetlunmask_1_svc: Lunmask removed for LUN %d	User	Info	The LUN mask was removed for LUN %d.
151896	qapisetmgmintfcparams_1_svc: Management port configuration changed	User	Info	The management port configuration has changed.
151897	qapisetbridgebasicinfo_1_svc: Bridge configuration changed	User	Info	The router configuration has changed.
151908	GE%d: Port status changed by user to ENABLED.	User	Info	GE port %d was enabled user.
151909	GE%d: Port status changed by user to DISABLED.	User	Info	GE port %d was disabled by user.
151910	FC%d: Port status changed by user to ENABLED.	User	Info	Fibre Channel port %d was enabled by user.
151911	FC%d: Port status changed by user to DISABLED.	User	Info	Fibre Channel port %d was disabled by the user.
151912	qapimaptargetdevice_1_svc: Target WWPN: %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x mapped to iSCSI portal %d.	User	Info	The target at WWPN: xx.xx.xx.xx.xx.xx.xx.xx has been mapped to iSCSI portal %d.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
151913	qapimaptargetdevice_1_svc: Target WWPN: %.2x%.2x%.2x%.2x%.2x%.2x%.2x%.2x unmapped from iSCSI portal %d.	User	Info	The target at WWPN: xx.xx.xx.xx.xx.xx.xx.xx has been unmapped from iSCSI portal %d
152082	qapiaddmodifyinitiator_1_svc : Initiator Configuration Changed	User	Info	An initiator's configuration has changed.
152083	qapiremoveinitiator_1_svc : Initiator Removed	User	Info	An initiator has been removed.
152096	qapisetmigrfctargets_1_svc: Configuration Changed for migration target	User	Info	A set array was done on one of the arrays.
152099	LogMigration: Error in Writting log file	User	Info	Encountered an error while updating the migration log entry. Some migration log entries might be missing.
152100	qapiaddgroup_1_svc: Added Group with id %d	User	Info	Group with ID specified in the log was added.
152101	qapiremovegroup_1_svc: Removed Group with id %d	User	Info	Group with ID specified in the log was removed.
152102	qapiupdategroup_1_svc: Updated Group with id %d	User	Info	Group with ID specified in the log was updated.
152103	qapisetserialjobs_1_svc: Serial Time %lu	User	Info	Serial schedule jobs scheduled to start at time specified in the log.
152104	qapiadjustpriority_1_svc: Readjust Priority Failed on line %d with error %d	User	Info	Readjust priority command completed with an error. Error code 2 indicates no scheduled jobs were found. Error code 16 indicates a job with priority 1 configured.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
152105	qapireadjustpriority_1_svc: Readjust Priority Done	User	Info	Completed readjusting the serial schedule priority of migration jobs.
152106	qapiupdatemigration_1_svc: Update Migration returned with error %d	User	Info	An update migration action [Start, Stop, Pause, or Resume] has failed.
152107	RemoveMigration:%d with Job Id %d and error = %d	User	Info	Failed to remove a migration job with ID specified in the log.
152108	ValidateSerialSchedule: Previous time %ld New time %ld	User	Info	Reset the serial schedule delayed time to invalid if the last serial schedule job was removed.
152109	addMigration: Creating migration Job Failed with error %d	User	Info	Failed to create a migration job.
152129	sysTempMon: Left PCM Installed	User	Info	The left PCM is or has been installed.
152130	sysTempMon: Left PCM Un-installed	User	Info	The left PCM is or has been uninstalled.
152131	sysTempMon: Right PCM Installed	User	Info	The right PCM is or has been installed.
152132	sysTempMon: Right PCM Un-installed	User	Info	The right PCM is or has been uninstalled.
152133	sysTempMon: Power for Left PCM Plugged-in	User	Info	The left PCM is connected AC power.
152134	sysTempMon: Power for Left PCM Un-plugged	User	Info	The left PCM is not connected to AC power (unplugged).
152135	sysTempMon: Power for Right PCM Plugged-in	User	Info	The right PCM is connected AC power.
152136	sysTempMon: Power for Right PCM Un-plugged	User	Info	The right PCM is not connected to AC power (unplugged).

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
152137	sysTempMon: Slot 1 (R1) PCM Fan%d faulty	User	Info	The left PCM (#1) is reporting a faulty fan.
152138	sysTempMon: Slot 2 (R2) PCM Fan%d faulty	User	Info	The left PCM (#1) is reporting a healthy fan.
152139	sysTempMon: Slot 1 (R1) PCM Fan%d healthy	User	Info	The right PCM (#2) is reporting a faulty fan.
152140	sysTempMon: Slot 2 (R2) PCM Fan%d healthy	User	Info	The right PCM (#2) is reporting a healthy fan.
152141	sysTempMon: Over Temperature Front: %dC Rear: %dC CPU1: %dC CPU2: %dC	User	Info	The router has detected an over-temperature, Front: %dC Rear: %dC CPU1: %dC CPU2: %dC
152142	sysTempMon: Setting the fan speed to high	User	Info	The fan(s) speed has been set to high.
152143	sysTempMon: Setting the fan speed to normal	User	Info	The fan(s) speed has been set to normal.
152144	sysTempMon: Temperature back to safe value. Front: %dC Rear: %dC CPU1: %dC CPU2: %dC	User	Info	The router temperature has returned to normal operating range, Front: %dC Rear: %dC CPU1: %dC CPU2: %dC
152145	sysTempMon: Critical Temperature, Shutting Down Front: %dC Rear: %dC CPU1: %dC CPU2: %dC	User	Info	The router has reached a critical temperature and is shutting down, Front: %dC Rear: %dC CPU1: %dC CPU2: %dC
172040	FcipRoute#%d: Cleaning FCIP Instance	FCIP	Error	This is an informative message, not an error. This indicates an FCIP was removed or modified.
172231	FcipRoute#%d: Did not get the keepalive msg from remote peer	FCIP	Error	Connectivity with the remote peer has been interrupted check the Ethernet cabling and path to the remote peer.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
172238	FcipRoute#%d: Synchronization Error on Receive	FCIP	Error	Indicates an error in the received FCIP PDU framing; router will disconnect and reconnect with remote router to clear the error.
172239	FcipRoute#%d: Decompression Error on Receive	FCIP	Error	Indicates the receiver could not decompress a received FCIP frame. The router will disconnect and reconnect with the remote router to clear the error.
172240	FcipRoute#%d: De-encapsulation Error on Receive	FCIP	Error	Invalid FCIP header received. The header is invalid or improperly framed. The router will disconnect and reconnect with the remote router to clear the error.
172245	FcipRoute#%d: Transmit Failure	FCIP	Error	FCIP PDU transmit request was rejected, typically caused by the TCP connection closing when send was submitted. Can also be caused by lack of resources to accommodate the send (should never happen). If this persists and the TCP connection is up a reboot is required to clear the condition.
172246	FcipRoute#%d: Remote Peer Disconnected	FCIP	Error	The remote peer terminated the TCP connection via a FIN (finished) or RST (reset) flag. The router will attempt to restore the TCP connection.
172247	FcipRoute#%d: Failed to send FC Up/Down	FCIP	Error	Unable to notify the remote router that the local Fibre Channel link came up or went down. The TCP connection will be closed and the router will attempt to reconnect to the remote router.
172249	FcipRoute#%d: FCIP Link Down	FCIP	Error	The Fibre Channel link went down. Check the Fibre Channel cabling and Fibre Channel switch or drive statistics.



**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
172250	FcipRoute#%d: TCP Link Down	FCIP	Error	The TCP link went down. Check the Ethernet cabling and Ethernet switch or peer device statistics.
172253	FcipRoute#%d: Remote Peer IP Address Validation Failed	FCIP	Error	An TCP client attempted to connect to the router but the IP address did not match the address of the remote router specified in the route definition. Check the route definition; check for network rogues fishing for open TCP ports.
172272	FcipRoute#%d: Tcp Client's connect attempt failed	FCIP	Error	Router was not able to open a TCP connection with the remote router. Check the route definitions on each router; check the Ethernet cabling. Try to ping the remote router.
172273	FcipRoute#%d: Tcp Server's Listen attempt failed	FCIP	Error	TCP connection was closed before it was fully opened. Router will restart its listen socket.
184515	FcipRoute#%d: TCP Link Up	FCIP	Info	TCP connection was successfully established with remote router.
184536	FcipRoute#%d: FCIP Link Up	FCIP	Info	Local and remote Fibre Channel links are up.
184542	FcipRoute#%d: VLAN Info Unavailable	FCIP	Info	Route definition includes VLAN but the network VLAN device instance does not exist. This is an internal error. Try removing the route definition and re-enter the route definition.
200721	QL3022:ql3xxx_probe: Adapter eth#%d, Invalid NVRAM parameters	TOE	Fatal	A GE port (eth#%d) has invalid NVRAM parameters.

**Table C-1. iSR6200 Router Log Messages (Continued)**

ID	Log Message	Module Type	Msg. Type	Description
204835	QL3xxx:eth%x PHY Downshift occurred	TOE	Error	The Ethernet device could not successfully communicate with the link peer at the highest negotiated port rate. Check the Ethernet cabling and Ethernet switch statistics of the corresponding port.
204837	QL3xxx:eth%x Link Down	TOE	Error	The Ethernet link is down. Check the Ethernet cabling and Ethernet switch or remote peer statistics.
217124	QL3xxx:eth%x Link Up	TOE	Info	The Ethernet link is up.
233473	"memory monitor: Detected Uncorrectable Ecc %08lx system is rebooting in 5 secs\n"	System	Fatal	Uncorrectable memory error detected at address provided in log message.
233474	"Failed to register interrupt handler!\n"	System	Fatal	Attempt to register the interrupt handler failed.
233475	"%s class_simple_create failed\n"	System	Fatal	Failed class_simple_create system call from memory monitor initialization routine.
237572	"Failed to kill sys killer %d\n"	System	Error	Failed to kill system task.
237573	Temperature over high threshold %d	System	Error	The router temperature has exceeded the high temperature threshold.
249862	Temperature is back to normal range %d	System	Info	The router temperature has returned to the normal operating range.

# Glossary

## activity LED

A [port](#) LED that indicates when frames are entering or leaving the port.

## adapter

The board that interfaces between the host system and the target devices. Adapter is synonymous with *host bus adapter*, *host adapter*, and *adapter board*.

## adapter port

A port on the adapter board.

## adapter port beacon

An LED on the adapter. Flashing it enables you to locate the adapter.

## alarm

A message generated by the switch that specifically requests attention. Alarms are generated by several switch processes. Some alarms can be configured.

## arbitrated loop

A circular (ring) topology (versus point-to-point) where two or more [ports](#) can be interconnected, but only two ports can communicate at a time. All communication passes through all ports connected to the loop.

## ASIC

Application specific integrated circuit. A microchip designed for special applications such as Fibre Channel.

## bandwidth

A measure of the volume of data that can be transmitted at a specific transmission rate. A 2Gbps Fibre Channel [port](#) can transmit or receive at nominal rates of 2Gbps. This corresponds to actual bandwidth value of 212MB.

## boot code

The program that initializes a system or an adapter. Boot code is the first program to run when a system or a device within a system, such as an adapter, is powered on. FCode, BIOS, and EFI (enhanced firmware interface) are all forms of boot code for specific hardware/operating system environments.

## CHAP

Challenge-handshake authentication protocol. CHAP is used for remote logon, usually between a client and server or a Web browser and Web server. A challenge/response is a security mechanism for verifying the identity of a person or process without revealing a secret password that is shared by the two entities. Also referred to as a *three-way handshake*.

## CLI

Command line interface. Program interface driven by entering commands and parameters.

### comma separated values file

See [CSV file](#).

### command line interface

See [CLI](#).

### Converged Network Adapter

QLogic adapter that supports both data networking (TCP/IP) and storage networking (Fibre Channel) traffic on a single I/O adapter using two new technologies: [Enhanced Ethernet](#) and Fibre Channel over Ethernet ([FCoE](#)).

### CRC

Cyclic redundancy check. A type of check value designed to catch most transmission errors.

### CSV file

Comma separated values file. Each line in the file corresponds to a row in the table. Within a line, fields are separated by commas, each field belonging to one table column.

### cyclic redundancy check

See [CRC](#).

### device

A [target](#), typically a disk drive. Hardware such as a disk drive, tape drive, printer, or keyboard that is installed in or connected to a system. In Fibre Channel, a *target* device.

### DHCP

Dynamic host configuration protocol (DHCP) enables computers on an IP network to extract their configuration from servers that have information about the computer only after it is requested.

### driver

The software that interfaces between the file system and a physical data storage device or network media.

### DS-1

Digital signal 1 (DS-1, also known as T1 and DS1) is a T-carrier signaling scheme that is a widely-used standard in telecommunications to transmit voice and data between devices. Technically, DS1 is the logical bit pattern used over a physical T1 line; however, the terms *DS1* and *T1* are often used interchangeably.

### DS-3

Digital signal 3 (DS-3) is a digital signal level 3 T-carrier. It may also be referred to as a *T3 line*.

### dynamic host configuration protocol

See [DHCP](#).

### E\_Port

Expansion port. A [port](#) in a Fibre Channel switch that connects to another Fibre Channel switch or bridge device by an inter-switch link. E\_Ports are used to link Fibre Channel switches to form a multi-switch [fabric](#).

### EEPROM

Electrically erasable programmable read-only memory. Memory that can be erased (entirely, not selectively) using higher electrical voltages.

### Enhanced Ethernet

Also called *data center Ethernet* or *converged enhanced Ethernet*. Refers to new enhancements to the existing Ethernet standard that eliminate Ethernet's inherently lossy nature and make 10Gb Ethernet a viable storage networking transport.

## **F\_Port**

The *fabric* port in a Fibre Channel fabric switch provides a point-to-point link attachment to a single [N\\_Port](#). F\_Ports are intermediate ports in virtual point-to-point links between end ports, for example N\_Port to F\_Port to F\_Port to N\_Port using a single Fibre Channel fabric switch.

## **fabric**

A fabric consists of cross-connected Fibre Channel devices and switches.

## **fabric port**

See [F\\_Port](#).

## **fabric switch**

Also, switched fabric. A fabric switch connects multiple devices from independent Fibre Channel-arbitrated loops (FC-ALs) and point-to-point topologies into a fabric using Fibre Channel switches.

## **failover path**

Software feature that ensures data availability and system reliability by assigning alternate path and automatic [adapter](#) failover for device resources. This feature is available only in Windows 2000/Windows Server 2003/Windows Vista, Novell NetWare, and Red Hat/SUSE Linux. (Windows XP and Windows Server 2008 do *not* support failover.)

## **FC**

See [Fibre Channel](#).

## **FC-IP mode**

Data transportation mode in which the iSR6200 transports Fibre Channel frames over a TCP/IP connection using the [FCIP](#) protocol to connect two iSR6200 routers. In FC-IP mode, a port pair (one Fibre Channel port and an IP port on the same router) on local iSR6200 and another port pair on a remote router form an FCIP route.

## **FCIP**

Fibre Channel over IP. Protocol that enables transmission of Fibre Channel information by tunneling data on a [SAN](#) over IP networks. An alternative to [iSCSI](#). Also known as Fibre Channel tunneling.

## **FCoE**

Fibre Channel over Ethernet. A new technology defined by the T11 standards body that allows traditional Fibre Channel storage networking traffic to travel over an Ethernet link by encapsulating Fibre Channel frames inside Layer 2 Ethernet frames. For more information, visit [www.fcoe.com](http://www.fcoe.com).

## **Fibre Channel**

A high-speed serial interface technology that supports other higher layer protocols such as [SCSI](#) and [IP](#).

## **field replaceable unit**

See [FRU](#).

**FL\_Port**

Fabric loop port. In a Fibre Channel, the [fabric switch](#) is capable of Fibre Channel arbitrated loop operations and is connected to one or more [NL\\_Ports](#) by a Fibre Channel Arbitrated Loop. An FL\_Port becomes a shared entry point for public NL\_Port devices to a Fibre Channel fabric. FL\_Ports are intermediate ports in virtual point-to-point links between end ports that do not reside on the same loop, for example NL\_Port to FL\_Port to F\_Port to N\_Port through a single Fibre Channel fabric switch.

**Flash**

Non-volatile memory where the boot code is saved. At times, Flash and [boot code](#) are used interchangeably.

**frame**

Data unit consisting of a start-of-frame (SOF) delimiter, header, data payload, CRC, and an end-of-frame (EOF) delimiter.

**FRU**

Field replaceable unit. Component that can be replaced in the field upon failure.

**G\_Port**

Generic port. A port that can operate as either an E\_Port or an F\_Port. A G\_Port can determine operating mode at switch port initialization, F\_Port when an N\_Port attachment is determined, E\_Port when an E\_Port attachment is determined. See [E\\_Port](#), [F\\_Port](#), [FL\\_Port](#), [L\\_Port](#), [N\\_Port](#), [NL\\_Port](#).

**GBIC**

Gigabit interface converter. Removable transceiver module that permits Fibre Channel and Ethernet physical layer transport.

**Gbps**

Gigabits per second. A measure of data transfer rates.

**gigabit interface converter**

See [GBIC](#).

**HA**

High availability. HA refers to a system or device that operates continuously for a long length of time.

**Host Bus Adapter**

See [adapter](#).

**heartbeat LED**

A chassis LED that indicates the router status.

**high availability**

See [HA](#).

**hot replaceable**

Also known as *hot swappable*, this means you can add new devices or remove existing ones when the system is running.

**IANA**

Internet Assigned Numbers Authority (IANA) is responsible for the global coordination of the DNS Root, IP addressing, and other Internet protocol resources.

**initiator**

System component, such as a network interface card, that originates an I/O operation.

**ioctl**

Input/output control. A system call in UNIX®/Linux systems that allows an application to control or communicate with a device driver outside usual read/write operations.

**IP**

Internet Protocol. A method by which data is sent from one computer to another over the Internet. IP specifies the format of packets, also called *datagrams*, and the addressing scheme.

**iSCSI**

Internet small computer system interface. Protocol that encapsulates data into IP packets to send over Ethernet connections.

**iSNS**

Internet simple name service (iSNS) is used for discovery and management of IP-based SANs.

**L\_Port**

Loop port. Does arbitrated loop functions and protocols. NL\_Ports and FL\_Ports are examples of loop-capable ports. See [E\\_Port](#), [F\\_Port](#), [FL\\_Port](#), [G\\_Port](#), [N\\_Port](#), [NL\\_Port](#).

**latency**

A measure of how fast a transaction travels through the router.

**LED**

Light emitting diode. Status indicator on a switch or other device.

**light emitting diode**

See [LED](#).

**LIP**

Loop initialization process. The initialization process in an arbitrated loop that occurs when the loop is powered up or a new device is added. One function of a LIP is to assign addresses. All data transmission on the loop is suspended during a LIP.

**load balancing**

A software feature that improves system performance by balancing device access between multiple ports for maximum resource efficiency.

**logical unit number**

See [LUN](#).

**loop initialization process**

See [LIP](#).

**loopback**

Diagnostic tool that routes transmit data through a loopback connector back to the same adapter.

**LUN**

Logical unit number, a subdivision of a SCSI target. It is the small integer handle that differentiates an individual disk drive or partition (volume) within a common SCSI target device such as a disk array.

Technically, a LUN can be a single physical disk drive, multiple physical disk drives, or a portion (volume) of a single physical disk drive. However, LUNs are typically not entire disk drives but rather virtual partitions (volumes) of a RAID set.

Using LUNs, the Fibre Channel host can address multiple peripheral devices that may share a common controller.

**maintenance button**

Multifunction momentary switch on the front panel of the router.

**management workstation**

PC workstation used to manage routers remotely by connecting to the routers using SANsurfer Router Manager or CLI commands.

**maximum transmission unit**

See [MTU](#).

**Mbps**

Megabits (millions of bits) per second. A measure of data transfer rates.

**media**

Physical-layer information carriers. Fibre Channel supports several different physical media: copper, multimode optical, and single-mode optical. All Fibre Channel protocols are supported on all media.

**MIB**

Management information base. A set of guidelines and definitions for SNMP functions.

**mid-plane**

Located inside the iSR6200 chassis between the blades and their corresponding [PCMs](#), the mid-plane connects the removable power supply and the iSR6200 blades.

**MTU**

Maximum transmission unit. Refers to the size (in bytes) of the largest packet ((IP datagram) that a specific layer of communications protocol can transfer.

**N\_Port**

Node port. Connects by a point-to-point link to either a single N\_Port or a single [F\\_Port](#). N\_Ports handle creation, detection, and flow of message units to and from the connected systems. N\_Ports are end ports in virtual point-to-point links through a fabric, for example N\_Port to F\_Port to F\_Port to N\_Port using a single Fibre Channel fabric switch. See also [Fibre Channel](#).

**network time protocol**

See [NTP](#).

**NIC**

Network interface card. Computer card installed to enable a dedicated network connection.

**NL\_Port**

Node loop port. A port capable of arbitrated loop functions and protocols. An NL\_Port connects through an arbitrated loop to other NL\_Port and at most a single FL\_Port. NL\_Ports handle creation, detection, and flow of message units to and from the connected systems. NL\_Ports are end ports in virtual point-to-point links through a fabric, for example NL\_Port to F\_Port to F\_Port to N\_Port using a single Fibre Channel fabric switch. In the absence of a fabric switch FL\_Port, NL\_Ports can communicate with other NL\_Ports in virtual point-to-point links through an FC\_AL open loop circuit often through FC\_AL (Arbitrated Loop) hub or loop switch devices. See: [E\\_Port](#), [F\\_Port](#), [FL\\_Port](#), [G\\_Port](#), [N\\_Port](#).

**non-volatile random access memory**

See [NVRAM](#).

**NTP**

Network time protocol. NTP is used for distributing the Coordinated Universal Time (UTC) by means of synchronizing the clocks of computer systems over packet-switched, variable-latency data networks.

**NVRAM**

Non-volatile random access memory. NVRAM is a type of memory that retains data (including configuration settings) even when power is removed. You can configure NVRAM settings manually or restore them from a file.



## OC

Optical carrier is a standardized set of specifications of transmission speeds that describe a range of digital signals that can be carried on synchronous optical networking (SONET) fiber optic networks. The number attached to the optical carrier abbreviation, OC-12, is directly proportional to the data rate of the bitstream of the digital signal.

## path

A path to a device is a combination of an adapter [port instance](#) and a target port as distinct from internal paths in the fabric network. A fabric network appears to the operating system as an opaque network between the adapter (initiator) and the target.

Because a path is a combination of an adapter and a target port, it is distinct from another path if it is accessed through a different adapter and/or it is accessing a different target port. Consequently, when switching from one path to another, the driver might be selecting a different adapter (initiator), a different target port, or both.

This is important to the driver when selecting the proper method of failover notification. It can make a difference to the target device, which might have to take different actions when receiving retries of the request from another initiator or on a different port.

## PCI

Peripheral component interface/interconnect. A 32-bit local bus specification introduced by Intel.

## PCM

Power and cooling module. A device that consists of one power supply and three fans.

## PID

Process identifier. A number used by some operating system kernels (such as that of UNIX, Mac OS X or Windows NT) to uniquely identify a process.

## ping

A computer network administration utility used to test whether a specified host is reachable across an IP network and to measure the round-trip time for packets sent from the local host to a destination computer.

## point-to-point

Also FC-P2P. Two Fibre Channel nodes directly connected (not in a loop).

## port

Access points in a device where a link attaches. There are four types of ports, as follows:

- [N\\_Port](#)—a Fibre Channel port that supports point-to-point topology.
- [NL\\_Port](#)—a Fibre Channel port that supports loop topology.
- [Fibre Channel](#)—a port in a fabric where an N\_Port can attach.
- [Fibre Channel](#)—a port in a fabric where an NL\_Port can attach.

## port instance

The number of the port in the system. Each adapter may have one or multiple ports, identified with regard to the adapter as port 0, port 1 and so forth. To avoid confusion when dealing with a system containing numerous ports, each port is assigned a port instance number when the system boots up. So Port 0 on an adapter might have a port instance number of 8, for example, if it is the eighth port discovered by the system.

## **POST**

Power-on self test. Diagnostics that the router performs at start-up.

## **reduced instruction set computer**

See [RISC](#).

## **registered state change notification**

See [RSCN](#).

## **RISC**

Reduced instruction set computer. A computer microprocessor that performs fewer types of computer instructions, thereby operating at higher speeds.

## **RSCN**

Registered state change notification. RSCN is a Fibre Channel fabric notification sent to all specified nodes when any major fabric changes occur. This notification allows nodes to immediately gain knowledge about the fabric and react accordingly.

## **router log**

Log of messages describing events that occur on the intelligent Storage Router (iSR).

## **SAN**

Storage area network. Multiple storage units (disk drives) and servers connected by networking topology.

## **SANsurfer Router Manager**

Workstation-based router management utility that provides a graphical user interface (GUI) used to configure and monitor intelligent Storage Router (iSR)s.

## **SCSI**

Small computer system interface. A high-speed interface used to connect devices, such as hard drives, CD drives, printers, and scanners, to a computer. The SCSI can connect many devices using a single controller. Each device is accessed by an individual identification number on the SCSI controller bus.

## **Secure SHell**

See [SSH](#).

## **SFF**

Small form factor. A transceiver device that is permanently attached to the circuit board.

## **SFP**

Small form-factor pluggable. A transceiver device, smaller than a GigaBit Interface Converter, that plugs into the Fibre Channel port.

## **simple network management protocol**

See [SNMP](#).

## **small computer system interface**

See [SCSI](#).

## **small form factor**

See [SFF](#).

## **small form-factor pluggable**

See [SFP](#).

## **SMI-S**

Storage management initiative—specification. A standard that provides for the management of the switch through third-party management applications.

## **SNMP**

Simple network management protocol. SNMP is a networking protocol that enables you to monitor the router using third-party applications that use SNMP.

## **SSH**

Secure SHell. Communications tool that provides secure and encrypted connections to traditionally non-encrypted services.

## **storage area network**

See [SAN](#).

## **storage management initiative—specification**

See [SMI-S](#).

## **T1**

See [DS-1](#).

## **T3**

See [DS-3](#).

## **target**

The storage-device endpoint of a SCSI session. Initiators request data from targets. Targets are typically disk-drives, tape-drives, or other media devices. Typically a SCSI peripheral device is the target but an adapter may, in some cases, be a target. A target can contain many LUNs.

A target is a device that responds to a requested by an initiator (the host system). Peripherals are targets, but for some commands (for example, a SCSI COPY command), the peripheral may act as an initiator.

## **Telnet**

Telecommunication network. A network protocol used on the Internet or local area network (LAN) connections. Telnet provides access to a command line interface (CLI) on a remote machine.

## **virtual logical area network (LAN)**

See [VLAN](#).

## **virtual port group**

See [VPGs](#).

## **VLAN**

Virtual logical area network (LAN). A group of hosts with a common set of requirements that communicate as if they were attached to the same wire, regardless of their physical location. Although a VLAN has the same attributes as a physical LAN, it allows for end stations to be grouped together even if they are not located on the same LAN segment. VLANs enable network reconfiguration through software, instead of physically relocating devices.

## **VPGs**

Virtual port group. VPG is the iSR6200 software component used to create additional logical Fibre Channel adapter initiator ports on the fabric.

## **world wide node name**

See [WWNN](#).

## **world wide port name**

See [WWPN](#).

## **world wide unique LUN name**

See [WWULN](#).

## **WWNN**

World wide node name. Unique 64-bit address assigned to a device.

## **WWPN**

World wide port name. Unique 64-bit address assigned to each port on a device. One WWNN may contain multiple WWPN addresses.

## **WWULN**

World wide unique LUN name identifiers for SCSI devices are read from page 83 and page 80 of your SCSI block device as based on the SCSI standard. SANsurfer looks for identifiers in the order of: page 83 type 3, page 83 type 2, page 83 type 1, page 80, and lastly page 83 type 0.

# Index

## A

- AC power [3-7](#)
- activity LED
  - definition of [Glossary-1](#)
  - port data indicator [1-15](#), [1-16](#)
  - port indicator [1-15](#), [1-16](#)
- adapter
  - cable for router [3-2](#)
  - connecting to router [3-12](#)
  - heartbeat missed error [C-15](#)
  - login message [C-9](#)
  - port beacon, definition of [Glossary-1](#)
  - transmission speed compatibility with [2-1](#)
  - definition of [Glossary-1](#)
  - port, definition of [Glossary-1](#)
- address
  - identifier, FC port [B-8](#)
  - IP of port [B-5](#)
  - MAC, of port [B-6](#)
  - mode, port [B-5](#)
- agent
  - shutdown notification [B-20](#)
  - software version number [B-19](#)
  - startup notification [B-20](#)
- alarm, definition of [Glossary-1](#)
- application specific integrated circuit, See ASIC
- arbitrated loop, definition of [Glossary-1](#)
- arrays, configuring [4-12](#)
- ASIC, definition of [Glossary-1](#)
- audience [xi](#)
- authentication traps, enabling [B-2](#)

## B

- bandwidth
  - definition of [Glossary-1](#)
  - FCIP, configuring [5-6](#), [5-16](#)
- beacon indicator [1-10](#)
- BIOS, definition of [Glossary-2](#)
- blade, resetting [1-11](#)
- blink patterns
  - heartbeat [6-3](#)
  - IP address conflict [6-3](#)
  - LED [6-2](#)
  - over-temperature [6-4](#)
  - system error [6-3](#)
- boot code, definition of [Glossary-1](#)
- boot image, selecting [1-12](#)
- browsers, requirements [3-2](#)

## C

- card, expansion, options for [A-2](#)
- challenge-handshake authentication protocol, See CHAP
- CHAP
  - authentication error [C-4](#)
  - definition of [Glossary-1](#)
  - key error [C-4](#)
  - support for [A-4](#)
- chassis
  - diagnostics [6-1](#)
  - LEDs [1-9](#)
- checklist
  - installation [3-2](#)
  - pre-installation [3-3](#)
- CLI
  - definition of [Glossary-1](#)

installing firmware [3-18](#)  
 set vpgroups [4-5](#)  
 show vpgroups [4-2](#), [4-6](#)  
 CNA, See Converged Network Adapter  
 command line interface, See CLI  
 community  
     read, setting SNMP properties [B-2](#)  
     trap, setting SNMP properties [B-2](#)  
 compatibility with vendor fabrics [5-1](#)  
 compressing data, FCIP [5-16](#)  
 conditions, environmental [3-2](#)  
 configurations, expansion card [A-2](#)  
 configuring  
     FC arrays [4-12](#)  
     FC port for FCIP [5-5](#)  
     FCIP [5-2](#)  
     GE port for FCIP [5-5](#)  
     management workstation [3-11](#)  
     router [3-16](#)  
     SNMP parameters [B-2](#)  
     SNMP trap [B-3](#)  
     VPGs [4-2](#)  
 connecting  
     iSCSI hosts [4-16](#)  
     router to AC power [3-7](#)  
     workstation to router [3-10](#)  
 connectivity  
     remote SAN island [1-2](#)  
 conventions, documentation [xiii](#)  
 Converged Network Adapter, definition of [Glossary-2](#)  
 CRC  
     definition of [Glossary-2](#)  
 CSV file, definition of [Glossary-2](#)  
 cyclic redundancy check, See CRC

## D

data compression, FCIP [5-6](#), [5-16](#)  
 data migration, licensed feature [1-2](#)  
 data rate, WAN [5-12](#)  
 date, event [B-20](#)  
 definitions of terms [Glossary-1](#)

device  
     access to router [2-2](#)  
     definition of [Glossary-2](#)  
     discovery notification [B-21](#)  
     management [A-3](#)  
 DHCP  
     definition of [Glossary-2](#)  
     enabling for maintenance port [1-12](#)  
 diagnostics [6-1](#)  
     chassis [6-1](#)  
     POST [6-2](#)  
 discovered initiators [B-9](#)  
 discovering target devices [B-21](#)  
 documentation  
     conventions [xiii](#)  
     related materials [1-xii](#)  
 downloading  
     firmware [3-17](#)  
     SANsurfer Router Manager [3-13](#)  
 driver, definition of [Glossary-2](#)  
 DS-1  
     definition of [Glossary-2](#)  
     window size settings [5-17](#)  
 DS-3  
     definition of [Glossary-2](#)  
     window size settings [5-18](#)  
 DS-5, window size setting [5-18](#)  
 dynamic host configuration protocol, See DHCP

## E

E\_Port  
     definition of [Glossary-2](#)  
     extension, configuring FCIP [5-6](#)  
 EEPROM  
     definition of [Glossary-2](#)  
     updated message [C-17](#)  
 enabling  
     FCIP interfaces [5-5](#)  
     VPGs [4-2](#)  
 environmental  
     conditions [3-2](#)

specifications [A-4](#)  
Ethernet management port [1-15](#)  
Ethernet ports  
  LEDs [1-15](#)  
  showing [B-19](#)  
event description [B-20](#)  
event severity [B-20](#)  
expansion card configurations [A-2](#)

## F

F\_Port  
  definition of [Glossary-3](#)  
  extension, configuring FCIP [5-8](#)  
fabric port, definition of [Glossary-3](#)  
fabric switch, definition of [Glossary-3](#)  
fabric, compatibility with vendor [5-1](#)  
fabric, definition of [Glossary-3](#)  
factory, restoring defaults [1-12](#)  
failed blade  
  removing [7-2](#), [7-5](#)  
  replacing [7-3](#), [7-8](#)  
failed PCM, removing [7-11](#)  
failover path, definition of [Glossary-3](#)  
failure, recover from [2-8](#)  
FC (Fibre Channel), definition of [Glossary-3](#)  
FC array hosts, configuring [4-12](#)  
FC ports  
  down notification [B-21](#)  
  FCIP, configuring [5-5](#)  
  identifier [B-8](#)  
  index [B-8](#)  
  information about [B-7](#)  
  list of [B-7](#)  
  MIB port table [B-7](#)  
  number of [B-19](#)  
  role/mode [B-8](#)  
  table, MIB object group [B-7](#)  
  type of [B-9](#)  
  WWN of node [B-8](#)  
FCIP  
  attributes [5-1](#)  
  bandwidth [5-16](#)  
  configuring [5-2](#)  
  data compression [5-16](#)  
  definition of [Glossary-3](#)  
  E\_Port extension [5-6](#)  
  F\_Port extension [5-8](#)  
  interfaces, enabling [5-5](#)  
  link data rate [5-12](#)  
  link quality [5-12](#)  
  ports, unblocking in firewall [5-15](#)  
  pre-configuration information, obtaining [5-3](#)  
  round-trip time [5-11](#)  
  TCP window settings [5-17](#)  
  TCP window setup [5-22](#)  
FC-IP mode, definition of [Glossary-3](#)  
fciproute add command [5-4](#), [5-5](#)  
FCode, definition of [Glossary-3](#)  
FCoE, definition of [Glossary-3](#)  
features, licensed [1-2](#)  
features, performance [A-2](#)  
Fibre Channel  
  devices, distance between [2-2](#), [2-3](#)  
  ports, WWNN [B-8](#)  
Fibre Channel over IP, See FCIP  
FICON, support for [5-2](#)  
field replaceable unit, See FRU  
firewall, unblocking ports [5-15](#)  
firmware  
  downloading [3-17](#)  
  installing [3-17](#)  
  version number, showing [B-19](#)  
FL\_Port, definition of [Glossary-4](#)  
Flash  
  definition of [Glossary-4](#)  
  set command failed [C-14](#)  
  write error [C-21](#)  
frame, definition of [Glossary-4](#)  
FRUs  
  definition of [Glossary-4](#)  
  removing/replacing [7-1](#)  
FTP [2-9](#)

## G

G\_Port, definition of [Glossary-4](#)  
gateway IP address, FCIP, configuring [5-5](#)  
gateway, port [B-6](#)  
GBIC  
    cable devices, connecting [3-17](#)  
    definition of [Glossary-4](#)  
    transceivers for devices [2-1](#)  
Gbps, definition of [Glossary-4](#)  
GE ports  
    bandwidth, limiting [5-16](#)  
    FCIP, configuring [5-5](#)  
    showing [B-4](#), [B-19](#)  
    speed, FCIP [5-6](#)  
generic notifications [B-24](#)  
gigabit Ethernet ports  
    showing [B-4](#), [B-19](#)  
gigabit interface converter, See GBIC  
glossary of terms [Glossary-1](#)

## H

HA  
    definition of [Glossary-4](#)  
    specifications [A-4](#)  
hardware version, showing [B-19](#)  
heartbeat  
    blink pattern [6-3](#)  
    LED [1-9](#)  
    LED, definition of [Glossary-4](#)  
high availability, See HA  
hot replaceable/hot swappable, definition of [Glossary-4](#)

## I

I/O control block, definition of [Glossary-5](#)  
IANA  
    definition of [Glossary-4](#)  
    FC port types registry [B-9](#)  
index, VPGs [4-6](#)  
initiators

    definition of [Glossary-4](#)  
    mapping to target [1-3](#)  
    object table [B-9](#)  
    support, iSCSI [A-3](#)  
input/output control (ioctl), definition of [Glossary-4](#)  
installation checklist [3-2](#)  
installing  
    firmware upgrade [3-17](#)  
    SANsurfer Router Manager on Linux [3-15](#)  
    SANsurfer Router Manager on Mac OS X [3-15](#)  
    SANsurfer Router Manager on Windows [3-15](#)  
instance (port), definition of [Glossary-7](#)  
interface specifications [A-1](#)  
Internet Protocol, definition of [Glossary-5](#)  
IOCB  
    command failed to execute [C-21](#)  
    definition of [Glossary-5](#)  
ioctl  
    definition of [Glossary-4](#)  
    FC reset request from [C-21](#)  
IP address  
    conflict [6-3](#)  
    FCIP, configuring [5-5](#)  
    port [B-5](#)  
    port type [B-5](#)  
    resetting [1-12](#)  
    workstation [3-11](#)  
IP, definition of [Glossary-5](#)  
IPv4 port type [B-5](#)  
IPv6 port type [B-5](#)  
iSCSI  
    initiator support [A-3](#)  
    port LED [1-15](#)  
    definition of [Glossary-5](#)  
iSNS, definition of [Glossary-5](#)  
iSR6200 chassis blade  
    dual blade installation [7-2](#)  
    removing/replacing [7-1](#)  
    single-blade installation [7-4](#)  
iSR6200 router  
    device access to [2-2](#)



devices attached to [2-1](#)  
high availability [2-7](#)  
services for [2-8](#)  
software [2-7](#)

## K

key, license [1-2](#)

## L

L\_Port, definition of [Glossary-5](#)  
latency  
    round-trip, determining [1-3](#)  
latency, definition of [Glossary-5](#)  
LEDs  
    activity, definition of [Glossary-1](#)  
    beacon [1-10](#)  
    blink patterns [6-2](#)  
    chassis [1-9](#)  
    definition of [Glossary-5](#)  
    heartbeat [1-9](#)  
    heartbeat, definition of [Glossary-4](#)  
    input power [6-2](#)  
    iSCSI Ethernet port [1-15](#)  
    link status [1-15](#), [1-16](#)  
    port activity [1-15](#), [1-16](#)  
    power [1-10](#)  
    system fault [1-10](#), [6-2](#)  
licensed features, key [1-2](#)  
light emitting diode, See LEDs  
limiting bandwidth [5-16](#)  
link characteristics, WAN [5-10](#)  
link quality, FCIP [5-12](#)  
link rate  
    FCIP, configuring [5-12](#)  
    port [B-6](#), [B-9](#)  
link status, port [B-6](#), [B-9](#)  
Linux, installing SANsurfer Router Manager on  
    [3-15](#)  
LIP  
    definition of [Glossary-5](#)

    notification of [C-21](#)  
    reset type [C-22](#)  
load balancing, definition of [Glossary-5](#)  
log messages [C-1](#)  
logical unit number, See LUN  
loop (arbitrated), definition of [Glossary-1](#)  
loop initialization process, See LIP  
loop port (L\_Port), definition of [Glossary-5](#)  
loopback, definition of [Glossary-5](#)  
LUN  
    access [4-22](#)  
    assignments [4-12](#)  
    definition of [Glossary-5](#)  
    mapping [4-25](#)  
    tables [B-12](#)

## M

MAC address, port [B-6](#)  
Mac OS X, installing SANsurfer Router  
    Manager on [3-15](#)  
maintenance button  
    definition of [Glossary-5](#)  
    functions of [1-11](#)  
    locating [1-11](#)  
maintenance port, enabling DHCP [1-12](#)  
management  
    device [A-3](#)  
    port, showing [B-4](#)  
    tools [2-7](#)  
    workstation, definition of [Glossary-5](#)  
management information base, See MIB  
mapping  
    LUNs [4-25](#)  
    targets [B-22](#)  
maximum transmission unit, See MTU  
Mbps, definition of [Glossary-6](#)  
mechanical specifications [A-3](#)  
media, definition of [Glossary-6](#)  
MIB  
    definition of [Glossary-6](#)  
    object groups, FC port table [B-7](#)  
    object groups, network port table [B-4](#)

object groups, sensor table [B-16](#)  
 object groups, system information [B-18](#)  
 sensor table [B-16](#)  
 tables [B-3](#)  
 mid-plane, definition of [Glossary-6](#)  
 migration, data [1-2](#)  
 mounting the router [3-5](#)  
 MTU  
     definition of [Glossary-6](#)  
     FCIP, configuring [5-5](#)

## N

N\_Port (node port), definition of [Glossary-6](#)  
 network interface card, definition of [Glossary-6](#)  
 network port down notification [B-21](#)  
 network port table, MIB object group [B-4](#)  
 network time protocol, See NTP [Glossary-6](#)  
 NIC, definition of [Glossary-6](#)  
 NL\_Port, definition of [Glossary-6](#)  
 node  
     loop port, definition of [Glossary-6](#)  
     port (N\_Port), definition of [Glossary-6](#)  
 non-volatile random access memory, See NVRAM  
 notifications, SNMP [B-18](#)  
     agent shutdown [B-20](#)  
     agent startup [B-20](#)  
     FC port down [B-21](#)  
     generic [B-24](#)  
     network port down [B-21](#)  
     objects [B-20](#)  
     qsrAgentShutdown [B-20](#), [B-21](#)  
     qsrAgentStartup [B-20](#)  
     qsrDscTgtStatusChanged [B-21](#)  
     qsrEventTimeStamp [B-20](#)  
     qsrFcPortDown [B-21](#)  
     qsrGenericEvent [B-24](#)  
     qsrPresTgtMapped [B-22](#)  
     qsrSensorNotification [B-22](#)  
     qsrVPGroupStatusChanged [B-22](#)  
     sensor state [B-22](#)  
     target device discovery [B-21](#)

target presentation (mapping) [B-22](#)  
 virtual port groups (VPGs) [B-22](#)  
 NTP  
     definition of [Glossary-6](#)  
     router service [2-8](#)  
 NVRAM  
     definition of [Glossary-6](#)  
     iSCSI port contains invalid data [C-15](#)  
     iSCSI processor failed diagnostic [C-12](#)  
     iSCSI processor invalid [C-14](#)  
     reboot timer failed [C-12](#)

## O

object table, initiator [B-9](#)  
 objects  
     notification [B-20](#)  
     qsrAgentVersion [B-19](#)  
     qsrEventDescription [B-20](#)  
     qsrEventSeverity [B-20](#)  
     qsrHwVersion [B-19](#)  
     qsrNoOfFcPorts [B-19](#)  
     qsrNoOfGbEPorts [B-19](#)  
     qsrSerialNumber [B-19](#)  
     qsrSwVersion [B-19](#)  
     system information [B-18](#)  
 OC, definition of [Glossary-7](#)  
 OC-1, TCP window sizes [2-5](#)  
 OC-12  
     definition of [Glossary-7](#)  
     TCP windows sizes [2-6](#)  
 OC-3, TCP window sizes [2-6](#)  
 online/offline targets [B-21](#)  
 optical carrier, See OC

## P

parameters, SNMP [B-2](#)  
 password, SNMP default [B-2](#)  
 path, definition of [Glossary-7](#)  
 PCI  
     definition of [Glossary-7](#)

- device discovery [6-2](#)
  - error in target operation [C-3](#)
  - power state for critical temperature [1-6](#)
  - PCM
    - definition of [Glossary-7](#)
    - installing [7-12](#)
    - log messages for [C-30](#)
    - replacing [7-10](#)
    - sensor notifications [B-23](#)
  - performance features [A-2](#)
  - peripheral component interface/interconnect, See PCI
  - PID
    - definition of [Glossary-7](#)
    - login error [C-22](#)
  - ping
    - command, determining RTT [5-11](#)
    - definition of [Glossary-7](#)
    - support for [5-1](#)
  - point-to-point
    - definition of [Glossary-7](#)
    - link up type [C-22](#)
  - port down notification, network [B-21](#)
  - port instance, definition of [Glossary-7](#)
  - port table
    - FC [B-7](#)
    - network [B-4](#)
  - ports
    - 10Gb Ethernet [1-8](#)
    - 1Gb iSCSI [1-9](#)
    - definition of [Glossary-7](#)
    - address mode [B-5](#)
    - Ethernet management [1-15](#)
    - FC, down notification [B-21](#)
    - FC, identifier [B-8](#)
    - FC, index [B-8](#)
    - FC, list of [B-7](#)
    - FC, number of [B-19](#)
    - FC, role/mode [B-8](#)
    - FC, showing information for [B-7](#)
    - FC, type of [B-9](#)
    - FC, WWN of node [B-8](#)
    - Fibre Channel [1-7](#)
    - indexing [B-5](#)
    - IP address of [B-5](#)
    - IP address type [B-5](#)
    - IP address, gateway [B-6](#)
    - IP address, subnet mask [B-6](#)
    - LED, activity [1-15](#), [1-16](#)
    - LED, connection [1-15](#), [1-16](#)
    - link rate [B-6](#), [B-9](#)
    - link status [B-6](#), [B-9](#)
    - MAC address [B-6](#)
    - network, showing [B-4](#)
    - operational role [B-5](#)
    - serial [1-16](#)
    - unblocking in firewall [5-15](#)
  - POST
    - blade, replacing [7-9](#)
    - definition of [Glossary-8](#)
    - diagnostics [A-3](#)
    - diagnostics performed [6-2](#)
    - errors on system fault LED [1-10](#)
    - failed message [C-17](#)
    - router blade, resetting [1-11](#)
  - power and cooling module, See PCM
  - power requirements [3-2](#)
  - power-on self test (POST), definition of [Glossary-8](#)
  - pre-configuration, FCIP [5-3](#)
  - presenting targets [B-22](#)
  - process identifier, See PID
  - protocols, supported [A-4](#)
- ## Q
- qsrAgentShutdown notification [B-20](#)
  - qsrAgentStartup notification [B-20](#)
  - qsrAgentVersion object [B-19](#)
  - qsrDscTgtStatusChanged notification [B-21](#)
  - qsrEventDescription object [B-20](#)
  - qsrEventSeverity object [B-20](#)
  - qsrEventTimeStamp notification [B-20](#)
  - qsrFcLinkRate table [B-9](#)
  - qsrFcLinkStatus table [B-9](#)
  - qsrFcPortDown notification [B-21](#)
  - qsrFcPortEntry table [B-7](#)

[qsrFcPortId table B-8](#)  
[qsrFcPortIndex table B-8](#)  
[qsrFcPortNodeWwn table B-8](#)  
[qsrFcPortRole table B-8](#)  
[qsrFcPortTable table B-7](#)  
[qsrFcPortType table B-9](#)  
[qsrFcPortWwn table B-8](#)  
[qsrGateway table B-6](#)  
[qsrGenericEvent notification B-24](#)  
[qsrHwVersion object B-19](#)  
[qsrIPAddress table B-5](#)  
[qsrIPAddressType table B-5](#)  
[qsrIsInit table B-9](#)  
[qsrIsInitAddress table B-11](#)  
[qsrIsInitAddressType table B-11](#)  
[qsrIsInitAlias table B-10](#)  
[qsrIsInitChapEnabled table B-11](#)  
[qsrIsInitEntry table B-10](#)  
[qsrIsInitIndex table B-10](#)  
[qsrIsInitName table B-10](#)  
[qsrIsInitOsType table B-11](#)  
[qsrIsInitStatus table B-11](#)  
[qsrLowerThreshold table B-17](#)  
[qsrLunEntry table B-12](#)  
[qsrLunProdRevLevel table B-13](#)  
[qsrLunProductId table B-13](#)  
[qsrLunSize table B-13](#)  
[qsrLunState table B-13](#)  
[qsrLunTable table B-12](#)  
[qsrLunVendorId table B-13](#)  
[qsrLunVPGroupId table B-14](#)  
[qsrLunVPGroupname table B-14](#)  
[qsrLunWwuln table B-12](#)  
[qsrMacAddress table B-6](#)  
[qsrNetMask table B-6](#)  
[qsrNoOfFcPorts object B-19](#)  
[qsrNoOfGbEPorts object B-19](#)  
[qsrNwLinkRate table B-6](#)  
[qsrNwLinkStatus table B-6](#)  
[qsrNwPortAddressMode table B-5](#)  
[qsrNwPortDown notification B-21](#)  
[qsrNwPortEntry table B-4](#)  
[qsrNwPortIndex table B-5](#)  
[qsrNwPortRole table B-5](#)

[qsrNwPortTable table B-4](#)  
[qsrPresTgtMapped notification B-22](#)  
[qsrSensorEntry table B-16](#)  
[qsrSensorIndex table B-17](#)  
[qsrSensorNotification notification B-22](#)  
[qsrSensorState table B-18](#)  
[qsrSensorTable table B-16](#)  
[qsrSensorType table B-16](#)  
[qsrSensorUnits table B-17](#)  
[qsrSensorValue table B-17](#)  
[qsrSerialNumber object B-19](#)  
[qsrSwVersion object B-19](#)  
[qsrUpperThreshold table B-17](#)  
[qsrVPGroupEntry table B-14](#)  
[qsrVPGroupId tables B-15](#)  
[qsrVPGroupIndex table B-15](#)  
[qsrVPGroupName table B-15](#)  
[qsrVPGroupStatus table B-15](#)  
[qsrVPGroupStatusChanged notification B-22](#)  
[qsrVPGroupTable table B-14](#)  
[qsrVPGroupWWNN table B-15](#)  
[qsrVPGroupWWPN table B-15](#)

## R

[read community, setting SNMP properties B-2](#)  
[recovering a router 6-4](#)  
[recovery from router failure 2-8](#)  
[reduced instruction set computer, See RISC](#)  
[registered state change notification, See RSCN](#)  
[related materials xii](#)  
[remote](#)

- [IP address, FCIP 5-5](#)
- [SAN island, connectivity 1-2](#)
- [storage, FCIP 5-8](#)

[removing](#)

- [failed blade 7-2, 7-5](#)
- [failed PCM 7-11](#)

[replacing failed blade 7-3, 7-8](#)  
[requirements](#)

- [browser 3-2](#)
- [power 3-2](#)

- site [3-1](#)
- workstation [3-1](#)
- resetting router blade [1-11](#)
- restoring factory defaults [1-12](#)
- RISC
  - definition of [Glossary-8](#)
  - FC processor firmware failed [C-18](#)
  - FC processor paused [C-18](#)
  - FC processor restarted [C-19](#)
  - iSCSI processor restarted [C-17](#)
- round-trip latency
  - determining [1-3](#)
- round-trip time (RTT), FCIP [5-11](#)
- router
  - blade, resetting [1-11](#)
  - configuring [3-16](#)
  - management [2-8](#)
  - mounting [3-5](#)
  - recovering [6-4](#)
  - SAN islands [1-2](#)
- router log, definition of [Glossary-8](#)
- Router Manager, See SANsurfer Router Manager
- router models
  - iSR6240 [1-9](#)
  - iSR6250 [1-8](#)
  - iSR6260 [1-7](#)
- RSCN
  - definition of [Glossary-8](#)
  - update received [C-22](#)
- RTT, FCIP, configuring [5-11](#)

## S

- safety specifications [A-4](#)
- SAN
  - definition of [Glossary-8](#)
  - E\_Port extension [5-6](#)
  - F\_Port extension [5-8](#)
  - islands, remote [1-2](#)
  - islands, supported configuration [5-1](#)
- SANsurfer Router Manager
  - configuring router [3-16](#)

- definition of [Glossary-8](#)
- downloading [3-13](#)
- Linux installation [3-15](#)
- Mac OS X installation [3-15](#)
- services [2-8](#)
- starting [3-16](#)
- VPGs, enabling and disabling [4-3](#)
- Windows installation [3-15](#)
- SCSI
  - command error [C-19](#)
  - definition of [Glossary-8](#)
  - documents, related [1-xiii](#)
  - status error [C-6](#)
- Secure SHell, See SSH
- security [2-9](#)
- sensor state [B-18](#)
- sensor state notification [B-22](#)
- sensor table, MIB object group [B-16](#)
- sensors
  - data measurement type [B-16](#)
  - entry/row [B-16](#)
  - index/identifier [B-17](#)
  - listing all [B-16](#)
  - lower-level threshold [B-17](#)
  - unit of measure [B-17](#)
  - upper-level threshold [B-17](#)
  - value of [B-17](#)
- serial
  - port [1-16](#)
  - workstation port [3-12](#)
- serial number, showing [B-19](#)
- SFF
  - definition of [Glossary-8](#)
  - router, connecting cables [3-17](#)
- SFP
  - definition of [Glossary-8](#)
  - optical transceivers, removing and replacing [7-1](#)
  - transceivers [1-14](#)
- showing
  - number of FC ports [B-19](#)
  - system hardware version number [B-19](#)
  - system serial number [B-19](#)
- shutdown notification, agent [B-20](#)

simple network management protocol, *See* [SNMP](#)  
site requirements [3-1](#)  
small computer system interface, *See* [SCSI](#)  
small form factor, *See* [SFF](#)  
small form-factor pluggable, *See* [SFP](#)  
SMI-S  
    definition of [Glossary-8](#)  
    device management [A-3](#)  
SNMP [2-8](#)  
    definition of [Glossary-9](#)  
    notifications [B-18](#)  
        agent shutdown [B-20](#)  
        agent startup [B-20](#)  
        FC port down [B-21](#)  
        generic [B-24](#)  
        network port down [B-21](#)  
        objects [B-20](#)  
        sensor state [B-22](#)  
    parameters, configuring [B-2](#)  
    trap configuration [B-3](#)  
software version, showing [B-19](#)  
software, router [2-7](#)  
specifications  
    interface [A-1](#)  
    mechanical [A-3](#)  
    technical [A-1](#)  
SSH  
    definition of [Glossary-9](#)  
    service [2-9](#)  
startup notification, agent [B-20](#)  
storage area network, *See* [SAN](#)  
storage management initiative-specification,  
    *See* [SMI-S](#)  
subnet mask  
    FCIP, GE port [5-5](#)  
    port [B-6](#)  
switched fabric, definition of [Glossary-3](#)  
system  
    error blink patterns [6-3](#)  
    fault LED [1-10](#)  
    hardware version number, showing [B-19](#)  
    serial number, showing [B-19](#)

    software/firmware version number, showing [B-19](#)  
system information, MIB object group [B-18](#)

## T

T1  
    definition of [Glossary-2](#)  
    TCP window sizes [2-4](#)  
    window size settings [5-17](#)  
T3  
    definition of [Glossary-2](#)  
    TCP window size [2-5](#)  
tables  
    FC ports [B-7](#)  
    LUN [B-12](#)  
    LunVPGroupid [B-14](#)  
    MIB [B-3](#)  
    network ports [B-4](#)  
    qsrFcLinkRate [B-9](#)  
    qsrFcLinkStatus [B-9](#)  
    qsrFcPortEntry [B-7](#)  
    qsrFcPortId [B-8](#)  
    qsrFcPortIndex [B-8](#)  
    qsrFcPortNodeWwn [B-8](#)  
    qsrFcPortRole [B-8](#)  
    qsrFcPortTable [B-7](#)  
    qsrFcPortType [B-9](#)  
    qsrFcPortWwn [B-8](#)  
    qsrGateway [B-6](#)  
    qsrIPAddress [B-5](#)  
    qsrIPAddressType [B-5](#)  
    qsrIsInitAddress [B-11](#)  
    qsrIsInitAddressType [B-11](#)  
    qsrIsInitAlias [B-10](#)  
    qsrIsInitChapEnabled [B-11](#)  
    qsrIsInitEntry [B-10](#)  
    qsrIsInitIndex [B-10](#)  
    qsrIsInitName [B-10](#)  
    qsrIsInitOsType [B-11](#)  
    qsrIsInitStatus [B-11](#)  
    qsrIsInitTable [B-9](#)  
    qsrLowerThreshold [B-17](#)

qsrLunEntry [B-12](#)  
qsrLunProdRevLevel [B-13](#)  
qsrLunProductId [B-13](#)  
qsrLunSize [B-13](#)  
qsrLunState [B-13](#)  
qsrLunTable [B-12](#)  
qsrLunVendorId [B-13](#)  
qsrLunVPGroupName [B-14](#)  
qsrLunWwuln [B-12](#)  
qsrMacAddress [B-6](#)  
qsrNetMask [B-6](#)  
qsrNwLinkRate [B-6](#)  
qsrNwLinkStatus [B-6](#)  
qsrNwPortAddressMode [B-5](#)  
qsrNwPortEntry [B-4](#)  
qsrNwPortIndex [B-5](#)  
qsrNwPortRole [B-5](#)  
qsrNwPortTable [B-4](#)  
qsrSensorEntry [B-16](#)  
qsrSensorIndex [B-17](#)  
qsrSensorState [B-18](#)  
qsrSensorTable [B-16](#)  
qsrSensorType [B-16](#)  
qsrSensorUnits [B-17](#)  
qsrSensorValue [B-17](#)  
qsrUpperThreshold [B-17](#)  
qsrVPGroupEntry [B-14](#)  
qsrVPGroupId [B-15](#)  
qsrVPGroupIndex [B-15](#)  
qsrVPGroupName [B-15](#)  
qsrVPGroupStatus [B-15](#)  
qsrVPGroupTable [B-14](#)  
qsrVPGroupWWPN [B-15](#)  
sensor [B-16](#)  
virtual port groups (VPGs) [B-14](#)  
targets  
  definition of [Glossary-9](#)  
  discovery [B-21](#)  
  mapping [B-22](#)  
  mapping to initiator [1-3](#)  
  online/offline [B-21](#)  
  presentation [B-22](#)  
TCP  
  port number, FCIP [5-5](#)

  window settings, FCIP [5-17](#)  
  window setup [5-22](#)  
  window size [1-3](#)  
technical specifications [A-1](#)  
technical support [xix](#)  
Telnet  
  connecting to new blade [7-7](#)  
  definition of [Glossary-9](#)  
  logging into router [3-16](#)  
  port, unblocking [5-15](#)  
  router management [3-11](#)  
  service availability [2-8](#)  
terms and definitions [Glossary-1](#)  
time, event notification [B-20](#)  
TOE module message [C-33](#)  
trace route, support for [5-1](#)  
transceivers [1-14](#)  
  installing [3-6](#)  
  removing and replacing [7-1](#)  
traps  
  authentication, enabling [B-2](#)  
  community, setting SNMP properties [B-2](#)  
  configuration, SNMP [B-3](#)  
troubleshooting [6-1](#)

## U

unblocking ports in firewall [5-15](#)

## V

version number  
  hardware, showing [B-19](#)  
  software/firmware, showing [B-19](#)  
virtual LAN, definition of [Glossary-9](#)  
virtual logical area network (LAN), See VLAN  
VLAN  
  definition of [Glossary-9](#)  
  FCIP, configuring [5-6](#)  
VPGs  
  definition of [Glossary-9](#)  
  enabling [4-2](#)



- enabling and disabling [4-3](#)
- enabling/disabling with CLI [4-5](#)
- enabling/disabling with GUI [4-3](#), [4-5](#)
- guidelines [4-1](#)
- information [4-3](#)
- notifications [B-22](#)
- required FC switches [2-2](#)
- showing [4-6](#)
- tables [B-14](#)
- zoning [4-9](#)

## Z

- zoning VPGs [4-9](#)

## W

### WAN

- characteristic, determining [5-10](#)
- data rate for FCIP [5-12](#)
- link quality for FCIP [5-12](#)
- what's in this guide [xi](#)
- window scaling, configuring FCIP [5-5](#)
- window settings, TCP [5-17](#), [5-22](#)
- Windows, installing SANsurfer Router Manager on [3-15](#)
- workstation
  - configuring [3-11](#)
  - connecting to router [3-10](#)
  - definition of [Glossary-5](#)
  - IP address [3-11](#)
  - requirements [3-1](#)
  - serial port [3-12](#)
- world wide node name, See WWNN
- world wide port name, See WWPN
- world wide unique LUN name, See WWULN
- WWNN
  - definition of [Glossary-9](#)
  - Fibre Channel port [B-8](#)
  - login message [C-9](#)
- WWPN
  - definition of [Glossary-10](#)
  - login message [C-9](#)
- WWULN
  - definition of [Glossary-10](#)
  - viewing for LUN [B-12](#)







**Corporate Headquarters** QLogic Corporation 26650 Aliso Viejo Parkway Aliso Viejo, CA 92656 949.389.6000 [www.qlogic.com](http://www.qlogic.com)

**International Offices** UK | Ireland | Germany | France | India | Japan | China | Hong Kong | Singapore | Taiwan

---

© 2009–2012 QLogic Corporation. Specifications are subject to change without notice. All rights reserved worldwide. QLogic and the QLogic logo are registered trademarks, and TrueFlex are trademarks of QLogic Corporation. ATTO is a registered trademark of ATTO Technology Inc. FICON is a registered trademark of IBM Corporation. Linux is a registered trademark of Linus Torvalds. Mac OS is a registered trademark of Apple, Inc. Mozilla and Firefox are registered trademarks of the Mozilla Foundation. Red Hat and Enterprise Linux are registered trademarks of Red Hat, Inc. Solaris and Java are trademarks or registered trademarks of Sun Microsystems, Inc. SUSE is a registered trademark of Novell, Inc. UNIX is a registered trademark of The Open Group. Windows is a registered trademark of Microsoft Corporation. All other brand and product names are trademarks or registered trademarks of their respective owners. Information supplied by QLogic Corporation is believed to be accurate and reliable. QLogic Corporation assumes no responsibility for any errors in this brochure. QLogic Corporation reserves the right, without notice, to make changes in product design or specifications.